

# SIEMENS

## SIPART

### Electropneumatic positioner SIPART PS2 with PROFIBUS PA

#### Operating Instructions


6DR55..  
6DR59..


Introduction	1
Safety information	2
Description	3
Installing/mounting	4
Connect	5
Operation	6
Commissioning	7
Parameter assignment	8
Functions/operations using PROFIBUS PA	9
Functional safety	10
Service and maintenance	11
Diagnostics and troubleshooting	12
Technical data	13
Dimension drawing	14
Spare parts/accessories/ scope of delivery	15
Appendix	A
External position detection	B
Pressure gauge block	C
Sealing plug / thread adapter	D
Booster	E
Positioner with remote control electronics	F
Abbreviations	G


## Legal information

### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 <b>DANGER</b>
indicates that death or severe personal injury <b>will</b> result if proper precautions are not taken.

 <b>WARNING</b>
indicates that death or severe personal injury <b>may</b> result if proper precautions are not taken.

 <b>CAUTION</b>
indicates that minor personal injury can result if proper precautions are not taken.

<b>NOTICE</b>
indicates that property damage can result if proper precautions are not taken.


If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

### Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

### Proper use of Siemens products

Note the following:

 <b>WARNING</b>
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

### Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

### Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

# Table of contents

<b>1</b>	<b>Introduction</b>	<b>13</b>
1.1	Purpose of this documentation	13
1.2	Scope of documentation	13
1.3	Document history	14
1.4	Product compatibility	15
1.5	Checking the consignment	15
1.6	Purpose	15
1.7	Security information	16
1.8	Transportation and storage	16
1.9	Notes on warranty	17
<b>2</b>	<b>Safety information</b>	<b>19</b>
2.1	Precondition for use	19
2.2	Warning symbols on the device	19
2.3	Laws and directives	19
2.4	Conformity with European directives	20
2.5	Improper device modifications	20
2.6	Requirements for special applications	21
2.7	Use in hazardous areas	21
<b>3</b>	<b>Description</b>	<b>23</b>
3.1	Function	23
3.2	Structure	23
3.2.1	Design overview	23
3.2.2	Nameplate layout	26
3.2.3	Explanation of Ex information	27
3.3	Device components	28
3.3.1	Overview of device components	28
3.3.2	Overview of device components (Ex)	29
3.3.3	Basic electronics	30
3.4	Functional principle	30
3.4.1	PROFIBUS system configuration	32
3.4.2	SIMATIC PDM	33
3.5	PROFIBUS PA	33
3.5.1	Overview	33
3.5.2	Transmission technology	33
3.5.3	Bus topology	34

3.5.4	Properties .....	35
3.5.5	Profile .....	35
3.5.6	Connection .....	35
3.5.7	Number of connectable devices .....	37
3.5.8	Assigning the device addresses .....	37
<b>4</b>	<b>Installing/mounting .....</b>	<b>39</b>
4.1	Basic safety instructions .....	39
4.1.1	Exceeded maximum permissible operating pressure .....	39
4.1.2	Proper mounting.....	41
4.1.2.1	Freezing of the exhaust air outlets.....	41
4.2	Mounting to linear actuator .....	42
4.3	Mounting to part-turn actuator .....	47
4.4	Setting and locking the transmission ratio .....	50
4.5	Installing the optional modules .....	53
4.5.1	General information about the installation of option modules .....	53
4.5.1.1	Opening the standard and and intrinsically safe version.....	53
4.5.1.2	Closing the standard and and intrinsically safe version.....	55
4.5.1.3	Opening the device version with "flameproof enclosure".....	56
4.5.1.4	Closing the device version with "flameproof enclosure".....	59
4.5.2	Position feedback modules 6DR4004-6J and -8J.....	60
4.5.3	Alarm modules 6DR4004-6A and -8A .....	62
4.5.4	Slot initiator alarm modules 6DR4004-6G and -8G .....	64
4.5.5	Mechanical limit switch modules 6DR4004-6K and -8K .....	66
4.5.6	Internal NCS modules (iNCS) 6DR4004-5L and -5LE .....	70
4.5.7	EMC filter modules 6DR4004-6F and -8F.....	74
<b>5</b>	<b>Connect.....</b>	<b>77</b>
5.1	Basic safety instructions .....	77
5.1.1	Interference immunity .....	81
5.1.2	Safety shutdown .....	81
5.2	Electrical wiring .....	82
5.2.1	Connection diagram for basic electronics.....	82
5.2.2	Bus cable .....	82
5.2.3	Option modules .....	85
5.2.3.1	Alarm modules 6DR4004-6A and -8A .....	85
5.2.3.2	Position feedback modules 6DR4004-6J and -8J.....	86
5.2.3.3	SIA modules 6DR4004-6G and -8G .....	86
5.2.3.4	Mechanical limit switch modules 6DR4004-6K and -8K .....	87
5.2.3.5	EMC filter modules 6DR4004-6F and -8F.....	89
5.2.4	Option device version M12 connector .....	90
5.2.4.1	M12 connector in the basic device .....	90
5.2.4.2	M12 connector for connecting the position feedback module 6DR4004-6J / 8J (-Z D53) .....	91
5.2.4.3	M12 connector for connecting the external position detection system (-Z D54).....	91
5.2.4.4	M12 connector for connecting the alarm module 6DR4004-6A / -8A (-Z D55).....	91
5.2.4.5	M12 connector for connecting the SIA module 6DR4004-6G / -8G (-Z D56).....	92
5.2.4.6	M12 connector for connecting the mechanical limit switch module 6DR4004-6K (-Z D57).....	92
5.3	Pneumatic connection .....	92
5.3.1	Basic safety instructions for the pneumatic connection .....	92

5.3.2	Pneumatic connection in non-flameproof enclosure .....	93
5.3.2.1	Structure of pneumatic connection .....	93
5.3.2.2	Integrated pneumatic connection.....	93
5.3.3	Pneumatic connection in the flameproof enclosure .....	94
5.3.4	Reaction to failure of auxiliary powers .....	95
5.4	Restrictors.....	95
<b>6</b>	<b>Operation.....</b>	<b>97</b>
6.1	Operating elements .....	97
6.1.1	Display.....	97
6.1.2	Buttons.....	98
6.1.3	Firmware version .....	100
6.2	Operating modes .....	100
6.2.1	Overview of operating modes .....	100
6.2.2	Changing the operating mode.....	101
6.2.3	Overview of configuration.....	102
6.2.4	Description of operating modes .....	102
6.2.5	Optimization of controller data .....	104
<b>7</b>	<b>Commissioning .....</b>	<b>107</b>
7.1	Basic safety instructions .....	107
7.1.1	Lever for position detection.....	107
7.2	Overview .....	109
7.3	Sequence of automatic initialization.....	111
7.4	Setting the friction clutch.....	116
7.5	Purge air switching .....	118
7.6	Commissioning linear actuators .....	118
7.6.1	Preparing linear actuators for commissioning .....	118
7.6.2	Automatic initialization of linear actuators.....	120
7.6.3	Manual initialization of linear actuators.....	122
7.7	Commissioning part-turn actuators .....	125
7.7.1	Preparing part-turn actuators for commissioning .....	125
7.7.2	Automatic initialization of part-turn actuators .....	126
7.7.3	Manual initialization of part-turn actuators.....	127
7.8	Canceling initialization.....	129
7.9	Device replacement .....	130
<b>8</b>	<b>Parameter assignment.....</b>	<b>133</b>
8.1	Introduction to parameter assignment section.....	133
8.2	Tabular overview of the parameters.....	134
8.2.1	Overview of initialization parameters 1 to 5.....	134
8.2.2	Overview of application parameters 6 to 55 .....	135
8.2.3	Overview of advanced diagnostics parameters A to P.....	138
8.3	Description of parameters .....	142
8.3.1	Initialization parameters 1 to 5.....	142
8.3.1.1	'1.YFCT' type of actuator .....	142

8.3.1.2	'2.YAGL' Rated angle of rotation of feedback .....	143
8.3.1.3	'3.YWAY' Range of stroke .....	144
8.3.1.4	'4.INITA' Initialization (automatically).....	145
8.3.1.5	'5.INITM' Initialization (manual).....	145
8.3.2	Application parameters 6 to 55 .....	145
8.3.2.1	'6.SDIR' Setpoint direction .....	145
8.3.2.2	'7.TSUP' Setpoint ramp UP / '8.TSDO' Setpoint ramp DOWN .....	146
8.3.2.3	'9.SFCT' Setpoint function .....	146
8.3.2.4	'10.SL0' ... '30.SL20' Setpoint turning point.....	147
8.3.2.5	'31.DEBA' Deadband of controller .....	148
8.3.2.6	'32.YA' Manipulated variable limiting Start / '33.YE' Manipulated variable limiting End .....	148
8.3.2.7	'34.YNRM' Manipulated variable standardization.....	149
8.3.2.8	'35.YDIR' Direction of action of manipulated variable for display and position feedback .....	150
8.3.2.9	'36.YCLS' Tight closing/fast closing with manipulated variable .....	150
8.3.2.10	'37.YCDO' Value for tight closing/fast closing Down .....	151
8.3.2.11	'38.YCUP' Value for tight closing/fast closing Up .....	152
8.3.2.12	'38.YCUP' Upper value for tight closing / fast closing .....	152
8.3.2.13	'39.BIN1' / '40.BIN2' Function of binary inputs.....	153
8.3.2.14	'41.AFCT' Alarm function.....	154
8.3.2.15	'42.A1' / '43.A2' Alarm response threshold .....	156
8.3.2.16	'44.\IFCT' Function fault message .....	156
8.3.2.17	'45.\ITIM' Monitoring time for setting of fault message 'Control deviation' .....	157
8.3.2.18	'46.\LIM' Response threshold of fault message 'Control deviation' .....	157
8.3.2.19	'47.\STRK' Limit monitoring for the number of total strokes .....	158
8.3.2.20	'48.PRST' Preset.....	158
8.3.2.21	'49.PNEUM' Pneumatics type.....	159
8.3.2.22	'50.XDIAG' Activation of extended diagnostics .....	160
8.3.2.23	'51.FSTY' Safety position .....	161
8.3.2.24	'52.FSTI' Monitoring time to set the safety position .....	162
8.3.2.25	'53.FSVL' Safety setpoint .....	162
8.3.2.26	'54.STNR' Station number.....	162
8.3.2.27	'55.IDENT' Device operating mode (ID No.) .....	162
8.3.3	Extended diagnostics parameters A to P .....	163
8.3.3.1	Partial stroke test 'A.\PST'.....	163
8.3.3.2	Monitoring of dynamic control valve behavior 'b.\DEVI' .....	168
8.3.3.3	Monitoring/compensation of pneumatic leakage 'C.\LEAK' .....	170
8.3.3.4	Monitoring of stiction (slipstick) 'd.\STIC'.....	173
8.3.3.5	Monitoring of deadband 'E.\DEBA' .....	175
8.3.3.6	Monitoring the lower endstop 'F.\ZERO'.....	176
8.3.3.7	Monitoring the upper endstop 'G.\OPEN'.....	177
8.3.3.8	Monitoring the lower limit temperature 'H.\TMIN' .....	179
8.3.3.9	Monitoring the upper limit temperature 'J.\TMAX' .....	180
8.3.3.10	Monitoring of number of total strokes 'L.\STRK' .....	182
8.3.3.11	Monitoring of number of changes in direction 'O.\DCHG' .....	183
8.3.3.12	Monitoring the position average value 'P.\PAVG' .....	185
<b>9</b>	<b>Functions/operations using PROFIBUS PA.....</b>	<b>189</b>
9.1	System integration.....	189
9.2	Acyclic data transfer.....	189
9.2.1	Acyclic data transfer using SIMATIC PDM .....	189
9.2.2	'Device' menu .....	190
9.2.2.1	Load to device .....	190

9.2.2.2	Load into PG/PC .....	190
9.2.2.3	Assign address and TAG.....	190
9.2.2.4	Value comparison .....	190
9.2.2.5	Object properties .....	191
9.2.2.6	Calibration report.....	192
9.2.2.7	Change log .....	193
9.2.2.8	Wizard .....	194
9.2.2.9	Partial stroke test (PST) .....	195
9.2.2.10	PST trace characteristic .....	195
9.2.2.11	Offline leakage test .....	195
9.2.2.12	Maintenance and diagnostics .....	196
9.2.2.13	Initialization parameters.....	196
9.2.2.14	Initialization.....	197
9.2.2.15	Operation .....	197
9.2.2.16	Simulation .....	200
9.2.2.17	Date and time in the device.....	200
9.2.2.18	Write protection .....	201
9.2.2.19	Reset parameters in PDM.....	201
9.2.2.20	Reset parameters on the device.....	201
9.2.2.21	Reset the field device .....	202
9.2.3	'View' menu .....	203
9.2.3.1	Process variables / diagnostics cockpit .....	203
9.2.3.2	Starting the lifelist .....	204
9.2.4	'Diagnostics' menu .....	204
9.2.4.1	Updating diagnostics .....	204
9.2.4.2	Device diagnostics .....	206
9.2.4.3	Maintenance information.....	207
9.2.4.4	Trend characteristic.....	208
9.2.4.5	Histograms .....	208
9.2.4.6	Alarm logbook .....	208
9.2.4.7	Characteristic curve .....	209
9.3	Cyclic data transfer .....	209
9.3.1	Configuration.....	209
9.3.2	Useful data through PROFIBUS .....	212
9.3.2.1	Possible combinations of the useful data .....	213
9.3.2.2	Diagnostics.....	217
9.3.3	Adjustable status (condensed status) .....	218
9.3.3.1	Diagnostics messages in case of deactivated condensed status .....	222
9.3.3.2	Diagnostics messages in case of activated condensed status.....	224
9.3.3.3	Definition of the status.....	226
9.3.3.4	Sub-status for deactivated condensed status .....	227
9.3.3.5	Sub-status for activated condensed status .....	227
9.3.3.6	List of diagnostics events with status and diagnostics message for deactivated condensed status .....	228
9.3.3.7	List of diagnostics events with status and diagnostics message for activated condensed status .....	230
<b>10</b>	<b>Functional safety .....</b>	<b>235</b>
10.1	Range of applications for functional safety .....	235
10.2	Safety function .....	235
10.3	Safety Integrity Level (SIL).....	237

10.4	Settings .....	238
10.5	Safety characteristics .....	239
10.6	Maintenance/check.....	240
<b>11</b>	<b>Service and maintenance .....</b>	<b>241</b>
11.1	Basic safety instructions .....	241
11.1.1	Cleaning the enclosure .....	241
11.2	Cleaning of the screens .....	242
11.2.1	Positioners 6DR5..0, 6DR5..3 and 6DR5..5 .....	242
11.2.2	Positioners 6DR5..1, 6DR5..2 and 6DR5..6 .....	243
11.3	Maintenance and repair work.....	243
11.3.1	Maintenance during continued operation in a hazardous area .....	243
11.3.2	Repair/Upgrading .....	244
11.4	Replace basic electronics.....	244
11.5	Replace pneumatic block.....	245
11.6	Return procedure .....	247
11.7	Disposal.....	248
<b>12</b>	<b>Diagnostics and troubleshooting.....</b>	<b>249</b>
12.1	Output of system messages in the display .....	249
12.1.1	System messages during operation .....	249
12.1.2	System messages before initialization.....	250
12.1.3	System messages during initialization .....	251
12.1.4	System messages when exiting the Configuration mode.....	253
12.1.5	System messages during operation .....	254
12.2	Diagnostics.....	256
12.2.1	Display of diagnostics values .....	256
12.2.2	Saving the diagnostics values.....	257
12.2.3	Overview of diagnostics values .....	257
12.2.4	Meaning of the diagnostic values.....	259
12.2.4.1	Diagnostic value '1.STRKS - Number of total strokes' .....	259
12.2.4.2	Diagnostic value '2.CHDIR - Number of changes in direction' .....	259
12.2.4.3	Diagnostic value '3.\CNT - Number of fault messages' .....	259
12.2.4.4	Diagnostic value '4.A1CNT - Number of alarms 1' / '5.A2CNT - Number of alarms 2' .....	259
12.2.4.5	Diagnostic value '6.HOURS - Number of operating hours'.....	260
12.2.4.6	Diagnostic value '7.HOURR - Resettable operating hours counter' .....	260
12.2.4.7	Diagnostic value '8.WAY - Determined travel' .....	260
12.2.4.8	Diagnostic value '9.TUP - Travel time up' / '10.TDOWN - Travel time down' .....	260
12.2.4.9	Diagnostic value '11.LEAK - Leakage test'.....	261
12.2.4.10	Diagnostic value '12.PST - Monitoring of partial stroke test'.....	262
12.2.4.11	Diagnostic value '13.PRPST' - Time since last partial stroke test' .....	263
12.2.4.12	Diagnostic value '14.NXPST - Time until next partial stroke test' .....	263
12.2.4.13	Diagnostics value '15.DEVI - Dynamic control valve behavior' .....	263
12.2.4.14	Diagnostic value '16.ONLK - Pneumatic leakage' .....	263
12.2.4.15	Diagnostic value '17.STIC - Stiction (slipstick)' .....	264
12.2.4.16	Diagnostic value '18.ZERO - Lower endstop' .....	264
12.2.4.17	Diagnostic value '19.OPEN - Upper endstop' .....	264



12.2.4.18	Diagnostic value '20.PAVG - Average value of position' .....	265
12.2.4.19	Diagnostic value '21.P0 - Potentiometer value of lower endstop (0%)' / '22.P100 - Potentiometer value of upper endstop (100%)' .....	265
12.2.4.20	Diagnostic value '23.IMPUP - Pulse length up' / '24.IMPDN - Pulse length down' .....	267
12.2.4.21	Diagnostic value '25.PAUP - Pulse interval' .....	267
12.2.4.22	Diagnostic value '26.DBUP - Deadband up' / '27.DBDN - Deadband down' .....	267
12.2.4.23	Diagnostic value '28.SSUP - Slow step zone up' / '29.SSDN - Slow step zone down' .....	267
12.2.4.24	Diagnostic value '30.TEMP - Current temperature' .....	268
12.2.4.25	Diagnostic value '31.TMIN - Minimum temperature' / '32.TMAX - Maximum temperature' ..	268
12.2.4.26	Diagnostic value '33.T1' ... '41.T9' - Number of operating hours in the temperature range 1 to 9 .....	268
12.2.4.27	Diagnostic value '42.VENT1' / '43.VENT2' .....	268
12.2.4.28	Diagnostic value '44.VEN1R' / '45.VEN2R' .....	269
12.2.4.29	Diagnostic value '46.STORE - Save maintenance data' .....	270
12.2.4.30	Diagnostic value '47.PRUP - Prediction up' / '48.PRDN - Prediction down' .....	270
12.2.4.31	Diagnostic value '49.WT00' ... '56.WT95' - Number of operating hours in the travel range WT00 to WT95 .....	270
12.2.4.32	Diagnostics value '50.LKPUL - Length of the leakage compensation pulse' .....	271
12.2.4.33	Diagnostics value '51.LKPER - Period of the leakage compensation pulse' .....	271
12.3	Online diagnostics .....	271
12.3.1	Overview of online diagnostics .....	271
12.3.2	Overview of error codes .....	272
12.3.3	XDIAG parameter .....	274
12.3.4	Meaning of error codes .....	274
12.3.4.1	1 Remaining control deviation .....	274
12.3.4.2	2 Device not in "Automatic" mode .....	274
12.3.4.3	3 Binary input BIN1 or BIN2 active .....	274
12.3.4.4	4 Monitoring the number of total strokes .....	275
12.3.4.5	5 Monitoring the number of changes in direction .....	275
12.3.4.6	6 Monitoring the lower endstop and 7 Monitoring the upper endstop .....	275
12.3.4.7	8 Monitoring deadband .....	275
12.3.4.8	9 Partial stroke test .....	276
12.3.4.9	10 Monitoring of dynamic control valve behavior .....	276
12.3.4.10	11 Monitoring/compensation of pneumatic leakage .....	276
12.3.4.11	12 Monitoring of stiction (slipstick) .....	276
12.3.4.12	13 Monitoring the lower limit temperature .....	276
12.3.4.13	14 Monitoring the upper limit temperature .....	276
12.3.4.14	15 Monitoring the position average value .....	276
12.3.4.15	16 Monitoring the plausibility of values for the partial stroke test .....	276
12.4	Fault correction .....	277
12.4.1	Fault identification .....	277
12.4.2	Remedial measures table 1 .....	277
12.4.3	Remedial measures table 2 .....	278
12.4.4	Corrective measures Table 3 .....	279
12.4.5	Corrective measures Table 4 .....	279
12.4.6	Remedial measures table 5 .....	280
<b>13</b>	<b>Technical data .....</b>	<b>281</b>
13.1	Rated conditions .....	281
13.2	Pneumatic data .....	282

13.3	Construction .....	283
13.4	Controller .....	284
13.5	Explosion protection .....	285
13.5.1	Breakdown of the article numbers.....	285
13.5.2	Protection against explosion device and option modules.....	287
13.5.3	Maximal permissible ambient temperature ranges.....	288
13.6	Certificates, approvals, explosion protection .....	289
13.7	Electrical specifications .....	289
13.8	Communication .....	291
13.9	Technical data for natural gas as actuator medium.....	292
13.10	Option modules .....	293
13.10.1	Alarm module.....	293
13.10.2	Position feedback module .....	294
13.10.3	SIA module .....	295
13.10.4	Mechanical limit switch module .....	296
13.10.5	EMC filter module .....	297
13.10.6	Internal NCS modules 6DR4004-5L and 6DR4004-5LE.....	297
13.10.7	Other technical specifications .....	297
<b>14</b>	<b>Dimension drawing.....</b>	<b>299</b>
14.1	Positioner in non-flameproof enclosure .....	299
14.2	Terminal strip for positioner with polycarbonate enclosure .....	300
14.3	Positioner in flameproof enclosure .....	301
<b>15</b>	<b>Spare parts/accessories/scope of delivery .....</b>	<b>303</b>
15.1	Overview .....	303
15.2	Spare parts .....	304
15.3	Scope of delivery of mechanical limit switch module .....	307
15.4	Scope of delivery EMC filter module .....	308
15.5	Accessories.....	309
15.6	Order data .....	309
<b>A</b>	<b>Appendix.....</b>	<b>311</b>
A.1	Certificates.....	311
A.2	Technical support.....	311
<b>B</b>	<b>External position detection .....</b>	<b>313</b>
B.1	Introduction to external position detection .....	313
B.2	Non-Contacting Sensor .....	314
B.2.1	Principle of operation of NCS.....	314
B.2.2	Mounting the NCS .....	315
B.2.2.1	Mounting on part-turn actuator .....	316
B.2.2.2	Mounting on linear actuator up to 14 mm (0.55 inch) .....	318
B.2.2.3	Mounting on linear actuator > 14 mm (0.55 inch) .....	320

B.2.3	Connecting NCS to EMC filter module .....	323
B.2.4	Commissioning of NCS.....	324
B.2.4.1	Prerequisites / default settings.....	324
B.2.4.2	Initialization of part-turn actuators .....	325
B.2.4.3	Initializing linear actuators with a stroke range up to 14 mm (0.55 inch).....	325
B.2.4.4	Initializing linear actuators with a stroke range > 14 mm (0.55 inch).....	325
B.2.5	Technical specifications NCS.....	325
B.2.6	Dimensional drawing of non-contacting sensor .....	327
B.2.7	NCS sensor scope of delivery.....	327
B.2.7.1	Scope of delivery of NCS for part-turn actuators .....	327
B.2.7.2	Scope of delivery of NCS for linear actuators up to 14 mm (0.55 inch) . .....	328
B.2.7.3	Scope of delivery of NCS for linear actuators > 14 mm (0.55 inch) . .....	328
B.3	External position detection system .....	329
B.3.1	Principle of operation of external position detection system.....	329
B.3.2	Connecting the external position detection system to the EMC filter module .....	329
B.3.3	Technical specifications of the external position detection system .....	330
B.3.4	Scope of delivery of external position detection system .....	330
<b>C</b>	<b>Pressure gauge block.....</b>	<b>333</b>
<b>D</b>	<b>Sealing plug / thread adapter .....</b>	<b>335</b>
D.1	Intended use of accessory part .....	335
D.2	Safety instructions for accessory part .....	335
D.3	Technical specifications of accessory part .....	336
D.4	Dimension drawing for accessory part.....	337
<b>E</b>	<b>Booster.....</b>	<b>339</b>
E.1	Increased sound pressure level .....	339
E.2	Booster introduction .....	339
E.3	Operating principle of booster.....	340
E.4	Mounting booster, without flameproof enclosure .....	341
E.5	Booster mounting, flameproof enclosure.....	345
E.6	Booster commissioning .....	349
E.7	RUN 3 and 4 sequence (booster) .....	351
E.8	Booster dimension drawings .....	352
E.8.1	For positioners in non-flameproof enclosure.....	352
E.8.2	For positioners in flameproof enclosure.....	353
E.9	Technical specifications of booster.....	353
<b>F</b>	<b>Positioner with remote control electronics .....</b>	<b>355</b>
F.1	Introduction.....	355
F.2	19" slide-in module .....	356
F.2.1	Commissioning positioner 6DR5910-... and 19" slide-in module.....	356
F.2.2	Connecting the positioner to the 19" slide-in module .....	358
F.2.3	Connecting multiple positioners.....	360
F.2.4	PA cable connection for bus connection .....	361

F.2.5 Connecting 19" slide-in modules ..... 362

F.3 Positioner with remote control electronics ..... 363

F.4 Technical specifications, 19" slide-in module ..... 363

F.5 Scope of delivery of remote control electronics ..... 364

F.6 Grounding concept 19" slide-in module ..... 365

**G Abbreviations..... 367**

G.1 Abbreviations for positioners ..... 367

G.2 Abbreviations positioner without basic electronics 6DR5910 ..... 368

G.3 Abbreviations for functional safety ..... 368

**Glossary ..... 371**

**Index ..... 379**

# Introduction

## 1.1 Purpose of this documentation

These instructions contain all information required to commission and use the device. Read the instructions carefully prior to installation and commissioning. In order to use the device correctly, first review its principle of operation.

The instructions are aimed at persons mechanically installing the device, connecting it electronically, configuring the parameters and commissioning it, as well as service and maintenance engineers.

## 1.2 Scope of documentation

Article no.	Product
6DR55..	SIPART PS2 with PROFIBUS PA
6DR59..	SIPART PS2 without basic electronics
6DR4004-6A / -8A	Alarm module / Digital I/O Module (DIO)
6DR4004-6F / -8F	EMC filter module / Analog Input Module (AIM)
6DR4004-6J / -8J	Position feedback module / Analog Output Module (AOM)
6DR4004-6G / -8G	Slot initiator alarm module / Inductive Limit Switches (ILS)
6DR4004-6K / -8K	Mechanical limit switch module / Mechanic Limit Switches (MLS)
6DR4004-5L / 5LE	Internal NCS module
6DR4004-.N	NCS sensor

## 1.3 Document history

The most important changes in the documentation when compared with the respective previous edition are given in the following table.

Edition	Note
05/2019	<ul style="list-style-type: none"> <li>• Changes for FW 6.01.00</li> <li>• Ex "nA" (non-sparking equipment) is replaced by Ex "ec" (increased safety)</li> <li>• Section "Connecting pneumatically" – Revised section "Reaction to failure of auxiliary powers"</li> <li>• Section "Assign parameters" - '36.YCLS', '37.YCDO' and '38.YCUP' extended by "Fast closing" function</li> <li>• Section "Commissioning" – Revised section "Setting friction clutch"</li> <li>• Section "Functions/Operation via PROFIBUS PA" - For acyclic data transmission with SIMATIC PDM, the Offline leakage test (Page 195) has been extended by the "Test area" parameter.</li> <li>• Section "Service and maintenance" <ul style="list-style-type: none"> <li>– Old section "Replacing the basic electronics" with the "Fail in Place" function has been revised and is now called "Replace basic electronics (Page 244)"</li> <li>– New section "Replace pneumatic block (Page 245)"</li> </ul> </li> <li>• Section "Technical specifications" – Explosion protection restructured and contains a breakdown of the article number (Page 285)</li> <li>• Section "Spare parts/accessories/scope of delivery (Page 303)" extended</li> <li>• New appendices <ul style="list-style-type: none"> <li>– External position detection (Page 313)</li> <li>– Pressure gauge block (Page 333)</li> <li>– Sealing plug / thread adapter (Page 335)</li> <li>– Booster (Page 339)</li> <li>– Positioner with remote control electronics (Page 355) 6DR59..</li> </ul> </li> </ul>
02/2016	<ul style="list-style-type: none"> <li>• Changes for FW 6.00.00</li> </ul>

### See also

Installing/mounting (Page 39)

Parameter assignment (Page 133)

Diagnostics (Page 256)


## 1.4 Product compatibility

The following table describes the compatibility between document output, device revision, engineering system and associated Electronic Device Description (EDD).

Manual edition	Comments	Device revision	Compatible version of device integration package	
05/2019	New device features	PROFIBUS PA FW: 6.01.00 or higher	SIMATIC PDM V9.1	EDD: 23.00.00 or higher
			SIMATIC PDM V8.2 SP1	EDD: 23.00.00 or higher
			SITRANS DTM V4.1	EDD: 23.00.00 or higher
02/2016	New device features	PROFIBUS PA FW: 6.00.00 or higher	SIMATIC PDM V9.0	EDD: 22.00.00 or higher
			SIMATIC PDM V8.2 SP1	EDD: 22.00.00 or higher
			SITRANS DTM V4.0	EDD: 22.00.01 or higher

## 1.5 Checking the consignment

1. Check the packaging and the delivered items for visible damages.
2. Report any claims for damages immediately to the shipping company.
3. Retain damaged parts for clarification.
4. Check the scope of delivery by comparing your order to the shipping documents for correctness and completeness.

 <b>WARNING</b>
<b>Using a damaged or incomplete device</b>
Risk of explosion in hazardous areas.
<ul style="list-style-type: none"> <li>• Do not use damaged or incomplete devices.</li> </ul>

## 1.6 Purpose

The electropneumatic positioner is used for the continuous control of process valves with pneumatic drives in the following industries.

- Chemicals
- Oil and gas
- Energy production
- Food and beverages
- Pulp and paper
- Water/waste water
- Pharmaceutical industry
- Offshore plants

Operate the device according to the specifications in section "Technical data (Page 281)".

For additional information, refer to the operating instructions for the device.

## 1.7 Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens’ products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place.

For additional information on industrial security measures that may be implemented, please visit

<https://www.siemens.com/industrialsecurity>.

Siemens’ products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer’s exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under

<https://www.siemens.com/industrialsecurity>.

## 1.8 Transportation and storage

To guarantee sufficient protection during transport and storage, observe the following:

- Keep the original packaging for subsequent transportation.
- Devices/replacement parts should be returned in their original packaging.
- If the original packaging is no longer available, ensure that all shipments are properly packaged to provide sufficient protection during transport. Siemens cannot assume liability for any costs associated with transportation damages.

<b>NOTICE</b>
<b>Insufficient protection during storage</b>
The packaging only provides limited protection against moisture and infiltration.
<ul style="list-style-type: none"><li>• Provide additional packaging as necessary.</li></ul>



Special conditions for storage and transportation of the device are listed in Technical data (Page 281).



## **1.9 Notes on warranty**

The contents of this manual shall not become part of or modify any prior or existing agreement, commitment or legal relationship. The sales contract contains all obligations on the part of Siemens as well as the complete and solely applicable warranty conditions. Any statements regarding device versions described in the manual do not create new warranties or modify the existing warranty.

The content reflects the technical status at the time of publishing. Siemens reserves the right to make technical changes in the course of further development.




## Safety information

### 2.1 Precondition for use

This device left the factory in good working condition. In order to maintain this status and to ensure safe operation of the device, observe these instructions and all the specifications relevant to safety.

Observe the information and symbols on the device. Do not remove any information or symbols from the device. Always keep the information and symbols in a completely legible state.

### 2.2 Warning symbols on the device

Symbol	Explanation
	Consult operating instructions

### 2.3 Laws and directives

Observe the safety rules, provisions and laws applicable in your country during connection, assembly and operation. These include, for example:

- National Electrical Code (NEC - NFPA 70) (USA)
- Canadian Electrical Code (CEC) (Canada)

Further provisions for hazardous area applications are for example:

- IEC 60079-14 (international)
- EN 60079-14 (EU)

## 2.4 Conformity with European directives

The CE marking on the device shows conformity with the regulations of the following European guidelines:


Electromagnetic compatibility EMC 2014/30/EU	Directive of the European Parliament and of the Council on the harmonization of the laws of the Member States relating to electromagnetic compatibility.
Atmosphère explosive ATEX 2014/34/EU	Directive of the European Parliament and of the Council on the harmonization of the laws of the Member States relating to equipment and protective systems intended for use in potentially explosive atmospheres.
2011/65/EU RoHS	Directive of the European Parliament and of the Council on the restriction of the use of certain hazardous substances in electrical and electronic equipment

The directives applied can be found in the EU declaration of conformity for the associated device.

### See also

Certificates (<http://www.siemens.com/processinstrumentation/certificates>)

## 2.5 Improper device modifications

 <b>WARNING</b>
<b>Improper device modifications</b> Risk to personnel, system and environment can result from modifications to the device, particularly in hazardous areas. <ul style="list-style-type: none"><li>• Only carry out modifications that are described in the instructions for the device. Failure to observe this requirement cancels the manufacturer's warranty and the product approvals.</li></ul>

## 2.6 Requirements for special applications

Due to the large number of possible applications, each detail of the described device versions for each possible scenario during commissioning, operation, maintenance or operation in systems cannot be considered in the instructions. If you need additional information not covered by these instructions, contact your local Siemens office or company representative.

---

### Note

#### Operation under special ambient conditions

We highly recommend that you contact your Siemens representative or our application department before you operate the device under special ambient conditions as can be encountered in nuclear power plants or when the device is used for research and development purposes.

---

## 2.7 Use in hazardous areas

### Qualified personnel for hazardous area applications

Persons who install, connect, commission, operate, and service the device in a hazardous area must have the following specific qualifications:

- They are authorized, trained or instructed in operating and maintaining devices and systems according to the safety regulations for electrical circuits, high pressures, aggressive, and hazardous media.
- They are authorized, trained, or instructed in carrying out work on electrical circuits for hazardous systems.
- They are trained or instructed in maintenance and use of appropriate safety equipment according to the pertinent safety regulations.

 <b>WARNING</b>
----------------------------------------------------------------------------------------------------

<b>Use in hazardous area</b>
------------------------------

Risk of explosion.
--------------------

- |                                                                                                                                                                                                                                                                                                                                                                                                |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"><li>• Only use equipment that is approved for use in the intended hazardous area and labeled accordingly.</li><li>• Do not use devices that have been operated outside the conditions specified for hazardous areas. If you have used the device outside the conditions for hazardous areas, make all Ex markings unrecognizable on the nameplate.</li></ul> |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

 **WARNING**

**Loss of safety of device with type of protection "Intrinsic safety Ex i"**

If the device or its components have already been operated in non-intrinsically safe circuits or the electrical specifications have not been observed, the safety of the device is no longer ensured for use in hazardous areas. There is a risk of explosion.

- Connect the device with type of protection "Intrinsic safety" solely to an intrinsically safe circuit.
- Observe the specifications for the electrical data on the certificate and/or in Technical data (Page 281).

## Description

### 3.1 Function

- The electropneumatic positioner and an actuator form a control system. The current position of the actuator is recorded by a servo potentiometer and the actual value  $x$  is fed back. The setpoint and the actual value are also shown simultaneously on the display.
- The control system provides the setpoint  $w$  digitally to the positioner over the bus.
- The positioner works as a predictive five-point positioner, through whose output value  $\pm\Delta y$  the integrated valves can be controlled by pulse length modulation.
- These input signals change pressure in the actuator chamber(s) and displace the actuator until the control deviation becomes zero.
- Using the three buttons and the display with the enclosure cover removed, operation (manual mode) and configuration (structuring, initialization, and parameter assignment) can be performed.
- By default, the basic unit has a binary input (BIN). This binary input can be individually configured and used, for example, to block the control levels.
- It has a friction clutch and a switchable gear so that the positioner can be used with different mechanical part-turn and linear actuators.
- In the case of positioners with the "Fail in Place" function, the current position of the actuator is held if the electric and/or pneumatic auxiliary power fails. Does not function in conjunction with SIL.
- Parameter "51.FSTY" must be set to "FSSP" in the case of the "Fail in Place" function if the current position is to be held when switching on again following failure of the electric auxiliary power.

### 3.2 Structure

#### 3.2.1 Design overview

The following sections describe the mechanical and electrical structure, components, and principle functionality of the positioner.

The positioner and the PROFIBUS PA communication interface function as components in a digital process automation system. It functions as a slave and communicates with the master through the PROFIBUS PA fieldbus. Apart from communication, the fieldbus also supplies electrical auxiliary power to the positioner.

The positioner is used to move and control pneumatic actuators. The positioner works electropneumatically, using compressed air as auxiliary power. The positioner is used to control valves, for example, with:

- Linear actuator
- Part-turn actuator VDI/VDE 3845

Various add-on extensions are available for linear actuators:


- IEC 60534-6-1 (NAMUR)
- Integrated mounting ARCA, except with flameproof versions
- Integrated addition to SAMSON in non-flameproof aluminum enclosure



- ① Pressure gauge block, single-acting
- ② Valve
- ③ Yoke / actuator yoke
- ④ Single-acting positioner in non-flameproof aluminum enclosure
- ⑤ Actuator


Figure 3-1 Positioner attached to a single-acting linear actuator





- ① Part-turn actuator
- ② Pressure gauge block, double-acting
- ③ Double-acting positioner in polycarbonate enclosure


Figure 3-2 Positioner attached to double-acting part-turn actuator



- ① Single-acting positioner in flameproof aluminum enclosure
- ② Pressure gauge block, single-acting
- ③ Yoke / actuator yoke
- ④ Actuator

Figure 3-3 Positioner in flameproof aluminum enclosure attached to linear actuator

3.2 Structure




- ① Part-turn actuator
- ② Double-acting positioner in flameproof aluminum enclosure
- ③ Pressure gauge block, double-acting

Figure 3-4 Positioner in flameproof aluminum enclosure attached to part-turn actuator


3.2.2 Nameplate layout

Example of manufacturer nameplate




- ① Manufacturer
- ② Degree of protection
- ③ Observe the operating instructions
- ④ Conformity with country-specific directives
- ⑤ Built-in option modules
- ⑥ QR code to the mobile website with device-specific product information
- ⑦ Serial number
- ⑧ Auxiliary power (supply air PZ)
- ⑨ Software version and hardware version
- ⑩ Country of origin
- ⑪ Supply voltage
- ⑫ Ordering supplement (Order code)
- ⑬ Article number
- ⑭ Product name

## Example of explosion protection nameplate




- ① Approvals  
② ATEX/IECEx marking for hazardous area



- ③ FM/CSA marking for hazardous area  
④ Permissible ambient temperature for operation in hazardous areas

## 3.2.3 Explanation of Ex information

### Explanation of Ex information




- ① Category for operating range  
② Type of protection  
③ Group (gas, dust)  
④ Maximum surface temperature (temperature class)  
⑤ Device protection level

Figure 3-5 Explanation of Ex information

### 3.3 Device components

#### 3.3.1 Overview of device components




→ Arrowhead means: Turn the device to see the corresponding view

- |                                             |                                                         |
|---------------------------------------------|---------------------------------------------------------|
| ① Bus cable                                 | ⑩ Restrictor Y1 for single-acting actuators             |
| ② Wiring diagram on module cover            | ⑪ Restrictor Y1 for double-acting actuators             |
| ③ Display                                   | ⑫ Exhaust air outlet with a sound absorber              |
| ④ Purging air selector                      | ⑬ Transmission ratio selector                           |
| ⑤ Output: Actuating pressure Y1             | ⑭ Friction clutch adjustment wheel                      |
| ⑥ Input: Supply air                         | ⑮ Basic electronics                                     |
| ⑦ Output: Actuating pressure Y2             | ⑯ Connecting terminals of option modules                |
| ⑧ Buttons                                   | ⑰ Shield connection (only with polycarbonate enclosure) |
| ⑨ Restrictor Y2 for double-acting actuators | ⑱ Cable gland                                           |

Figure 3-6 View of the positioner (cover open; polycarbonate enclosure)

### 3.3.2 Overview of device components (Ex)



- |   |                                           |   |                                             |
|---|-------------------------------------------|---|---------------------------------------------|
| ① | Display                                   | ⑧ | Output: Actuating pressure Y2 <sup>1)</sup> |
| ② | Restrictor Y1                             | ⑨ | Restrictor Y2 <sup>1)</sup>                 |
| ③ | Output: Actuating pressure Y1             | ⑩ | Buttons                                     |
| ④ | Input: Supply air PZ                      | ⑪ | Ground terminal                             |
| ⑤ | Safety catch                              | ⑫ | Connecting terminals of option modules      |
| ⑥ | Transmission ratio selector <sup>2)</sup> | ⑬ | Connecting terminals of basic electronics   |
| ⑦ | Friction clutch adjustment wheel          |   |                                             |

<sup>1)</sup> for double-acting actuators

<sup>2)</sup> visible when the positioner is open

Figure 3-7 View of positioner in flameproof enclosure, cover opened

### 3.3.3 Basic electronics




Figure 3-8 Basic electronics, schematic representation

The basic electronics contains:

- CPU
- Memory
- Analog-to-digital converter
- Display
- Buttons
- Terminal strips to connect the option module to the basic electronics

## 3.4 Functional principle

### Control loop

The electropneumatic positioner forms a control loop with the pneumatic actuator:

- The actual value  $x$  represents the position of the actuator spindle for linear actuators or the position of the actuator shaft for part-turn actuators.
- The higher-level control loop provides the setpoint  $w$ .

The stroke or rotary movement of the actuator is transferred to a potentiometer using suitable attachments, positioner shaft and a backlash-free, switchable gear drive, and then to the analog input of the microcontroller.

The current position can also be forwarded to the positioner using an external sensor. A **Non Contacting Position Sensor (NCS)** is used to record the stroke or rotary angle directly on the actuator.

The microcontroller:

- Corrects the angle error of the shaft pick-up if necessary.
- Compares the potentiometer voltage as actual value  $x$  with setpoint  $w$ .
- Calculates the manipulated variable increments  $\pm\Delta y$ .

The piezo-controlled inlet or exhaust air valve is opened depending on the magnitude and direction of the control deviation ( $x-w$ ). The actuator volume integrates the controller increment for the actuating pressure  $y$  which is proportional to the drive rod or the drive shaft. This controller increment changes the actuating pressure until the control deviation becomes zero.

Pneumatic actuators are available in single and double-acting versions. In a single-acting version, only one pressure chamber is ventilated and depressurized. The pressure developed works against a spring. In a double-acting version, two pressure chambers work against each other. Ventilating the volume of one chamber simultaneously depressurizes the volume of the other.

## Control algorithm

The control algorithm is an adaptive, predictive five-point controller.

In case of large control deviations, the valves are controlled using permanent contact. This takes place in the so-called fast step zone.

In case of medium control deviations, valves are controlled using pulse-length modulated pulses. This takes place in the so-called slow step zone.




Figure 3-9 Functional principle of five-point controller

Small control deviations do not send control pulses in the zone. This takes place in the so-called adaptive deadband. The deadband adaptation and the continuous adaptation of minimum pulse lengths in "Automatic" mode ensure the best possible control accuracy with the smallest number of operating cycles. The start parameters are determined during the initialization phase and stored in the non-volatile memory. The most important start parameters are:

- The real actuator travel with end positions
- Travel times
- The deadband size

The number of fault messages, changes in direction, and the number of total strokes are continuously determined during operation and saved every 15 minutes. You can read and document these parameters using communication programs such as SIMATIC PDM and AMS. By comparing the old values with the current ones, you can draw conclusions about the wear and tear of the valve. You can use the diagnostics function for this.

### 3.4.1 PROFIBUS system configuration

#### Overview

The positioner can be used in a number of system configurations.

Use with the SIMATIC PCS 7 Automation System is described below.

#### System communication

The Operator Station of the SIMATIC PCS 7 process control system allows easy and safe control of the process by the operating personnel using OS Multi-Clients.

The Maintenance Station assists the maintenance engineer in guaranteeing high plant availability, securing this long-term using optimization measures, and implementing the maintenance measures using a minimum of personnel, materials, energy, costs etc.

The field devices are integrated over PROFIBUS PA with:

- PA Link to the gateway between PROFIBUS PA and PROFIBUS DP
- Control system, e.g. SIMATIC PCS 7 Automation System, which communicates over PROFIBUS
- Engineering Station, SIMATIC PDM (Process Device Manager) which communicates over Industrial Ethernet




Figure 3-10 Typical system configuration



### 3.4.2 SIMATIC PDM

SIMATIC PDM is a software package for configuring, parameter assignment, commissioning, diagnostics and maintenance of this device and other process devices.

SIMATIC PDM offers simple monitoring of process values, alarms, and device status information.

SIMATIC PDM allows the process device data to be:

- displayed
- set
- modified
- saved
- diagnosed
- checked for plausibility
- managed
- simulated

Additional information on SIMATIC PDM can be found at [www.siemens.com/simatic-pdm](http://www.siemens.com/simatic-pdm) ([www.siemens.com/simatic-pdm](http://www.siemens.com/simatic-pdm)).

## 3.5 PROFIBUS PA

### 3.5.1 Overview

The Process Fieldbus (PROFIBUS) is an open communications system for automation technology and is specified in the international standard IEC 61158.

PROFIBUS Process Automation (PROFIBUS PA) is a variant of PROFIBUS Decentral Peripherals (PROFIBUS DP), which is widely used in process technology.

### 3.5.2 Transmission technology

The PROFIBUS PA has the special transmission technique MBP (Manchester coded Bus Powered) and therefore satisfies the requirements of process automation and process engineering requirements.

This transmission technology is defined in the international standard IEC 61158-2.

The PROFIBUS PA is based on the FISCO model (Fieldbus Intrinsically safe Concept) and can therefore be used in hazardous areas.

### 3.5.3 Bus topology

The bus topology is mainly able to be selected as desired. Therefore, line, star and tree structures, and mixed forms are possible. All types of field devices such as transmitters, actors, analysis devices, etc. can be connected to the PROFIBUS PA.

Advantages include:

- Savings on installation costs
- More extensive diagnostics, leading to increased availability of installation sections
- Automatic management of installation documentation
- Installation optimization on the fly during operation

In an automation system, there are generally multiple PROFIBUS PA lines connected to fast PROFIBUS DP via coupler units. This is also connected to the process control system.

Both bus systems use the same protocol layer. This makes PROFIBUS PA a "communications-compatible" extension of the PROFIBUS DP into the field.




Figure 3-11 Functional principle of the PROFIBUS automation system

The figure shows a section of a typical PROFIBUS automation system. The control system consists of two masters with distributed tasks.

The class-1 master recognizes the control and regulation tasks. The class-2 master enables the operating and monitoring functions. Between the class-1 master and the field devices there is a periodic exchange of measurement and settings data. The status information from the field devices is transmitted parallel to this data, and evaluated in the class-1 master. Assignment of parameters for the field devices or the reading of additional device information is not performed during periodic operation.

Besides periodic operation, one or more class-2 masters can access the field devices asynchronously. Using this type of communication, additional information can be retrieved from the devices or settings sent to them.

### 3.5.4 Properties

PROFIBUS PA allows bidirectional communication between a bus master and field devices. At the same time, the shielded two-strand wiring provides auxiliary power to the two-wire field devices.

### 3.5.5 Profile

As an extension to the EN 50170 standard, the PROFIBUS user organization (PNO) defined the functionality of the individual field device types in a so-called profile description. This profile determines minimum functional requirements and optional extensions. The device-internal "Device Management" provides the configuration tool of the control system with all necessary basic information to find profile parameters. One parameter assignment tool serves all profile-conforming devices, regardless of type or manufacturer.

Depending on the size of the installation (and therefore the number of field devices) and the time behavior required, you implement the system with one or more PROFIBUS PA strands. One PROFIBUS PA strand consists of the components shown in the following figure.




Figure 3-12 PROFIBUS PA strand

FD Field device

T Terminating resistor

PC Personal Computer

PCS Process control system

### Reference

PNO PROFIBUS-PA interest group

### 3.5.6 Connection

Control is performed by the central process control system (PCS) or by a PC for lower-performance requirements.

In general, the following functions are combined into one coupling assembly:

- DP/PA signal transfer
- Bus power
- Bus termination

Depending on the number of the PROFIBUS PA field devices to be operated in the automation system and the time behavior required, a DP/PA coupler or a DP/PA link is used. For standard requirements, you use a DP/PA coupler; for higher requirements, a more powerful DP/PA link.

For reasons related to transmission technology, the bus is also equipped on the far end with a terminating resistance T. When using the recommended bus cable, the theoretical maximum cable length is 1900 meters. The theoretical maximum cable length is the sum of all cable segments. During planning, also take into account the voltage drop over the wires powering the field devices.

However, the power requirements of the individual nodes and the voltage drop on the cable must also be calculated during projection. The individual field devices (FD) can be connected at nearly any point in the bus system.

DP/PA couplers or DP/PA links are supplied using a safety extra-low voltage (SELV) power supply. This power supply must have sufficient reserves to bridge over temporary power failures.

The maximum number of devices which can be connected to one bus strand depends on their power consumption and the conditions of use. When operated in the safe zone, the couplers or links supply the bus with up to 400 mA.

When operated in explosive atmospheres, intrinsic safety is only guaranteed if all devices, components, etc. connected to the bus (e.g. bus terminator) fulfill the following requirements:

- They are certified as intrinsically safe equipment.
- They fulfill the requirements of the FISCO model (Fieldbus Intrinsic Safety Concept).

Power supply devices in particular (bus couplers) must be certified as so-called FISCO power supplies. Observe the safety-relevant maximum values and other specifications of the EG type test certificate.

Connect power supplies (bus couplers) which are not explosion protected and certified to intermediate EX-certified zener barriers. Observe the specifications of the EG type test certificate.



**WARNING**

For power supply to intrinsically safe PROFIBUS, use only power supplies, DP/PA couplers, or DP/PA links certified as compliant with the FISCO model.

Switch through zener barriers if using non-EX-protected power supplies. See the requirements of the EG type test certificate.

### 3.5.7 Number of connectable devices

The number of devices which can be connected to a bus strand can be calculated from the sum of the maximum power consumption of the devices and the power available. By default, assume 10 mA per device. For safety reasons, plan for a power reserve. Otherwise you run the risk of a defective device overloading the bus with an increased power consumption. This can interrupt the power supply and communication with the functioning nodes. The amount of power reserved is based on the nominal power increase given by the manufacturer in case of failure.

### 3.5.8 Assigning the device addresses

So that the connected process devices can be distinguished from one another, each device has its own address.

Be sure that the device addresses are set before operating two or more field devices on the bus. Each address may only be given once to make sure they are unique.

Principally, the address range is from 1 to 125. The address 126 is set for the delivery state. Normally, masters in PROFIBUS systems receive lower addresses. Therefore, we recommend starting at 30 when assigning addresses to the positioners. Either use the keys on the positioner or the SIMATIC PDM software via the bus to set the addresses. In the last case, a new positioner is always connected to the bus and the new address is set via the software. The next positioner is then connected to the bus and processed the same way.

We recommend writing the set address on the field device with a wipe resistant pen.

#### See also

Process instrumentation catalog (<http://www.siemens.com/processinstrumentation/catalogs>)

*Description*

---

3.5 PROFIBUS PA

## Installing/mounting

### 4.1 Basic safety instructions

 **WARNING**

**High operating force with pneumatic actuators**

Risk of injury when working on control valves due to the high operating force of the pneumatic actuator.

- Please observe the corresponding safety instructions for the pneumatic actuator in use.

 **WARNING**

**It is possible to damage the cover gasket**

If the cover gasket is not positioned correctly in the groove of the base plate, it could be damaged when the cover is mounted and screwed tight.

- Therefore make sure that the gasket is seated correctly.

#### 4.1.1 Exceeded maximum permissible operating pressure

 **WARNING**

**Exceeded maximum permissible operating pressure**

Risk of injury or poisoning.

The maximum permissible operating pressure depends on the device version, pressure limit and temperature rating. The device can be damaged if the operating pressure is exceeded. Hot, toxic and corrosive process media could be released.


Ensure that maximum permissible operating pressure of the device is not exceeded. Refer to the information on the nameplate and/or in Technical data (Page 281).

 **WARNING**

**Electrostatic charging of nameplates**

The nameplates used on the device can reach a charging capacity of 5 pF.

- Keep the device and the cables at a distance from strong electromagnetic fields.

 **CAUTION**

**Unsuitable compressed air**

Device damage. As a general rule, the positioner must only be operated with dry and clean compressed air.


- Use the customary water separators and filters. An additional dryer is required in extreme cases.
- Use dryers, especially if you operate the positioner at low ambient temperatures.

 **CAUTION**

**Note the following before working on the control valve and when attaching the positioner**

Danger of injury.

- Prior to working on the control valve, you must move the control valve into a completely pressureless state. Proceed as follows:
  - Depressurize the actuator chambers.
  - Switch off the supply air PZ.
  - Lock the valve in its position.
- Make sure that the valve has reached the pressureless state.
- If you interrupt the pneumatic auxiliary power to the positioner, the pressureless position can only be reached after a certain waiting time.
- When mounting, observe the following sequence imperatively to avoid injuries or mechanical damage to the positioner/mounting kit:
  - Mount the positioner mechanically.
  - Connect the electrical auxiliary power supply.
  - Connect the pneumatic auxiliary power supply.
  - Commission the positioner.

 **WARNING**

**Mechanical impact energy**

In order to ensure the degree of protection of the housing (IP66), protect the housing versions of the positioners listed here from mechanical impact energy:

- 6DR5..3; not greater than 2 Joule
- 6DR5..0; not greater than 1 Joule
- 6DR5..1 with inspection window; not greater than 1 Joule




<b>NOTICE</b>
<b>Torque with NPT screwed gland</b>
Device damage. The maximum torque of the cable gland must not be exceeded.
<ul style="list-style-type: none"><li>To avoid damage to the device, the NPT adapter must be held in place while the NPT gland is screwed into the NPT adapter. Refer to the section "Technical specifications &gt; Construction (Page 283)" for the torque value.</li></ul>

## 4.1.2 Proper mounting

### 4.1.2.1 Freezing of the exhaust air outlets

<b>NOTICE</b>
<b>Freezing of the exhaust air outlets</b>
When devices of the type 6DR5..0/1/2/3 are used, the exhaust air outlets ② may freeze. The function of the device is impaired.
<ul style="list-style-type: none"><li>Do <b>not</b> install the positioner with the base plate ① pointing up.</li></ul>



- ① Base plate
- ② Exhaust air outlets

Figure 4-1 Exhaust air outlets, base plate

<b>⚠ WARNING</b>
<b>Loss of type of protection</b>
Risk of explosion. Damage to device if the enclosure is open or not properly closed. The type of protection specified on the nameplate or in Technical data (Page 281) is no longer guaranteed.
<ul style="list-style-type: none"><li>Make sure that the device is securely closed.</li></ul>

**NOTICE****Incorrect mounting**

The device can be damaged, destroyed, or its functionality impaired through improper mounting.

- Before installing ensure there is no visible damage to the device.
- Make sure that process connectors are clean, and suitable gaskets and glands are used.
- Mount the device using suitable tools. Refer to the information in Technical data (Page 281).

## 4.2 Mounting to linear actuator

### Requirements

There are linear actuators for standard mounting in accordance with IEC 60534 and for integrated mounting. Use the reduced mounting kit 6DR4004-8VK for actuators with integrated mounting. Integrated mounting is not possible with flameproof stainless steel enclosure (6DR5..6).

This section describes how to connect the positioner to the linear actuator according to IEC 60534. Depending on the stroke height, you will need the following mounting kit:

- 3 to 35 mm mounting kit 6DR4004-8V
- 35 to 130 mm mounting kit 6DR4004-8V and additional 6DR4004-8L

### See also

Construction (Page 283)

### Procedure

"Linear actuator IEC 60534 (3 to 35 mm)" mounting kit 6DR4004-8V and 6DR4004-8L			
Sr. no. *)	Quantity	Name	Note
①	1	NAMUR mounting bracket IEC 60534	Standardized connection point for mount with fin, column or plane surface
②	1	Pick-up bracket	Guides the pulley with the carrier pin and rotates the lever arm.
③	2	Clamping piece	Installs the pick-up bracket on the actuator spindle
④	1	Carrier pin	Installation with pulley ⑤ on lever ⑥
⑤	1	Pulley	Installation with carrier pin ④ on lever ⑥
⑥	1	Lever	For the range of stroke from 3 mm to 35 mm The lever 6DR4004-8L is additionally required for ranges of stroke > 35 mm to 130 mm (not included in the scope of delivery).
⑦	2	U-bolts	Only for actuators with columns
⑧	4	Hexagon bolt	M8x20 DIN 933-A2

"Linear actuator IEC 60534 (3 to 35 mm)" mounting kit 6DR4004-8V and 6DR4004-8L			
Sr. no. *)	Quantity	Name	Note
⑨	2	Hexagon bolt	M8x16 DIN 933-A2
⑩	6	Spring lock washer	A8 - DIN 127-A2
⑪	6	Washer	B8.4 - DIN 125-A2
⑫	2	Washer	B6.4 - DIN 125-A2
⑬	1	Spring	VD-115E 0.70 x 11.3 x 32.7 x 3.5
⑭	1	Spring lock washer	A6 - DIN 137A-A2
⑮	1	Lock washer	3.2 - DIN 6799-A2
⑯	3	Spring lock washer	A6 - DIN 127-A2
⑰	3	Socket cap screw	M6x25 DIN 7984-A2
⑱	1	Hexagon nut	M6 - DIN 934-A4
⑲	1	Square nut	M6 - DIN 557-A4
⑳	4	Hexagon nut	M8 - DIN 934-A4

\*) The serial numbers refer to the images of the description of the installation steps below.

1. Install the clamping pieces ③ on the actuator spindle.
2. Slide the pick-up bracket ② into the milled recesses of the clamping pieces ③.




Figure 4-2 Pick-up bracket

3. Tighten the screws ⑰ so that you can still shift the pick-up bracket ②.

4.2 Mounting to linear actuator

4. If you use a short lever, the carrier pin is already pre-mounted. If you use the long lever 6DR4004-8L, fasten the carrier pin ④ with the existing parts to the long lever.




Figure 4-3 Short lever




Figure 4-4 Long lever 6DR4004-8L with mounted carrier pin ④ and cylinder head screw ⑰

5. Set the stroke value. The stroke value is specified on the nameplate of the actuator. Position the pin center of the carrier pin ④ on the corresponding value of the scale. If none of the values on the lever scale matches the stroke value of the actuator, select the next higher value on the scale.  
For strokes  $\geq 25$  mm, select the scale (90). For strokes  $< 25$  mm, select the scale (33).
6. Set the transmission ratio selector to the value of the selected scale.
7. If you need the value of actuator travel after initialization in mm: ensure that the configured stroke value matches the value of the "3.YWAY" parameter.
8. Push the pre-installed lever ⑥ up to the endstop on the positioner shaft. Fasten the lever ⑥ with socket cap screw ⑰.

9. Install the mounting bracket ① at the rear side of the positioner. Use 2 hexagon bolts ⑨, 2 spring lock washers ⑩ and 2 flat washers ⑪ for this purpose.




Figure 4-5 Installation with mounting bracket







Figure 4-6 Installation with mounting bracket, flameproof enclosure

10. Select the row of holes. The selection of the row of holes depends on the yoke width of the actuator. Select the row of holes in such a way that the carrier pin ④ meshes with the pick-up bracket ② near the spindle.
11. Keep the positioner and the fastening bracket on the actuator. Ensure that the carrier pin ④ for the entire range of stroke of the actuator is guided inside the pick-up bracket ②. Ensure that the carrier pin ④ does not touch the clamping pieces ③.

4.2 Mounting to linear actuator

12. Tighten the pick-up bracket (2).

13. Fasten the positioner on the yoke. Use the installation parts suitable for the corresponding actuator.

Actuator type	Required installation components	
Yoke with fin	<ul style="list-style-type: none"> <li>• Hexagon bolt (8)</li> <li>• Washer (11)</li> <li>• Spring lock washer (10)</li> </ul>	
Yoke with plane surface	<ul style="list-style-type: none"> <li>• Four hexagon bolts (8)</li> <li>• Washer (11)</li> <li>• Spring lock washer (10)</li> </ul>	
Yoke with columns	<ul style="list-style-type: none"> <li>• Two U-bolts (7)</li> <li>• Four hexagon nuts (20)</li> <li>• Washer (11)</li> <li>• Spring lock washer (10)</li> </ul>	

**Note****Height adjustment of the positioner**

When you fasten the positioner on the yoke, the following applies to its height adjustment:

1. Set the height of the positioner in such a way that the horizontal lever position is near the center of the stroke.
2. Orient yourself by the lever scale of the actuator.
3. If symmetrical mounting is not possible, you must always ensure that the horizontal lever position is maintained within the range of stroke.

## 4.3 Mounting to part-turn actuator

### Requirements

You require an actuator-specific VDI/VDE 3845 mount to install the positioner on a part-turn actuator. Because of the high weight of the version in the flameproof stainless steel enclosure 6DR5..6, you should select a particularly stable mount.

### Procedure

"Part-turn actuator" mounting kit 6DR4004–8D			
Sr. no. *)	Quantity	Name	Note
①	1	Coupling wheel	Installation on positioner shaft
②	1	Carrier	Installing on the actuator shaft
③	1	Multiple plate	Display of the position, consisting of scale ⑤ and pointer mark ⑥
④	8	Scale	Different divisions
⑤	2	Pointer mark	Reference point for scale
⑥		Mount	Actuator-specific, VDI/VDE 3845
⑦	4	Hexagon bolt	M6x12 DIN 933, torque see the section "Technical specifications > Construction (Page 283)"
⑧	4	Lock washer	S6
⑨	1	Socket cap screw	M6x16 DIN 84
⑩	1	Washer	6.4 DIN 125
⑪	1	Hex socket-head screw	For coupling wheel
	1	Machinist's wrench	For hexagon socket-head screw ⑪

\*) The serial numbers refer to the images of the description of the installation steps below.

4.3 Mounting to part-turn actuator

1. Rest the actuator-specific VDI/VDE 3845 mount (6) on the rear side of the positioner. Tighten the mount using the hexagon bolts (7) and lock washers (8).
2. Push the coupling wheel (1) or the stainless steel coupling up to the endstop on the positioner shaft. Then retract the coupling wheel or the stainless steel coupling by approximately 1 mm. Tighten the hexagon socket-head screw (11) using the machinist's wrench provided. Maximum tightening torque = 1 Nm. If you are using the stainless steel coupling, omit the next step.

**Note**

**Coupling wheel**

Instead of the polycarbonate coupling wheel (1), it is possible to use a stainless steel coupling (article number TGX: 16300-1556).




Figure 4-7 Left: Coupling wheel, right: Coupling wheel, flameproof enclosure

3. Place the carrier (2) on the actuator shaft. Tighten the carrier (2) using the socket cap screw (9) and the washer (10).




Figure 4-8 Carrier



- Place the positioner and the mount on the actuator carefully. One of the two pins (12) of the coupling wheel (1) must fit in the carrier (2) when you do this.




Figure 4-9 Left: Orientation of mount; right: Orientation of mount, flameproof enclosure

- When using the stainless steel coupling (article number TGX: 16300-1556): Place the positioner and the mount on the actuator carefully. Place the stainless steel coupling on the stump of the actuator's positioner shaft.
- Align the positioner with mount at the center of the actuator.
- Fasten the positioner with mount.
- Initialize the positioner.
- After commissioning, drive the positioner to the end position.
- Stick the scale (4) with the direction of rotation or the swivel range on the coupling wheel (1). The stickers with scale are self-adhesive.





Figure 4-10 Left: Adhesive label with scale; right: Adhesive label with scale, flameproof enclosure

4.4 Setting and locking the transmission ratio



- H = height of shaft butt
- ① Fixing level of positioner on mount
  - ② Part-turn actuator

Figure 4-11 Dimensions of mount in accordance with VDI/VDE 3845 (depends on actuator)

See also

Preparing part-turn actuators for commissioning (Page 125)

## 4.4 Setting and locking the transmission ratio

### Introduction

The positioner has a friction clutch and a transmission ratio selector. The positioner can therefore be used on a variety of mechanically different part-turn and linear actuators.

- The transmission ratio selector allows you to adapt the positioner to small or large strokes.
- You can then use the friction clutch to adjust the working area.

Strong acceleration forces act on control valves that are subjected to heavy mechanical loads, e.g. breakaway valves, strongly shaking or vibrating valves, as well as in case of "vapor shocks". These forces may be much higher than the specified data. This may move the transmission ratio in extreme cases. In these cases it is possible to lock the transmission ratio selector by means of the gear fixing.

When the positioner is mounted and fully operational, set the friction clutch as described in the section Setting the friction clutch (Page 116).

**NOTICE****Wrong registration of the rotary or part-turn movement**

A different setting of the transmission ratio selector and the gear latch results in a hysteresis in position detection. The hysteresis in position detection can result in unstable control response of the higher level control loop.

- Make sure the transmission ratio selector ⑤ and the gear latch ① are set to the same value, either to 33° or to 90°.

**Note****Use of external NCS sensor / internal NCS module**


If you use the accessory part "NCS sensor for non-contacting position detection" or a built-in internal NCS module, the locking and fixing measures described in this section are **not** necessary.

**Requirement**

- The positioner is mounted.
- You know whether the transmission ratio is to be set to 33° or 90°.

## Procedure

On the right in the graphic the positioner is shown in the flameproof enclosure Ex d with open cover. The procedure is the same for both enclosure versions.



① Wheel for gear latch (yellow)

② Locking transmission ratio to 33°

③ Neutral position

④ Locking transmission ratio to 90°

⑤ Transmission ratio selector (yellow)

Figure 4-12 Locking the transmission ratio

1. Ensure that the wheel for the gear latch ① is in neutral position ③. The neutral position is between 33° and 90°. The setting of the transmission ratio selector ⑤ can only be changed effectively if the gear latch ① is in the neutral position ③.
2. Make sure the transmission ratio selector ⑤ is set to the same value as the gear latch ①, either to 33° or to 90°.
3. Turn the wheel for the gear latch ① until the gear latch ① perceptibly locks. Use an approx. 4 mm wide standard screwdriver.  
Turning right locks the transmission ratio to 33° ②. Turning left locks the transmission ratio to 90° ④.


The transmission ratio ② is set and locked.

**See also**

Overview of device components (Ex) (Page 29)

## 4.5 Installing the optional modules

### 4.5.1 General information about the installation of option modules

 <b>WARNING</b>
<b>Use in hazardous area</b> Risk of explosion. <ul style="list-style-type: none"><li>• Only use equipment that is approved for use in the intended hazardous area and labeled accordingly.</li><li>• Do not use devices that have been operated outside the conditions specified for hazardous areas. If you have used the device outside the conditions for hazardous areas, make all Ex markings unrecognizable on the nameplate.</li></ul>


#### 4.5.1.1 Opening the standard and intrinsically safe version

##### Introduction

The following option modules are available for the positioner in the standard and intrinsically safe version:

- Position feedback module 6DR4004-6J (Page 60)
- Alarm module 6DR4004-6A (Page 62)
- Slit initiator alarm module (SIA) 6DR4004-6G (Page 64)
- Mechanical limit switch module 6DR4004-6K (Page 66)
- Internal NCS module (iNCS) 6DR4004-5L (Page 70)
- EMC Filter Module 6DR4004-6F (Page 74)

Overview screen



- |   |                                                                                       |   |                                                  |
|---|---------------------------------------------------------------------------------------|---|--------------------------------------------------|
| ① | Module cover                                                                          | ⑪ | Adapter                                          |
| ② | Fixing screws module cover                                                            | ⑫ | Transmission ratio selector                      |
| ③ | Fixing screws basic electronics                                                       | ⑬ | Pneumatic block                                  |
| ④ | Ribbon cable/connector for fitted potentiometer or fitted EMC filter module           | ⑭ | Warning label on the side opposite the nameplate |
| ⑤ | Ribbon cable/connector for alarm module, SIA module or mechanical limit switch module | ⑮ | SIA module or mechanical limit switch module     |
| ⑥ | Ribbon cable/connector for position feedback module                                   | ⑯ | Insulating cover, yellow                         |
| ⑦ | Basic electronics                                                                     | ⑰ | Special screw                                    |

- |                            |                                    |
|----------------------------|------------------------------------|
| ⑧ Alarm module             | ⑱ Friction clutch adjustment wheel |
| ⑨ Position feedback module | ⑲ Wiring diagram on module cover   |
| ⑩ Nameplate                |                                    |

Figure 4-13 Installing the optional modules in the standard and intrinsically safe version

### Procedure for opening the device

1. Open the positioner.
2. Loosen the four fixing screws of the enclosure cover. Remove the enclosure cover.
3. Disconnect the power supply lines or de-energize the power supply lines.
4. Disconnect all other electrical connections of the device.
5. Loosen the two fixing screws ② of the module cover ①.
6. Remove the module cover ①.

If you install an option module, proceed as described for the respective option modules. For slot initiator alarm module (SIA), mechanical limit switch module, internal non-contacting sensor module and EMC filter module, remove the basic electronics.

If you replace the basic electronics, a pneumatic block or pressure sensor module, proceed as described in the respective chapters under "Service and maintenance (Page 241)".

#### 4.5.1.2 Closing the standard and and intrinsically safe version

The legend numbers refer to the figure in "Opening the standard and and intrinsically safe version (Page 53)"

1. Now start with the assembly. Place on the module cover ①. Make sure that the ribbon cable is not trapped.
2. Turn the fixing screws ② counterclockwise until they noticeably engage in the thread pitch.
3. Carefully tighten both fixing screws ② in a clockwise direction.  
The module cover protects and locks the optional modules mechanically.

---

#### Note

##### Untimely wear

The module cover is fastened using **self-tapping** screws, one screw for the base plate and one screw for the valve.

- In order to avoid premature wear of the base plate and valve, proceed as described here.
- 


4. Connect the power supply lines or supply the power supply lines with voltage.
5. Put on the enclosure cover.
6. Tighten the fixing screws of the enclosure cover.

### 4.5.1.3 Opening the device version with "flameproof enclosure"

#### Introduction


The following option modules are available for the positioner in the flameproof enclosure:

- Position feedback module 6DR4004-8J (Page 60)
- Alarm module 6DR4004-8A (Page 62)
- Internal NCS module 6DR4004-5LE (Page 70)

 <b>DANGER</b>
<b>Risk of explosion</b>
Before supplying the positioner with auxiliary power in potentially hazardous areas, ensure the following:
<ul style="list-style-type: none"><li>• The installed electronic unit has been approved.</li><li>• The enclosure of the positioner is closed.</li><li>• The duct openings for electronic connections must be closed. Only use the Ex d certified cable entries or sealing plugs.</li><li>• If you use a "conduit piping system", install an ignition trap. The maximum distance between the ignition trap and the positioner enclosure is 46 cm (18 inch).</li></ul>



Overview screen



- |   |                                                                                       |   |                                                  |
|---|---------------------------------------------------------------------------------------|---|--------------------------------------------------|
| ① | Module cover                                                                          | ⑬ | Pneumatic block                                  |
| ② | Fixing screws module cover                                                            | ⑭ | Warning label on the side opposite the nameplate |
| ③ | Fixing screws basic electronics                                                       | ⑮ | Screw cap                                        |
| ④ | Ribbon cable/connector for fitted potentiometer or external position detection system | ⑯ | Feedback lever bracket with pin                  |
| ⑤ | Ribbon cable/connector for alarm module, SIA module or mechanical limit switch module | ⑰ | Pin (feedback lever bracket)                     |
| ⑥ | Ribbon cable/connector for position feedback module                                   | ⑱ | Adjustment wheel for external friction clutch    |
| ⑦ | Basic electronics                                                                     | ⑲ | Feedback shaft                                   |
| ⑧ | Alarm module                                                                          | ⑳ | Fixing screws adapter                            |

4.5 Installing the optional modules

- |   |                             |   |              |
|---|-----------------------------|---|--------------|
| ⑨ | Position feedback module    | ⑳ | Safety catch |
| ⑩ | Nameplate                   | ㉑ | Clip         |
| ⑪ | Adapter                     | ㉒ | Enclosure    |
| ⑫ | Transmission ratio selector |   |              |

Figure 4-14 Installing the optional modules in the "flameproof enclosure" version

**Opening the device version with "flameproof enclosure"**

1. Disconnect the power supply lines or de-energize the power supply lines.
2. Open the safety catch ㉑.
3. Unscrew the screw cap ⑮.
4. Completely dismount the positioner from the actuator.
5. Turn the feedback shaft ⑲ on the positioner until the pin (feedback lever bracket) ⑰ below the adapter ⑪ shows in the direction of removal. If you look into the enclosure below the adapter, you will see the position of the pin.
6. Loosen the four fixing screws ㉒ of the adapter ⑪.
7. Completely remove the adapter ⑪ carefully from the enclosure ㉓.  
The positioner comes with a clip ㉑ and a pin (feedback lever bracket) ⑰ which interlock and ensure backlash-free position feedback. To ensure backlash-free position feedback make sure you remove the adapter ⑪ carefully.

<p><b>NOTICE</b></p> <p><b>Displaced O-rings</b></p> <p>There are several O-rings between adapter ⑪ and enclosure ㉓. These O-rings may come off during removal.</p> <ul style="list-style-type: none"> <li>• Carefully remove the adapter. Make sure the O-rings do not get lost during removal.</li> </ul>
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

8. Loosen the two fixing screws ② of the module cover ①.
9. Remove the module cover ①.

If you install an option module, proceed as described for the respective option module. Remove the basic electronics with an internal NCS module.

If you replace the basic electronics or a pneumatic block, proceed as described in the respective chapters under "Service and maintenance (Page 241)".

#### 4.5.1.4 Closing the device version with "flameproof enclosure"

1. Now start with the assembly. Place on the module cover ①. Make sure that the ribbon cable is not trapped.
2. Turn the fixing screws ② counterclockwise until they noticeably engage in the thread pitch. Carefully tighten both fixing screws ② in a clockwise direction.  
The module cover protects and locks the optional modules mechanically.

---

**Note****Untimely wear**

The module cover is fastened using a **self-tapping** screw for the valve.

- In order to avoid premature wear of the valve, proceed as described here.
- 

3. Check whether the position of the O-rings is correct before inserting the adapter into the enclosure.
  - With an enclosure made from aluminum, O rings are inside the enclosure and on the rear of the adapter.
  - With an enclosure made from stainless steel, O-rings are on the rear of the adapter.
4. Make sure no loose items in the enclosure interfere with the assembly.
5. Push the adapter ⑪ fully into the enclosure ⑳.  
The positioner comes with a clip ㉒ and a pin (feedback lever bracket) ⑰ which interlock and ensure backlash-free position feedback. To ensure backlash-free position feedback, insert the adapter ⑪ carefully into the enclosure.
6. Screw in the four mounting screws ㉑ of the adapter ⑪. Tighten the screws.  
Check carefully whether the feedback shaft ⑲ can be smoothly turned by 360°. If you feel resistance, do **not** continue to turn but turn the feedback shaft ⑲ back again to the point of removal.
7. Mount the positioner on the actuator.
8. Unscrew the screw cap ⑮.
9. Close the safety catch ㉓.
10. Connect the power supply lines or supply the power supply lines with voltage.

## 4.5.2 Position feedback modules 6DR4004-6J and -8J

### Function

- The optional position feedback module indicates the current position of the actuator as a two-wire signal between 4 mA and 20 mA. The position feedback module is electrically isolated from the basic device.
- The current position is indicated as a passive mA signal only after successful initialization.
- Operational faults are signaled by a fault current of 3.6 mA.

### Device features




Figure 4-15 Position feedback module 6DR4004-6J (Ex) and 6DR4004-8J (not Ex), schematic representation

The position feedback module is:

- Single channel
- Potentially separated from the basic device.

### Requirements

- You are familiar with the general procedure described in the section "General information about the installation of option modules (Page 53)".
- A supply source according to the technical data of the position feedback module (Page 294) must be available.

### Procedure for installing the position feedback module

1. Open the positioner as in the description depending on the device version:
  - Opening the standard and intrinsically safe version (Page 53)
  - Opening the device version with "flameproof enclosure" (Page 56)
2. Slide the position feedback module up to the endstop in the lower bay of the rack.

3. Connect the module to the basic electronics. For this purpose, use the 6-pin flat ribbon cable provided.
4. Close the positioner as in the description depending on the device version:
  - Closing the standard and intrinsically safe version (Page 55)
  - Closing the device version with "flameproof enclosure" (Page 59)

### 4.5.3 Alarm modules 6DR4004-6A and -8A

#### Function

The alarm module triggers fault messages and alarms via three binary outputs. The message function is based on the change in the signal status:

- If the signal status is "HIGH", there is no alarm message and the binary inputs are conductive.
- If the signal status is "LOW", the module reports an alarm by shutting down binary outputs using a high-resistance.
- Operational faults are signaled at a high-resistance output. Set the following parameters to activate and configure the output of alarms and fault messages:
  - "AFCT" - Alarm function
  - "A1" - Response threshold, alarm 1
  - "A2" - Response threshold, alarm 2
  - "FCT" - Function for fault message output
  - "TIM" - Monitoring time
  - "LIM" - Response threshold

Apart from binary outputs, the alarm module has a binary input BIN2. Depending on the selected parameters, this binary input is used to block the actuator or to move it to its end position. Configure the suitable settings on parameter "BIN2".

#### Device features




Figure 4-16 Alarm module, schematic diagram

The alarm module has the following features:

- Available in two versions.
  - Explosion-proof version for connecting to a switching amplifier in conformity with EN 60947-5-6.
  - Non-explosion-proof version for connecting to power sources having a maximum of 35 V.
- Three binary outputs. Binary inputs are potentially separated from the basic configuration and from each other.
- The binary input BIN2 has two inputs. Both inputs are implemented as logical OR combination.
  - Input 1 at terminals 11/12: Is electrically isolated, and is triggered by an active signal.
  - Input 2 at terminals 21/22: Is not electrically isolated, and is triggered by a passive NO contact.

## Requirement

- You are familiar with the general procedure described in the section "General information on installing option modules (Page 53)".

## Procedure for installing the alarm module

1. Open the positioner as in the description depending on the device version:
  - Opening the standard and and intrinsically safe version (Page 53)
  - Opening the device version with "flameproof enclosure" (Page 56)
2. Slide the alarm module into the rack below the basic electronics . Ensure that you slide it up to the endstop.
3. Connect the module to the basic electronics. For this purpose, use the 8-pin flat ribbon cable provided.
4. Close the positioner as in the description depending on the device version:
  - Closing the standard and and intrinsically safe version (Page 55)
  - Closing the device version with "flameproof enclosure" (Page 59)

#### 4.5.4 Slot initiator alarm modules 6DR4004-6G and -8G

##### Function

If the standard controller requires electrically independent limit value messages, the slotted initiator alarm module with slotted initiators is used instead of the alarm module.

- A binary output is used to display a collective fault message. Compare with the function of the alarm module. The floating binary output is implemented as an automatic fault indicating semiconductor output.
- The other two binary outputs are used to signal the two limits L1 and L2 which can be adjusted mechanically using slotted initiators. Both these binary outputs are electrically independent from the remaining electronic unit.

##### Device features




Figure 4-17 SIA module, schematic diagram

The slotted initiator alarm module, SIA module for short, consists of three binary outputs ⑥.

##### Requirement

- You are familiar with the procedure described in the section "General information about the installation of option modules (Page 53)".



## Procedure for installing the slot initiator alarm module

1. Open the positioner as described in section "Opening the standard and and intrinsically safe version (Page 53)".
2. Remove the ribbon cable from the basic electronics.
3. Tighten the two fixing screws of the basic electronics. Remove the basic electronics.
4. Insert the SIA module from the top up to the upper printed circuit board guide of the rack.
5. Slide the module in the printed circuit board of the rack approx. 3 mm to the right.
6. Screw the special screw ② through the module into the positioner shaft. Tighten the special screw ② with a **torque of 2 Nm**.

---

### Note

#### Pin in the actuating disk bearing

A pin ③ is pressed in the actuating disk bearing ①.

1. Align pin ③ with the groove of the special screw before inserting the head of the special screw ② into the actuating disk bearing ①.
2. Rotate the actuating disk bearing ① and the special screw ② simultaneously so that the pin ③ is inserted into the groove of the special screw ②.

- 
7. Set the limits L1 and L2 as described below.
  8. An insulating cover (yellow) is required over the module. This insulating cover is supplied with the module. Place the insulating cover on one side under the basic electronics seat of the rack. The recesses of the insulating cover must fit in the corresponding webs of the rack. To tighten the insulating cover, bend the walls of the adapter slightly outwards. Firmly press the other end until the insulating cover is underneath the contact surface of the basic electronics. The recesses of the insulating cover must fit in the corresponding webs of the rack.
  9. Place the basic electronics onto the four holders of the rack.
  10. Tighten the two fixing screws of the basic electronics. Tighten the screws.
  11. Reestablish all electrical connections between the basic electronics and the option modules.
  12. Connect the basic electronics with the option modules and the potentiometer. Use the corresponding ribbon cables.
  13. Put on the **supplied module cover**. Make sure that the ribbon cable is not trapped.

---

### Note

#### Module cover

Do **not** use the standard module cover. The provided module cover has a larger recess.

- 
14. Select the labels that already exist on the standard version of the module cover from the label set provided. Affix the selected labels on the installed module cover as per the standard version.
  15. Close the positioner as described in section "Closing the standard and and intrinsically safe version (Page 55)".

### See also

Slot initiator alarm modules 6DR4004-6G and -8G (Page 64)

### Procedure: Determining the switch status of the slotted initiators

You will require a suitable display device to determine the switch status. For example, use the initiator tester type 2 / Ex from Pepperl + Fuchs.

1. Connect the display device to the following terminals of the SIA module:
  - 41 and 42
  - 51 and 52
2. Read the switch status of slotted initiators.

### Procedure: Setting the L1 and L2 limits

The consecutive numbers in the following text refer to the above image in this section. Proceed as follows to set the limits:

1. Move the actuator to the first desired mechanical position.
2. Adjust the upper actuating disk ④ manually until the output signal at terminals 41 and 42 changes. Set a high-low or a low-high switchover as follows:
  - Rotate the actuating disc ④ beyond the switching point until you reach the next switching point.
3. Move the actuator to the second desired mechanical position.
4. Adjust the lower actuating disk ⑤ manually until the output signal at terminals 51 and 52 changes. Set a high-low or a low-high switchover as follows:
  - Rotate the actuating disc ⑤ beyond the switching point until you reach the next switching point.

---

#### Note

#### Adjusting the actuating disk

The actuating disks ④ and ⑤ are relatively difficult to move. This design prevents their unintentional movement during operation. You can achieve an easier and finer adjustment by reducing stiction temporarily.

- Move the actuator to and fro while simultaneously holding the actuating disks ④ and ⑤.
- 

## 4.5.5 Mechanical limit switch modules 6DR4004-6K and -8K

### Function

This module is used to report two limits. These limits are reported using galvanic switching contacts.

## Device features




Figure 4-18 Limit contact module, schematic diagram

The mechanical limit switch module consists of:

- One binary output to display a collective fault message. Compare with the device features of the alarm module.
- Two switches to report two mechanically adjustable limits. Both these switches are electrically independent from the remaining electronic unit.

## Requirement

- You are familiar with the procedure described in the section "General information about the installation of option modules (Page 53)".

## Procedure for installing the mechanical limit switch module

1. Open the positioner as described in section "Opening the standard and intrinsically safe version (Page 53)".
2. Remove the ribbon cable from the basic electronics.
3. Tighten the two fixing screws of the basic electronics. Remove the basic electronics.
4. Insert the mechanical limit switch module from the top up to the upper printed circuit board guide of the rack.
5. Slide the module in the printed circuit board of the rack approx. 3 mm to the right.

6. Screw the special screw ② through the module into the positioner shaft. Tighten the special screw ② with a **torque of 2 Nm**.

---

**Note**

**Pin in the actuating disk bearing**

A pin ③ is pressed in the actuating disk bearing ①.

1. Align pin ③ with the groove of the special screw before inserting the head of the special screw ② into the actuating disk bearing ①.
  2. Rotate the actuating disk bearing ① and the special screw ② simultaneously so that the pin ③ is inserted into the groove of the special screw ②.
- 

7. Set the limits L1 and L2 as described below.
8. An insulating cover (yellow) is required over the module. This insulating cover is supplied with the module. Place the insulating cover on one side under the basic electronics seat of the rack. The recesses of the insulating cover must fit in the corresponding webs of the rack. To tighten the insulating cover, bend the walls of the adapter slightly outwards. Firmly press the other end until the insulating cover is underneath the contact surface of the basic electronics. The recesses of the insulating cover must fit in the corresponding webs of the rack.
9. Place the basic electronics onto the four holders of the rack.
10. Tighten the two fixing screws of the basic electronics. Tighten the screws.
11. Reestablish all electrical connections between the basic electronics and the option modules.
12. Connect the basic electronics with the option modules and the potentiometer. Use the corresponding ribbon cables.
13. Put on the **supplied module cover**. Make sure that the ribbon cable is not trapped.

---

**Note**

**Module cover**

Do **not** use the standard module cover. The provided module cover has a larger recess.

---

14. Close the positioner as described in section "Closing the standard and and intrinsically safe version (Page 55)".

### Procedure: Setting the limits L1 and L2

1. Move the actuator to the first desired mechanical position.
2. Adjust the upper actuating disk ④ manually until the output signal at terminals 51 and 52 changes. Set a high-low or a low-high switchover as follows:
  - Rotate the actuating disc beyond the switching point until you reach the next switching point.

3. Move the actuator to the second desired mechanical position.
4. Adjust the lower actuating disk ⑤ manually until the output signal at terminals 41 and 42 changes. Set a high-low or a low-high switchover as follows:
  - Rotate the actuating disc beyond the switching point until you reach the next switching point.

---

**Note****Adjusting the actuating disk**

The actuating disks ④ and ⑤ are relatively difficult to move. This design prevents their unintentional movement during operation. You can achieve an easier and finer adjustment by reducing stiction temporarily.

- Move the actuator to and fro while simultaneously holding the actuating disks ④ and ⑤.
- 

**See also**


Mechanical limit switch modules 6DR4004-6K and -8K (Page 66)

### 4.5.6 Internal NCS modules (iNCS) 6DR4004-5L and -5LE

#### Function

Wear-free, contact-free position detection

#### Device features



- ① Internal NCS module 6DR4004-5L.
- ② Insulating cover, yellow
- ③ Ribbon cable of the internal NCS module
- ④ Adjustment wheel for the magnet clamp
- ⑤ Adjustment wheel for the friction clutch (without function)


Figure 4-19 Installing the internal NCS module, schematic diagram

## Requirement

- You are familiar with the general procedure described in the section "General information on installing option modules (Page 53)".
- The slot required for the internal NCS (iNCS) module in the rack is free. The following option modules use the same slot in the rack:
  - Alarm module
  - SIA module
  - Mechanical limit switch module
  - Internal NCS module
- The positioner is mounted, or is to be mounted, directly on the valve using the positioner shaft.


## Procedure

1. Open the positioner as in the description depending on the device version:
  - Opening the standard and and intrinsically safe version (Page 53)
  - Opening the device version with "flameproof enclosure" (Page 56)
2. Remove the ribbon cable from the basic electronics.
3. Tighten the two fixing screws of the basic electronics.
4. Remove the basic electronics.
5. Insert the connector of the ribbon cable (A) into the slot as shown below.  
Note: There is no space for the ribbon cable (A) in earlier versions of the positioner. Here you fasten the ribbon cable to the container using a cable tie.




6. Screw the special screw ⑥ into the shaft of the positioner.

7. Tighten the special screw with a torque of 2 Nm.



8. Press the adjustment wheel of the magnet clamp (4) firmly onto the special screw (6) of the friction clutch until you clearly hear it click into place.



#### Installing the internal NCS module

1. Position the ribbon cable (3) of the internal NCS module (1) on the top before you slide the internal NCS module into the rack.
2. Slide the internal NCS module (1) under the basic electronics into the rack until you hear it click into place.
3. An insulating cover (yellow) is required over the module. This insulating cover is supplied with the module. Place the insulating cover (2) on one side under the basic electronics seat of the rack. The recesses of the insulating cover must fit in the corresponding webs of the rack.
4. To tighten the insulating cover, bend the walls of the adapter slightly outwards.
5. Firmly press the other end until the insulating cover is underneath the contact surface of the basic electronics. The recesses of the insulating cover must fit in the corresponding webs of the rack.

#### Installing the basic electronics and closing the positioner

1. Place the basic electronics onto the four holders of the rack.
2. Tighten the two fixing screws of the basic electronics.
3. Tighten the screws.



4. Insert the ribbon cable connector of the internal NCS module ① onto the positioner basic electronics.  
Note for installed position feedback module: Reestablish all electrical connections between the basic electronics and the position feedback module.
5. Put on the **supplied module cover**. Make sure that the ribbon cable is not trapped.

---

**Note****Module cover**

Do **not** use the standard module cover. The provided module cover has a larger recess.

---

6. Close the positioner as in the description depending on the device version:
  - Closing the standard and intrinsically safe version (Page 55)
  - Closing the device version with "flameproof enclosure" (Page 59)

**Result**


The module is installed and connected to the basic electronics of the positioner. Now configure the module with the parameter "1.YFCT (Page 142)".

### 4.5.7 EMC filter modules 6DR4004-6F and -8F

#### Function

You will require the EMC filter module if you use an external position sensor on the positioner, e.g. a potentiometer or a non-contacting sensor. The EMC filter module forms the interface between external position sensors and the basic electronics of the positioner. This module protects the positioner from electromagnetic effects.

#### Device features



- ① Switch block 1
- ② Switch block 2

Figure 4-20 EMC filter module, schematic diagram


- EMC protection
- Connection to basic electronics
- Connection terminals for:
  - External potentiometers with 3 k $\Omega$ , 5 k $\Omega$  or 10 k $\Omega$
  - Signals 0 to 20 mA
  - Signals 0 to 10 V

#### Requirement

- You are familiar with the general procedure described in the section "General information on installing option modules (Page 53)".
- You have at least one of the following modules:
  - 6DR4004-8F EMC filter module / Analog Input Module (AIM) - nEx
  - 6DR4004-6F EMC filter module / Analog Input Module (AIM) - Ex

- Any already installed optional module has been removed.
- You have one of the following external position detection systems / Position Transmitters:
  - 6DR4004-.N\* NCS sensor
  - C73451-A430-D78 Polycarbonate enclosure with potentiometer
  - 6DR4004-1ES Aluminum enclosure with potentiometer
  - 6DR4004-2ES Aluminum enclosure with NCS
  - 6DR4004-3ES Aluminum enclosure with NCS and SIA module / Inductive Limit Switch (ILS)
  - 6DR4004-4ES Aluminum enclosure with NCS and Mechanic Limit Switch (MLS)

### Procedure for installing the EMC filter module




- |                                                                                                     |                                    |
|-----------------------------------------------------------------------------------------------------|------------------------------------|
| ① EMC filter module terminals                                                                       | ⑤ Basic electronics                |
| ② Yellow wheel for locking the position detection                                                   | ⑥ Screw                            |
| ③ Positioner                                                                                        | ⑦ EMC filter module 6DR4004-6F1-8F |
| ④ Ribbon cable connector of fitted potentiometer,<br>or ribbon cable connector of EMC filter module |                                    |

Figure 4-21 Installation EMC filter module


1. Open the positioner as described in section "Opening the standard and intrinsically safe version (Page 53)".
2. Remove the ribbon cable from the basic electronics.
3. Loosen the two fixing screws of the basic electronics ⑤.
4. Remove the basic electronics.
5. Loosen the screw ⑥ in the connection area of the positioner.


6. Insert the connector of the ribbon cable (A) into the slot as shown below.  
Note: There is no space for the ribbon cable (A) in earlier versions of the positioner. Here you fasten the ribbon cable with the supplied cable tie at the container.




7. Secure the EMC filter module using the screw ⑥.
8. Place the basic electronics ⑤ onto the four holders of the rack.
9. Screw in the two fixing screws of the basic electronics ⑤.
10. Tighten the screws.
11. Insert the ribbon cable connector ④ of the EMC filter module onto the positioner basic electronics.
12. Establish all electrical connections between the basic electronics and the option modules.
13. Close the positioner as described in section "Closing the standard and and intrinsically safe version (Page 55)".

## 5.1 Basic safety instructions

 <b>WARNING</b>
<b>Lever for position detection</b> Danger of crushing and shearing with mounting kits which use a lever for position detection. During commissioning and ongoing operation, severing or squeezing of limbs could occur as a result of the lever. Risk of injury when working on control valves due to the high operating force of the pneumatic actuator. <ul style="list-style-type: none"><li>• Do not reach into the range of motion of the lever following mounting of the positioner and mounting kit.</li></ul>

 <b>WARNING</b>
<b>With intrinsically device version (Ex i)</b> Risk of explosion in hazardous areas. For intrinsically safe device versions only the certified circuits may be connected as auxiliary power supply, control and signal circuits. <ul style="list-style-type: none"><li>• Make sure that the power source of the used circuits is marked as intrinsically safe.</li></ul>

 <b>WARNING</b>
<b>Unsuitable cables, cable glands and/or plugs</b> Risk of explosion in hazardous areas. <ul style="list-style-type: none"><li>• Use only cable glands/plugs that comply with the requirements for the relevant type of protection.</li><li>• Tighten the cable glands in accordance with the torques specified in Technical data (Page 281).</li><li>• Close unused cable inlets for the electrical connections.</li><li>• When replacing cable glands, only use cable glands of the same type.</li><li>• After installation, check that the cables are seated firmly.</li></ul>

**NOTICE****Condensation in the device**

Damage to device through formation of condensation if the temperature difference between transportation or storage and the mounting location exceeds 20 °C (36 °F).

- Before taking the device into operation let the device adapt for several hours in the new environment.

**NOTICE****Ambient temperature too high**

Damage to cable sheath.

- At an ambient temperature  $\geq 60$  °C (140 °F), use heat-resistant cables suitable for an ambient temperature at least 20 °C (36 °F) higher.

**WARNING****Improper power supply**

Risk of explosion in hazardous areas as result of incorrect power supply.

- Connect the device in accordance with the specified power supply and signal circuits. The relevant specifications can be found in the certificates, in Technical data (Page 281) or on the nameplate.

**WARNING****Lack of equipotential bonding**

Risk of explosion through compensating currents or ignition currents through lack of equipotential bonding.

- Ensure that the device is potentially equalized.

**Exception:** It may be permissible to omit connection of the equipotential bonding for devices with type of protection "Intrinsic safety Ex i".

**WARNING****Unprotected cable ends**

Risk of explosion through unprotected cable ends in hazardous areas.

- Protect unused cable ends in accordance with IEC/EN 60079-14.

**⚠ WARNING****Improper laying of shielded cables**

Risk of explosion through compensating currents between hazardous area and the non-hazardous area.

- Shielded cables that cross into hazardous areas should be grounded only at one end.
- If grounding is required at both ends, use an equipotential bonding conductor.

**⚠ WARNING****Connecting device in energized state**

Risk of explosion in hazardous areas.

- Connect devices in hazardous areas only in a de-energized state.

**Exceptions:**

- Devices having the type of protection "Intrinsic safety Ex i" may also be connected in energized state in hazardous areas.
- Exceptions for type of protection "Increased safety ec" (Zone 2) are regulated in the relevant certificate.

**⚠ WARNING****Incorrect selection of type of protection**

Risk of explosion in areas subject to explosion hazard.

This device is approved for several types of protection.

1. Decide in favor of one type of protection.
2. Connect the device in accordance with the selected type of protection.
3. In order to avoid incorrect use at a later point, make the types of protection that are not used permanently unrecognizable on the nameplate.

**NOTICE****Standard cable gland/torque**

Device damage.

- Owing the reasons pertaining to tightness (IP enclosure rating) and the required tensile strength, only use the cables having a diameter  $\geq 8$  mm for standard M20x1.5 cable gland, or use a suitable seal insert in case of smaller diameters.
- In the NPT version, the positioner is delivered with a coupling. When inserting a counter piece in the coupling, ensure that the maximum permissible torque of 10 Nm is not exceeded.

<b>⚠ CAUTION</b>
<b>Maximum AC/DC switching voltage with UL approval E344532</b>
Mechanic Limit Switches (MLS) 6DR4004-6K/-8K are approved for use with positioners with UL approval. The maximum switching voltage in this case is $\leq 30$ V AC/DC.
If switching voltages greater than 30 V are connected, the UL approval for the positioner becomes invalid.

**Note**


**Improvement of interference immunity**

- Lay signal cables separate from cables with voltages  $> 60$  V.
- Use cables with twisted wires.
- Keep device and cables at a distance from strong electromagnetic fields.
- Take account of the conditions for communication specified in the Electrical specifications (Page 289).
- Use shielded cables to guarantee the full specification according to HART/PA/FF/Modbus/EIA-485/Profibus DP.

**Electromagnetic compatibility**

The polycarbonate enclosure is metalized from inside to increase the electromagnetic compatibility (EMC) with respect to high-frequency radiation. The shield is connected to the threaded bush shown in the following picture such that it is electrically conductive.

Note that this protection is effective only if you connect at least one of these bushes to the earthed control valves through electrically conductive (bare) attachments.



⏏ Shield  
Figure 5-1 Base plate ①



### 5.1.1 Interference immunity

If the bus shield is fully effective, the interference immunity and the interference emission conform to the specifications. The following measures ensure that the bus shield is fully effective:

- The shields have been connected to the metallic connections of the positioner.
- The shields have been laid up to the terminal boxes, the distributor and the transceiver.

---

#### Note

##### Dissipation of glitch impulses/equipotential bonding

In order to dissipate glitch impulses, the positioner must be connected to an equipotential bonding cable (earth potential) using a low resistance. The positioner in the polycarbonate enclosure is therefore equipped with an additional cable. Connect this cable to the shield of the bus cable and the equipotential bonding cable using a cable clamp.

Devices in the stainless steel or aluminum enclosure have a corresponding terminal on the outer side of the enclosure. This terminal must also be connected to the equipotential bonding cable.

For applications in hazardous areas, ensure an adequately suitable equipotential bonding between the hazardous and non-hazardous areas.

---

### 5.1.2 Safety shutdown

The positioner is equipped with an additional input (terminal 81 [+] and terminal 82 [-]) to approach the safety position. After activating this function, this input must be continuously supplied with +24 V in order to retain the normal control function.

If the 24-V signal is interrupted, the safety position is set as described in chapter "Basic safety instructions for the pneumatic connection (Page 92)".

Communication with the master is still possible. The "Jumper" on the basic electronics is used to activate this function. It can be accessed after removing the module cover, and must be switched from the right position (delivery state) to the left position.

## 5.2 Electrical wiring

### 5.2.1 Connection diagram for basic electronics





Figure 5-2 Device version with PROFIBUS PA

#### See also

Electrical specifications (Page 289)

### 5.2.2 Bus cable

The following image will help you in preparing the bus cable for the connection:



- a 80 mm: Normal version of device  
 120 mm: Version with flameproof enclosure (6DR5..5)
- ① Bus cables to be used:  
 SIMATIC NET, PB FC Process Cable, bus cable for IEC 61158-2
- ② Cable shield

Figure 5-3 Preparation of bus cable

### Devices without flameproof enclosure are:

- Normal version of devices
- Intrinsically safe versions
- Versions for zones 2 and 22

### Procedure for device versions without flameproof enclosure




Figure 5-4 Connection of bus cable and grounding cable for device version with polycarbonate enclosure


1. Strip the bus cable ①.
2. Open the enclosure of the positioner by unlatching the four cover screws.
3. Insert the prepared bus cable (described in Bus cable (Page 82)) through the cable inlet.
4. Fasten the shield using the clamp ② and the two screws on the enclosure.
5. Tighten the cable inlet.
6. Connect the red and the green wires to terminals 6 and 7 of the basic electronics as shown in the following picture. The polarity does not play any role here.

#### Note

#### Bus cable and grounding cable for device version with stainless steel/aluminum enclosure

In the case of the stainless steel or aluminum enclosure, use the grounding terminal provided on the outside of the device.

### Procedure for device versions with flameproof enclosure "Ex d"



- ① Basic electronics bus cable
- ② Grounding terminal
- ③ Ex d certified cable inlet
- ④ Bus cable
- ⑤ Cable clamp/shield

Figure 5-5 Connection of bus cable for versions with flameproof enclosure

1. Strip the bus cable.
2. Open the safety catch and unscrew the screw cap to open the positioner.
3. Insert the prepared bus cable ④ (described in Bus cable (Page 82)) through the Ex d-certified cable inlet ③. Follow the corresponding guidelines if you are using a conduit piping system.
4. Fasten the shield on the adapter using the clamp ⑤ and the two screws.
5. Tighten the Ex d-certified cable inlet ③.
6. Connect the red and the green wires to terminals 6 and 7 of the basic electronics as shown in the following picture. The polarity does not play any role here.


If a bus connection is not present, connect a separate power source with the following values to terminals 6/7:

- With intrinsically-safe devices: intrinsically-safe isolating power supply with 24 V DC
- With non-intrinsically-safe devices: 15 to 30 V DC

Then match the positioner to the respective actuator by configuring and initializing it. Finally set the bus address.

## 5.2.3 Option modules

### 5.2.3.1 Alarm modules 6DR4004-6A and -8A



nEx = Non-explosion-proof device version

Figure 5-6 Alarm module

5.2.3.2 Position feedback modules 6DR4004-6J and -8J




Figure 5-7 Analog Output Module (AOM)

5.2.3.3 SIA modules 6DR4004-6G and -8G




Figure 5-8 SIA module

## 5.2.3.4 Mechanical limit switch modules 6DR4004-6K and -8K

**! DANGER****Supply with hazardous voltage**

If you connect the switching contacts of the 6DR4004-8K module to a hazardous voltage, observe the following safety rules:

1. Isolate the device from power. Use a circuit breaker positioned near the device to do this.
2. Make sure that the device cannot be switched back on inadvertently.
3. Make sure the device is truly isolated from power.

**! CAUTION****Maximum AC/DC switching voltage with UL approval E344532**

Mechanic Limit Switches (MLS) 6DR4004-6K/-8K are approved for use with positioners with UL approval. The maximum switching voltage in this case is  $\leq 30$  V AC/DC.

If switching voltages greater than 30 V are connected, the UL approval for the positioner becomes invalid.

## Connection diagram for mechanical limit switch modules 6DR4004-6K and -8K





Figure 5-9 Mechanical limit switch module

### Procedure

1. Loosen the screw ① on the transparent cover ②.
2. Pull the transparent cover ② up to the front end stop.
3. Tighten every cable in the corresponding terminal.
4. Slide the transparent cover ② up to the end stop of the basic electronics.
5. Tighten the screw ① of the transparent cover ②.
6. Connect the cables of each switch to the lug of the printed circuit board in pairs. Use the provided cable ties ③ for this purpose.



- ① Screw
- ② Cover
- ③ Cable tie


Figure 5-10 Connecting the cables



## 5.2.3.5 EMC filter modules 6DR4004-6F and -8F

## Procedure

1. Connect the external position detection as follows.



2. If potentiometers or external signal sources are used, configure the switch blocks in accordance with the following table:

Measuring range	Switch block 1		Switch block 2			
	S1-1	S1-2	S2-1	S2-2	S2-3	S2-4
6DR4004-.N/P/R (NCS)	ON	OFF	ON	OFF	OFF	OFF
C73451-A430-D78	ON	OFF	ON	OFF	OFF	OFF
6DR4004-1ES / -2ES / -3ES / -4ES	ON	OFF	ON	OFF	OFF	OFF
10 ... 20 kΩ	ON	OFF	ON	OFF	OFF	OFF
5 kΩ	OFF	ON	ON	OFF	OFF	OFF
3 kΩ	OFF	OFF	ON	OFF	OFF	OFF

Measuring range	Switch block 1		Switch block 2			
	S1-1	S1-2	S2-1	S2-2	S2-3	S2-4
20 mA	OFF	OFF	ON	OFF	ON	OFF
10 V	OFF	OFF	OFF	ON	OFF	OFF

### 5.2.4 Option device version M12 connector


This section describes which terminal of the devices and option modules listed below is connected with the respective pole of the M12 connector.

**Note**

**Technical specifications**

Observe the specifications for the electrical data in the certificate and/or in section "Technical data (Page 281)".

**View of the mating side pole pattern**



Pole designation	Wire color of M12 connector
1	Brown
4	Black
3	Blue
2	White

#### 5.2.4.1 M12 connector in the basic device

You have a positioner 6DR55...-0.R.. or 6DR55...-0.S. In this case the M12 connector is connected to the bus circuit of the basic electronics.

Table 5-1 Assignment diagram

Bus circuit terminal	Pole designation
7	1 - Brown
Shield support of housing	4 - Black
6	3 - Blue

### 5.2.4.2 M12 connector for connecting the position feedback module 6DR4004-6J / 8J (-Z D53)

You have a positioner with order suffix -Z order code D53. In this version of the positioner, the M12 connector is used to electrically connect the current output of the position feedback module.

Table 5-2 Assignment diagram

Current output terminal	Pole designation
61 (+)	1 - Brown
Shield support of housing	4 - Black
62 (-)	3 - Blue

### 5.2.4.3 M12 connector for connecting the external position detection system (-Z D54)

You have a positioner with order suffix -Z order code D54. In this version of the positioner, the M12 connector is used to electrically connect the fitted EMC filter module (6DR4004-6F). Connect the external position detection system using the M12 connector.

Table 5-3 Assignment diagram

Terminal	Pole designation
POS (X1/2)	3 - Blue
VCC (X1/4)	1 - Brown
GND (X1/1)	4 - Black
VREF (X1/3)	2 - White

### 5.2.4.4 M12 connector for connecting the alarm module 6DR4004-6A / -8A (-Z D55)

You have a positioner with order suffix -Z order code D55. In this version of the positioner, the M12 connector is used to electrically connect the current output of the position feedback module.

Table 5-4 Assignment diagram

Alarm output terminal	Pole designation
41 (+)	1 - Brown
52 (-)	4 - Black
42 (-)	3 - Blue
51 (+)	2 - White

5.3 Pneumatic connection

**5.2.4.5 M12 connector for connecting the SIA module 6DR4004-6G /-8G (-Z D56)**

You have a positioner with order suffix -Z order code D56. In this version of the positioner, the M12 connector is used to electrically connect the outputs of the SIA module.

Table 5-5 Assignment diagram

Alarm output terminal	Pole designation
41 (+)	1 - Brown
52 (-)	4 - Black
42 (-)	3 - Blue
51 (+)	2 - White

**5.2.4.6 M12 connector for connecting the mechanical limit switch module 6DR4004-6K (-Z D57)**


You have a positioner with order suffix -Z order code D57. In this version of the positioner, the M12 connector is used to electrically connect the outputs of the mechanical limit switch module.

Table 5-6 Assignment diagram

Alarm output terminal	Pole designation
41 (+)	1 - Brown
52 (-)	4 - Black
42 (-)	3 - Blue
51 (+)	2 - White

**5.3 Pneumatic connection**

**5.3.1 Basic safety instructions for the pneumatic connection**

<p> <b>WARNING</b></p> <p><b>Pneumatic auxiliary power</b></p> <p>For safety reasons, the pneumatic auxiliary power supply can be fed after installation only if the positioner is switched to "P-Manual mode" when an electrical signal is present. This operating mode is preset in the delivery state.</p>
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

**Note**

**Specifications regarding air quality**

Observe the specifications regarding the air quality, see section "Technical specifications > Pneumatic data (Page 282)".

**Note****Leakage**

Besides continuous air consumption, a leakage can cause the positioner to try to compensate the position deviation. This will result in premature wear in the entire control device.

- Check offline using the diagnostic parameter "11.LEAK" whether leakage is present.
- If there is leakage, check the pneumatic connections for leaks.

**See also**

Changing the operating mode (Page 101)

Diagnostic value '11.LEAK - Leakage test' (Page 261)


**5.3.2 Pneumatic connection in non-flameproof enclosure****5.3.2.1 Structure of pneumatic connection**

Figure 5-11 Pneumatic connection, example

**5.3.2.2 Integrated pneumatic connection**


The following pneumatic connections are provided at the rear side of the basic device for the integrated attachment for single-acting linear actuators:

- Actuating pressure Y1
- Exhaust air outlet

These connections are sealed with screws when the device is delivered.

5.3 Pneumatic connection

The exhaust air outlet is corrosion-resistant for the blanketing of the pick-up room and the spring chamber with dry instrument air.




- ① Actuating pressure Y1
- ② Exhaust air outlet

Figure 5-12 Integrated pneumatic connection

### 5.3.3 Pneumatic connection in the flameproof enclosure

#### Structure

The pneumatic connections are provided on the right side of the positioner.




- ① Restrictor Y2 \*)
- ② Restrictor Y1
- ③ Output: Actuating pressure Y2 \*)
- ④ Input: Supply air PZ
- ⑤ Output: Actuating pressure Y1
- ⑦ Enclosure ventilation (2x)
- ⑥ Exhaust air outlet

\*) for double-acting actuators

Figure 5-13 Pneumatic connection in the flameproof enclosure

### 5.3.4 Reaction to failure of auxiliary powers

#### Overview

 <b>CAUTION</b>
<b>Before working on the control valve</b>
Note that before working on the control valve, you must first move it to the safety position. Make sure that the control valve has reached the safety position. If you only interrupt the pneumatic auxiliary power supply to the positioner, the safety position may in some cases only be attained after a certain delay period.

The difference between a failure of auxiliary pneumatic power and a failure of electrical auxiliary power:

- Failure of **electrical auxiliary power** means:
  - Failure of the bus voltage
  - Failure or signal <4.5 V at input for the safety shutdown (terminals 82 and 82)
- Failure of **auxiliary pneumatic power** means the supply air PZ is interrupted.


The following table shows the pneumatic connection versions for different actuator types, regulating action and safety position after an auxiliary power supply failure.

Actuator type	Response to failure of auxiliary power: The actuator moves into safety position		Fail in place, order suffix F01	
	Failure of electrical auxiliary power	Failure of pneumatic auxiliary power	Failure of electrical auxiliary power	Failure of pneumatic auxiliary power
Single-acting	Y1 = vented	Y1 = vented	Y1 = closed	Y1 = closed
Double-acting	Y1 = pressurized Y2 = vented	Y1 = closed Y2 = closed	Y1 = closed Y2 = closed	Y1 = closed Y2 = closed

## 5.4 Restrictors

- Reduce the air output to achieve travel times of  $T > 1.5$  s for small actuators. Use restrictors Y1 ① and Y2 ② for this purpose.
- When turned clockwise, they reduce the air output and finally shut it off.

- In order to set the restrictors, we recommend closing them and then opening slowly.
- In case of double-acting valves, ensure that both restrictors have approximately the same setting.



- ① Restrictor Y1
- ② Restrictor Y2, only in the version for double-acting actuators \*)
- ③ Hexagon socket-head screw 2.5 mm

Figure 5-14 Restrictors

\*) Restrictor Y2 ② is not active for single-acting Fail in Place F01

**See also**

Sequence of automatic initialization (Page 111)



## Operation

### 6.1 Operating elements

#### 6.1.1 Display

##### Introduction

**Note**

**Repetition rate display**

When operated in temperature ranges below -10°C, the liquid crystal display of the positioner becomes sluggish and the repetition rate display reduces considerably.

The display has two lines. These two lines are segmented differently. Each element in the upper line has 7 segments, whereas that in the lower line has 14 segments. Contents of the display depend on the selected mode.

#### Display options as per the mode

An overview of mode-specific display options is given below.

Operating mode	Representation in the display	Pos.	Legend
P manual mode		①	Potentiometer setting [%]
		②	Blinking indicator for the non-initialized status.
Initialization mode		①	Potentiometer setting [%]
		②	Display of the current status of initialization or a fault message.
		③	Indicator for ongoing initialization or a fault message.
Configuring		①	Parameter value
		②	Parameter name
		③	Parameter number

6.1 Operating elements

Operating mode	Representation in the display	Pos.	Legend
Manual mode (MAN)		①	Position [%]
		②	Setpoint [%]
		③	Fault message
Automatic (AUT)		①	Position [%]
		②	Setpoint [%]
		③	Fault message
Diagnostics		①	Diagnostics value
		②	Diagnostics name
		③	Diagnostics number

See also

System messages before initialization (Page 250)

Changing the operating mode (Page 101)

6.1.2 Buttons




Figure 6-1 Display and buttons of the positioner

- You can use three buttons to operate the positioner.
- The function of the buttons depends on the mode selected.
- In a positioner with a flameproof enclosure, the buttons are protected by a cover. The button cover can be opened after unlatching the locking screw.

---

**Note****Button cover**

In positioners with flameproof enclosures, the button cover prevents liquids from seeping through. The IP66 / type 4X degree of protection is not ensured when the enclosure or the button cover is open.

---

You have to remove the enclosure cover to operate the buttons of the basic device or the "intrinsically safe" version.




---

**Note****Degree of protection**

The IP66 / type 4X degree of protection is not ensured as long as the positioner is open.



---

**Function of buttons:**

- The  button is used to select the modes and to forward the parameters.
- The  button is used to select parameter values in "Configuration" mode. You can use this button to move the actuator in "Manual" mode.
- The  button is also used to select parameter values in "Configuration" mode. You can use this button to move the actuator in "Manual" mode.

---

**Note****Order**

Parameters are activated in the reverse order when the  and  buttons are pressed simultaneously.

---

**See also**

Display (Page 97)

### 6.1.3 Firmware version

The current firmware version is displayed when you exit the configuration menu.




Figure 6-2 Firmware version, e.g. version 6.00.00

## 6.2 Operating modes

### 6.2.1 Overview of operating modes

You have five operating modes at your disposal to operate the positioner:

1. P-manual mode (as-delivered condition)
2. Configuration and initialization mode
3. Manual mode (MAN)
4. Automatic (AUT)
5. Diagnostics

## 6.2.2 Changing the operating mode

The following picture illustrates the available operating modes and switching between the operating modes.




Figure 6-3 Switching between the operating modes

See also

Display (Page 97)

### 6.2.3 Overview of configuration

The following picture illustrates the handling of operating modes such as "Configuration" and "Initialization mode":




Figure 6-4 Overview of the "Configuration" operating mode

### 6.2.4 Description of operating modes

#### P manual mode

**Note**

**Delivery state**

The "P manual mode" is preset for the positioner in the delivery state.

The display of the positioner shows the current potentiometer position in the upper line. "NOINI" blinks in the second line of the display.

Move to the actuator with the ▽ or ▲ buttons.

Switch to "Configuration" mode to adapt the actuator to the positioner.

Alarms or position feedbacks can be triggered after initializing the positioner completely.

#### Configuration and initialization

To get to the "Configuration" mode, press the button for at least 5 seconds.

You can use the "Configuration" mode to adjust the positioner individually as per your actuator and start commissioning or initialization.

The positioner reports the "Configuration" mode with a configurable fault message. A position feedback or display of limits A1 and A2 is not possible.

---

**Note****Failure of electrical auxiliary power**

If electrical auxiliary power supply fails when configuring, the positioner responds as follows when the power supply is reestablished:

- The positioner switches to the first parameter.
- Settings of the values already configured are retained.

In order to save the changed parameter values, exit the "Configuration" mode or switch to another parameter. When "Configuration" mode is restarted, the output in the display switches to the last activated parameter.

---

## Manual mode (MAN)

In this mode, you move the actuator with  $\nabla$  or  $\triangle$ . The setting selected here is retained irrespective of the setpoint current and leakages, if any.

---

**Note****Accelerating the actuator movement**

Proceed as follows if you wish to accelerate the actuator movement:

1. Keep one of the two direction buttons pressed.
  2. Press the remaining direction button simultaneously.
- 

**Note****Failure of power supply**

When the power supply is reestablished after a failure, the positioner switches to the "Automatic" mode.

---

## Automatic (AUT)

Automatic is the standard mode. In this mode, the positioner compares the setpoint position with the actual position. The positioner moves the actuator until the control deviation reaches the configurable deadband. An error message is displayed if the deadband cannot be reached.

## Diagnostics

Proceed as follows to call the "Diagnostics" mode from the "Automatic" or "Manual" modes:

Press the three buttons of the positioner at the same time for at least 2 seconds.

Current operating data can be called and displayed in this mode, e.g.:

- Number of total strokes
  - Number of changes in direction
  - Number of fault messages
- 

**Note**

**Setting the mode**

The "Automatic" and "Manual" modes remain set when switching to the "Diagnostics" mode. The positioner responds as per the configured mode:

- The predefined setpoint is used as the control variable in "Automatic" mode.
  - The last reached position is retained in "Manual" mode.
- 

**See also**

Overview (Page 109)

Overview of advanced diagnostics parameters A to P (Page 138)

Overview of diagnostics values (Page 257)

## 6.2.5 Optimization of controller data

---

**Note**

**Initializing**

Initialize the positioner automatically before changing the parameter settings as per your specific requirements.

---

The positioner determines the data for control quality automatically during the initialization process.



The data determined is optimized for a short transient time in the case of minor overshoots.

The adjustment can be accelerated or the attenuation can be intensified by optimizing the data.

The following special cases are suitable for targeted data optimization:

- Small actuators with travel times < 1 s.
- Operation with boosters, described in section "Booster commissioning (Page 349)"

**Procedure**

1. Switch to "Diagnostics" mode.
2. Select the diagnostics parameters.
3. Press the three buttons of the positioner at the same time for at least 2 seconds.
4. Activate the setting function. Press the  or  button for at least 5 seconds.



The modified diagnostics values are effective immediately. The effects on the controller results can then be tested.

In order to optimize the controller data, change the values of the diagnostics parameters listed below.

### Diagnostics parameters '23.IMPUP' Impulse length UP / '24.IMPDN' Impulse length DOWN

You can use these diagnostics parameters to determine the smallest impulse lengths for each actuating direction. The actuator is then moved with these lengths. The optimum value depends in particular on the volume of the actuator. Small values lead to small controller increments and frequent activation of the actuator. Large values are advantageous for large actuator volumes.

---

#### Note

##### Controller increments

- There is no movement if the values are too small.
  - Large controller increments also lead to large movements with small actuators.
- 

### Diagnostics parameters '28.SSUP' Slow step zone UP / '29.SSDN' Slow step zone DOWN

The slow step zone is the area of mean control deviation. For more information on the slow step zone, refer to the section "Functional principle (Page 30)".

Select small values to achieve high speeds of shifting even with small control deviations. Select large values to reduce overshoots particularly in case of large changes in the setpoint.

<b>NOTICE</b>
<b>Overshoots or too low speeds of shifting</b>
Too small values can result in overshoots.
<ul style="list-style-type: none"><li>• Enter a higher value.</li></ul>
Too large values result in too slow speeds of shifting near the adjusted status.
<ul style="list-style-type: none"><li>• Enter a smaller value.</li></ul>

### Diagnostics parameters '47.PRUP' Prediction UP / '48.PRDN' Prediction DOWN

These diagnostics parameters act as attenuation factors and are used to set the control dynamics. Changes in the diagnostics values have the following results:

- Small values result in quick adjustments with overshoots.
- Large values result in slow adjustments without overshoots.

---

#### **Note**

##### **Reference variable**


It is advantageous to use a fixed reference variable to optimize the control data. Therefore, change the deadband of the controller in the '34.DEBA' parameter from "Auto" to a fixed value.


---


# Commissioning


## 7.1 Basic safety instructions


### 7.1.1 Lever for position detection


 <b>WARNING</b>
<b>Lever for position detection</b> Danger of crushing and shearing with mounting kits which use a lever for position detection. During commissioning and ongoing operation, severing or squeezing of limbs could occur as a result of the lever. Risk of injury when working on control valves due to the high operating force of the pneumatic actuator. <ul style="list-style-type: none"><li>• Do not reach into the range of motion of the lever following mounting of the positioner and mounting kit.</li></ul>


 <b>WARNING</b>
<b>Improper commissioning in hazardous areas</b> Device failure or risk of explosion in hazardous areas. <ul style="list-style-type: none"><li>• Do not commission the device until it has been mounted completely and connected in accordance with the information in Technical data (Page 281).</li><li>• Before commissioning take the effect on other devices in the system into account.</li></ul>

 <b>WARNING</b>
<b>Loss of explosion protection</b> Risk of explosion in hazardous areas if the device is open or not properly closed. <ul style="list-style-type: none"><li>• Close the device as described in Installing/mounting (Page 39).</li></ul>

 <b>WARNING</b>
<b>Opening device in energized state</b>
Risk of explosion in hazardous areas
<ul style="list-style-type: none"><li>• Only open the device in a de-energized state.</li><li>• Check prior to commissioning that the cover, cover locks, and cable inlets are assembled in accordance with the directives.</li></ul>
<b>Exception:</b> Devices having the type of protection "Intrinsic safety Ex i" may also be opened in energized state in hazardous areas.

 <b>WARNING</b>
<b>Water in compressed air line</b>
Device damage and possibly loss of type of protection. The factory setting for the purging air selector is "IN". In the "IN" position, water from the compressed air line may enter the device from the pneumatics during initial commissioning.
<ul style="list-style-type: none"><li>• Before commissioning, make sure that no water is present in the compressed air line.</li></ul>
If you cannot be sure that there is no water in the compressed air line:
<ul style="list-style-type: none"><li>• Set the purging air selector to "OUT". In this way, you prevent water from the compressed air line from penetrating the device.</li><li>• Only set the purging air selector to "IN" again when all water has been discharged from the compressed air line.</li></ul>

 <b>WARNING</b>
<b>Loss of type of protection</b>
Risk of explosion. Damage to device if the enclosure is open or not properly closed. The type of protection specified on the nameplate or in Technical data (Page 281) is no longer guaranteed.
<ul style="list-style-type: none"><li>• Make sure that the device is securely closed.</li></ul>

 <b>WARNING</b>
<b>Commissioning and operation with pending error</b>
If an error message appears, correct operation in the process is no longer guaranteed.
<ul style="list-style-type: none"><li>• Check the gravity of the error.</li><li>• Correct the error.</li><li>• If the error still exists:<ul style="list-style-type: none"><li>– Take the device out of operation.</li><li>– Prevent renewed commissioning.</li></ul></li></ul>

**⚠ CAUTION****Increased sound pressure level**

Changes to the sound absorber of the positioner or the mounting of pneumatic components or pneumatic options on the positioner can cause a sound pressure with a level of 80 dBA to be exceeded.

- Wear suitable hearing protection to protect yourself against hearing damage.

When operating the positioner with natural gas, you must follow and adhere to the following safety notes:

**⚠ WARNING****Operation with natural gas**

1. Only positioners and option modules which are connected to power supplies with type of protection "Intrinsic safety, protection level [ia]" may be operated with natural gas.
2. Do not operate the positioner with natural gas in closed spaces.
3. Natural gas is continuously blown off, depending on the model. Special care must therefore be taken during maintenance activities near the positioner. Always ensure that the immediate surroundings of the positioner are adequately ventilated.  
The maximum values for ventilation are listed in section "Technical data for natural gas as actuator medium (Page 292)".
4. If you operate the positioner with natural gas, it is not permitted to use Mechanic Limit Switches (MLS).
5. Depressurize the devices operated with natural gas adequately during maintenance activities. Open the cover in an explosion-free atmosphere and depressurize the device for at least two minutes.

**Note****Quality of natural gas**

Only use natural gas which is clean, dry and free from additives.

## 7.2 Overview

**Note**

- During the initialization process, the operating pressure must be at least one bar more than that required to close or open the valve. However, the operating pressure should not be greater than the maximum permissible operating pressure for the actuator.

### General information about commissioning

1. After installing the positioner on a pneumatic actuator, you must supply electric and pneumatic auxiliary power to it.
2. The positioner is in the "P manual mode" before initialization. At the same time, "NOINI" blinks in the lower line of the display.
3. Position feedback: You can adjust the range of position detection using the friction clutch if necessary.
4. Adjust the positioner as per the respective actuator with the help of the initialization process and by setting the parameters. If required, use the "PRST" parameter to cancel the adjustment of the positioner on the actuator. The positioner is again in the "P manual mode" after this process.

### Types of initialization

You can initialize the positioner as follows:

- Automatic initialization:  
during automatic initialization, the positioner determines the following one after the other:
  - The direction of action
  - The actuator travel and angle of rotation
  - The travel time of the actuator

The positioner also adjusts the control parameters as per the dynamic response of the actuator.

- Manual initialization:  
the actuator travel and the angle of rotation of the actuator are set manually. The remaining parameters are automatically determined. This function is useful for valves which are lined, for example, with PTFE.
- Copying the initialization data when replacing a positioner:  
the initialization data of a positioner can be read and copied into another positioner. A defective device can thus be replaced without interrupting an ongoing process through initialization.

You have to define a few parameters for the positioner before initialization. Owing to the preset values, you cannot adjust further parameters for initialization.

You can use a suitably configured and activated binary input to protect the configured settings against accidental adjustment.

### See also

Overview of operating modes (Page 100)

## 7.3 Sequence of automatic initialization


### Overview

The automatic initialization takes place in the following phases:


Automatic initialization phase	Description
Start	-
RUN 1	Establishing the direction of action.
RUN 2	Checking the actuator travel and trimming the lower and upper endstops.
RUN 3	Establishing and displaying the travel time (leakage test)
RUN 4	Minimization of controller increments
RUN 5	Optimization of the transient response
End	-

The following structured charts describe the sequence of initialization. The "Up/Down" names indicate the direction of action of actuators.


#### Linear actuator



#### Part-turn actuator




This structured chart describes the process to establish the direction of action.






This structured chart describes the sequence for checking the actuator travel. It also contains information about the sequence for trimming the lower and upper endstops.




7.3 Sequence of automatic initialization


This structured chart describes the process to determine the actuator travel checks. It also contains information about the sequence for trimming the lower and upper endstops.



This structured chart describes:

- Establishing and displaying the travel time/leakage in RUN 3
- Minimization of controller increments in RUN 4
- Optimization of the transient response in RUN 5





## 7.4 Setting the friction clutch



### Introduction

It has a friction clutch and a switchable gear (Page 50) so that the positioner can be used with different mechanical part-turn and linear actuators. Use the friction clutch to adjust the position detection area. For positioners in non-flameproof enclosures, you also have the option of locking the friction clutch.

### Condition

- The positioner is mounted.

## Procedure

In non-flameproof enclosure	In flameproof enclosure Ex d
	
<ol style="list-style-type: none"> <li>1. Adjust the working area to your application by turning the adjustment wheel of the friction clutch ①.</li> <li>2. Fasten the friction clutch. Insert a standard approx. 4 mm wide screwdriver in the friction clutch gear latch ②.</li> <li>3. Use the screwdriver to turn the friction clutch gear latch ② counterclockwise ③ until it engages. The friction clutch ① is locked.</li> </ol>	<ol style="list-style-type: none"> <li>1. With the positioner in the flameproof enclosure, the friction clutch is on the outside of the device. Attach a pin to the friction clutch ①.</li> <li>2. Adjust the working area to your application by turning the adjustment wheel of the friction clutch ①.</li> </ol> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• It is not possible to lock the friction clutch.</li> <li>• Do not open the screws on the friction clutch.</li> </ul>


## See also

Sequence of automatic initialization (Page 111)

## 7.5 Purge air switching

When the enclosure is open, the purge air switch above the pneumatic terminal strip on the pneumatic block can be accessed.

- In the IN position, the enclosure is flushed from inside with a small volume of clean and dry instrument air.
- In the OUT position, the purge air is directly directed towards outside.



- ① Purging air selector
- ② Pneumatic connections Y1, PZ and Y2

Figure 7-1 Purge air switch on the pneumatic block; view of the positioner on the pneumatic connection side when the cover is open

The factory setting is the "IN" position.

## 7.6 Commissioning linear actuators

### 7.6.1 Preparing linear actuators for commissioning

#### Condition

You have already installed the positioner using the suitable mounting kit.

#### Setting the transmission ratio selector

---

#### Note

#### Commissioning

The setting of the transmission ratio selector is extremely important to commission the positioner.

---

Stroke [mm]	Position of the transmission ratio selector
5 to 20	33°
25 to 35	90°
40 to 130	90°

## Connecting the positioner

1. Connect a suitable current or voltage source. The positioner is now in "P manual mode". The current potentiometer voltage (P) in percent is shown in the upper line of the display, e.g.: 'P37.5', and 'NOINI' flashes in the bottom line:



2. Connect the actuator and the positioner to the pneumatic lines.
3. Supply the pneumatic auxiliary power to the positioner.

## Setting the actuator

1. Check whether the mechanical unit can be moved freely in the entire travel range. Move the actuator to the respective end position for this purpose using the  $\triangle$  or  $\nabla$  button.

---

### Note

#### End position

By simultaneously pressing the  $\triangle$  and  $\nabla$  buttons, you reach the end position faster.

---

2. Now move the actuator to the horizontal position of the lever.
3. A value between 'P48.0' and 'P52.0' is shown on the display.
4. If a value beyond this value range is shown on the display, you must move the friction clutch. Move the friction clutch until a value between 'P48.0' and 'P52.0' is reached. The closer this value is to 'P50.0', the more accurately the positioner determines the stroke travel.

---

### Note

#### For device versions with flameproof enclosure

The inner friction clutch is fixed. Therefore, only move the outer friction clutch. This also applies when using an internal NCS module.

#### The following applies to device versions without flameproof enclosure with internal NCS module 6DR4004-5L.:

The inner friction clutch has no function. This means you should only adjust the adjustment wheel of the magnet clamp; see section "Internal NCS modules (iNCS) 6DR4004-5L and -5LE (Page 70)". Condition: The '1.YFCT' type of actuator (Page 142) parameter is set.

---

## See also

Mounting to linear actuator (Page 42)

Device components (Page 28)

Installing the optional modules (Page 53)

## 7.6.2 Automatic initialization of linear actuators

### Conditions

The following conditions must be fulfilled before activating the automatic initialization:


1. The actuator spindle can be moved completely.
2. The actuator spindle is at a central position after moving.

### Initializing the linear actuator automatically

---


#### Note

##### Interrupting initialization


An ongoing initialization can be interrupted at any time. To do this, press . The settings configured until then are retained.


All parameters are reset to factory settings only if you have explicitly activated the preset settings in the "PRST" parameter.

---

1. Switch to the "Configuration" mode. To do this, keep the  button pressed for at least 5 seconds. The display shows the following:





2. Call the "2.YAGL" parameter. To do this, press . The following is shown on the display depending on the setting:



3. Check whether the value displayed in the "2.YAGL" parameter matches the setting of the transmission ratio selector. If required, change the setting of the transmission ratio selector to 33° or 90°.





4. Set the "3.YWAY" parameter to determine the total stroke in mm. The setting of parameter 3 is optional. The display shows the determined total stroke only at the end of the initialization phase.
  - Press the  button if you do not require any information about the total stroke in mm. You are then directed to parameter 4.
  - Call the "3.YWAY" parameter. To do this, press . The display shows the following:





---


**Note**
**Set the "3.YWAY" parameter**

Proceed as follows to set parameter 3:

1. On the scale of the lever, read the value marked by the carrier pin.
  2. Set the parameter with the buttons  and  to the read value.
- 

5. Call the "4.INITA" parameter. To do this, briefly press the  button. The display shows the following:



6. Start the initialization process. To do this, keep the  button pressed for at least 5 seconds until the display shows the following:



The positioner runs through five initialization steps during the automatic initialization process. Displays for the initialization steps from "RUN 1" to "RUN 5" are shown in the lower line on the display. The initialization process depends on the actuator used, and takes up to 15 minutes.

7. The following display indicates that the automatic initialization is complete:


**See also**

Sequence of automatic initialization (Page 111)

### 7.6.3 Manual initialization of linear actuators


You can use this function to initialize the positioner without needing to move the actuator to the lower and upper endstops. The lower and upper endstops of the actuator travel are set manually. When the control parameters are optimized, the further initialization process runs automatically.

#### Conditions


The following conditions must be fulfilled before activating manual initialization:


1. The positioner has been prepared for using on linear actuators.
2. The actuator spindle can be moved completely.
3. The displayed potentiometer position is within the permissible range between "P5.0" and "P95.0".

#### Initializing the linear actuator automatically



1. Switch to the "Configuration" mode. To do this, press the  button for at least 5 seconds until the display shows the following:



2. Call the "2.YAGL" parameter. To do this, briefly press the  button. The following is shown on the display depending on the setting:






3. Check whether the value displayed of the "2.YAGL" parameter matches with the setting of the transmission ratio selector. If required, change the setting of the transmission ratio selector to 33° or 90°.

4. Set the "3.YWAY" parameter to determine the total stroke in mm. The setting of the "3.YWAY" parameter is optional. The display shows the determined total stroke only at the end of the initialization phase.
  - Briefly press the  button if you do not require any information about the total stroke in mm. You are then directed to parameter 4.
  - Call the "3.YWAY" parameter. To do this, briefly press the  button. The display shows the following:


**Note****Set the "3.YWAY" parameter**

To set the "3.YWAY" parameter proceed as follows:

1. On the scale of the lever, read the value marked by the carrier pin.
2. Set the parameter to the read value with the  or  button.

5. Call the "5.INITM" parameter. To do this, press the  button twice. The display shows the following:






6. Start the initialization process. To do this, press the  button for at least 5 seconds until the display shows the following:



The current potentiometer position is output on the display after 5 seconds. Examples of the displayed potentiometer positions are given below:



7. Determine the lower endstop of the actuator spindle.
8. Move the actuator to the desired position using the  or  button.

- 9. Press the  button. The current position of the actuator is applied. The display shows the following:










---

**Note**

**Fault message "RANGE"**

The selected end position is beyond the permissible measuring range if the "RANGE" message is output on the display. Correct the settings as follows:




1. Move the friction clutch until the display shows "OK".
  2. Press the  button.
  3. Move the actuator to another position using the  or  button.
  4. Abort the manual initialization process by pressing the  button.
  5. Then return to "P manual mode".
  6. Correct the actuator travel and the position detection.
- 
- 10. Determine the upper endstop of the actuator spindle. Move the actuator to the desired position using the  or  button.
  - 11. Press the  button. The current position of the actuator is applied.

---

**Note**

**Fault message "Set Middl"**

The lever arm is not in the horizontal position if the "Set Middl" message is output on the display. To correct the fault, set the reference point of the sine correction. Proceed as follows:

1. Move the lever arm to the horizontal position using the  or  button.
  2. Press the  button.
- 
- 12. The initialization process is automatically resumed. Initialization steps "RUN 1" to "RUN 5" are output in the bottom line of the display. The following is displayed when the initialization has been completed successfully:



---

**Note**

**Total stroke**

If the "3.YWAY" parameter has been set, the display shows the total stroke in mm.

---

## 7.7 Commissioning part-turn actuators

### 7.7.1 Preparing part-turn actuators for commissioning

---

#### Note

##### Setting of the adjustment angle

The usual adjustment angle for part-turn actuators is 90°.

- Set the transmission ratio selector in the positioner to 90°.
- 

#### Condition

The following conditions must be fulfilled before activating the initialization:

1. You have installed the positioner for the part-turn actuators using the suitable mounting kit.
2. You have connected the actuator and the positioner to the pneumatic lines.
3. Pneumatic auxiliary power is supplied to the positioner.
4. The positioner has been connected to a suitable power supply.

#### Setting the actuator

1. The positioner is in the "P manual mode". The current potentiometer voltage P in percent is shown on the upper line in the display. "NOINI" blinks in the lower line of the display. Examples of corresponding displays are given below:



2. Check whether the mechanical unit can be moved freely in the entire travel range. Move the drive to the respective end position for this purpose using the  $\blacktriangle$  or  $\blacktriangledown$  button.

---

#### Note

##### End position

By simultaneously pressing the  $\blacktriangle$  and  $\blacktriangledown$  buttons, you reach the end position faster.

---

3. After checking, move the actuator to a central position. This accelerates the initialization process.

## 7.7.2 Automatic initialization of part-turn actuators

### Condition

The following conditions must be fulfilled before activating the automatic initialization:


1. The travel range of the actuator can be passed through completely.
2. The actuator shaft is at a central position.

### Initializing the part-turn actuator automatically

---


#### Note

##### Interrupting initialization


An ongoing initialization can be interrupted at any time. To do this, press . The settings configured until then are retained.

All parameters are reset to factory settings only if you have explicitly activated the preset settings in the "PRST" parameter.


---

1. Switch to the "Configuration" mode. To do this, press the  button for at least 5 seconds until the display shows the following:




2. Use the  button to change from linear actuator to part-turn actuator until the display shows the following:




3. Call the "2.YAGL" parameter. To do this, briefly press the  button. This parameter has already been set to 90° automatically. The display shows the following:



4. Call the "4.INITA" parameter. To do this, briefly press the  button. The display shows the following:



5. Start the initialization process. To do this, press the  button for at least 5 seconds until the display shows the following:



The positioner runs through five initialization steps during the automatic initialization process. Displays for the initialization steps from "RUN 1" to "RUN 5" are shown in the lower line on the display. The initialization process depends on the actuator used, and takes up to 15 minutes.

6. The following display indicates that the automatic initialization is complete. The total angle of rotation of the actuator is shown on the upper line on the display:



### See also

Sequence of automatic initialization (Page 111)

### 7.7.3 Manual initialization of part-turn actuators

You can use this function to initialize the positioner without needing to move the actuator to the lower and upper endstops. The lower and upper endstops of the actuator travel are set manually. When the control parameters are optimized, the further initialization process runs automatically.

### Conditions

The following conditions must be fulfilled before activating manual initialization:

1. The positioner has been prepared for using on part-turn actuators.
2. The actuator can be moved completely.
3. The displayed potentiometer position is within the permissible range between "P5.0" and "P95.0".

---


#### Note

#### Setting of the adjustment angle


The usual adjustment angle for part-turn actuators is 90°. Accordingly set the transmission ratio selector in the positioner to 90°.

---


### Initializing the positioner manually


1. Switch to the "Configuration" mode. To do this, press the  button for at least 5 seconds until the display shows the following:




2. Set the "YFCT" parameter to "turn". To do this, press . The display shows the following:




3. Call the second parameter "YAGL". To do this, press . The display shows the following:



4. Call the "INITM" parameter. To do this, press the  button twice. The display shows the following:





5. Start the initialization process. Press the  button for at least 5 seconds until the display shows the following:




6. The current potentiometer position is output on the display after 5 seconds:



7. Determine the lower endstop of the actuator.
8. Move the actuator to the desired position using the  or  button.



9. Press the  button. The current position of the actuator is applied. The display shows the following:











---

#### Note


##### Fault message "RANGE"



The selected end position is beyond the permissible measuring range if the "RANGE" message is output on the display. Correct the settings as follows:

1. Move the friction clutch until the display shows "OK".
  2. Press the  button.
  3. Move the actuator to another position using the  or  button.
  4. Abort the manual initialization process by pressing the  button.
  5. Then return to "P manual mode".
  6. Correct the actuator travel and the position detection.
- 
10. Determine the upper endstop of the actuator. Move the actuator to the desired position using the  or  button.
11. Press the  button. The current position of the actuator is applied.
12. The initialization process is automatically resumed. Initialization steps "RUN 1" to "RUN 5" are output in the bottom line of the display. The following display indicates that the initialization has been completed successfully:



## 7.8 Canceling initialization

1. Press the  button.
  - Canceling automatic initialization: the display shows "INITA".
  - Canceling manual initialization: the display shows "INITM".

The positioner is in the "Configuration" mode.
2. Exit the "Configuration" mode. To do this, press the  button for at least 5 seconds. The software version is displayed. After releasing the  button, the positioner is in "P manual mode". The positioner is not initialized.

## 7.9 Device replacement

### Introduction

---

**Note****Initialization**

The positioner can be replaced without having to interrupt ongoing processes. However, copying and transferring of the initialization parameters only allows an approximate adjustment of the positioner to your actuator. Following initialization, the positioner initially works with the manually defined parameters.

- For this reason, an automatic or manual initialization should be carried out as soon as possible.
- 

**Note****Deferred initialization**

Initialize the new positioner as soon as possible. The following properties can be ensured only after initializing:

- Optimum adjustment of the positioner as per the mechanical and dynamic properties of the actuator.
  - Non-deviating position of endstops
  - Correctness of the maintenance data
- 

There are two ways of replacing a positioner when the equipment is in operation, without having to interrupt the process. The two options depend on whether your positioner has communication.

### First possibility - with communication

1. Read the initialization parameters from the previous positioner. Use the parameter assignment tools suitable for this purpose.
2. Transfer the initialization parameters read in the parameterization software under Point 1 into the new positioner.
3. Fix the actuator at its current position mechanically or pneumatically. Use the locking function of your mounting kit, if available.
4. Determine the actual position value. To do this, read the actual position value from the display of the previous positioner. Note down the read value.
5. Dismount the previous positioner from the actuator.
6. Attach the lever arm of the previous positioner to the new positioner.
7. Mount the new positioner on the actuator.
8. Set the transmission ratio selector of the new positioner to the same position as that of the previous positioner.
9. If the displayed actual position value differs from the noted value, correct the deviation by moving the friction clutch.

10. The new positioner is ready for operation when the displayed and noted values match.
11. Release the fixing of the actuator.

### Second possibility - without communication

1. Fix the actuator at its current position mechanically or pneumatically. Use the locking function of your mounting kit, if available.
2. Determine the actual position value. To do this, read the actual position value on the display of the previous positioner. Note down the read value.


---

#### Note

##### Electronics defect

If the positioner's electronics is defective, measure the actual position value with a ruler or protractor at the actuator or valve. Convert the read value into %. Note down the converted value.

---

3. Dismount the previous positioner from the actuator.
4. Attach the lever arm of the previous positioner to the new positioner.
5. To prevent interference with the ongoing process, initialize the new positioner on an actuator with a similar stroke or swivel range. Attach the new positioner to this actuator. Initialize the new positioner.
6. Then dismount the new, initialized positioner from this actuator.
7. Mount the new, initialized positioner on the fixed actuator.
8. If the displayed actual position value differs from the noted value, correct the deviation by moving the friction clutch.
9. Use the buttons on the positioner to enter the parameters which deviate from the factory setting, such as type of actuator or tight closing.
10. Change to the measured value view using the  button, see section "Description of operating modes (Page 102)".
11. Release the fixing of the actuator.



# Parameter assignment

## 8.1 Introduction to parameter assignment section

A positioner is responsible for controlling a valve and for monitoring the status of a valve. The parameters described in this section are used to optimally adapt the positioner to the valve and its application.

The parameters are divided into initialization parameters, application parameters, and the extended diagnostics parameters.

- Initialization parameters 1 to 5 (Page 142): Describes die parameters which are relevant for initial commissioning of the positioner on the valve. For example, you can start the automatic initialization here.
- Application parameters 6 to 55 (Page 145): Describes die parameters with which the positioner is adapted to the valve application, for example tight closing at the stops.
- Extended diagnostics parameters A to P (Page 163): Describes the diagnostics functions which are provided by the positioner. These include monitoring of leakages as well as the partial stroke test. Following activation of these functions, the positioner continuously monitors the status of the valve. If you enter thresholds in the parameters of the diagnostics functions, the positioner actively signals high or low violation of these thresholds. The current monitoring state for these thresholds is displayed as a diagnostic value. For additional details on diagnostics and diagnostic values, refer to the section Diagnostics (Page 256).

The following configuration schematic shows the principle of operation of the parameters. This is followed by a tabular overview of the parameters. Finally, the individual parameters and their functionality are described.

Furthermore, the positioners with HART, PA and FF communication interface in combination with a host system, e.g. SIMATIC PDM or HART communicator etc., offer the following advantages:

- Offline tests such as full stroke test, step response test, multi-step response test and valve performance test.
- Diagnostics cockpit which provides an overview of the state of positioner and valve.
- Logbook with time stamp for documentation of all events such as the violation of thresholds.
- Wizards which provide prompting through the relevant parameters during commissioning, the partial stroke test as well as the offline test.

## 8.2 Tabular overview of the parameters

### 8.2.1 Overview of initialization parameters 1 to 5

#### Introduction

Parameters 1 to 5 are the same for all versions of the positioner. These parameters are used to adjust the positioner to the actuator. Normally, setting these parameters is sufficient to be able to operate the positioner on an actuator.

If you want to get to know all details of the positioner, gradually try out the effects of the remaining parameters by systematic testing.

#### Note

Factory-set parameter values are printed in bold in the following table.

#### Overview

Parameter	Function	Parameter values		Unit
1.YFCT	Type of actuator	Normal	Inverted	
	Part-turn actuator	turn	-turn	
	Linear actuator	<b>WAY</b>	-WAY	
	Linear actuator - carrier pin on actuator spindle	FWAY	-FWAY	
	Linear actuator - external linear potentiometer (e.g. with cylinder drives)	LWAY	-LWAY	
	Part-turn actuator with NCS/iNCS	ncSt	-ncSt	
	Linear actuator with NCS	ncSL	-ncSL	
	Linear actuator with NCS/iNCS and lever	ncSLL	-ncLL	
2.YAGL	Rated angle of rotation of positioner shaft <sup>1)</sup>	<b>33°</b>		Degrees
		90°		
3.YWAY <sup>2)</sup>	Range of stroke (optional setting) <sup>3)</sup>	<b>OFF</b>		mm
		5   10   15   20 (Short lever 33°, range of stroke 5 mm to 20 mm)		
		25   30   35 (Short lever 90°, range of stroke 25 mm to 35 mm)		
		40   50   60   70   90   110   130 (Long lever 90°, range of stroke 40 mm to 130 mm)		
4.INITA	Initialization (automatic)	<b>NOINI</b>   no / ###.#   Strt		
5.INITM	Initialization (manual)	<b>NOINI</b>   no / ###.#   Strt		

1)	Set the transmission ratio selector accordingly.
2)	Parameter only appears with "WAY", "-WAY", "ncSLL", and "-ncLL"
3)	If used, the value on the actuator must correspond to the set range of stroke on the lever arm. Carrier must be set to the value of the actuator travel or, if this value is not scaled, to the next larger scale value.

**See also**

Commissioning (Page 107)

**8.2.2 Overview of application parameters 6 to 55****Introduction**

These parameters are used to configure the following additional functions of the positioner:

- Setpoint preparation
- Actual value preparation
- Binary signal processing
- Tight closing function
- Limit detection

**Note**

Factory-set parameter values are printed in bold in the following table.

**Overview**

Parameter	Function	Parameter values	Unit
6.SDIR	Setpoint direction		
	Rising	<b>riSE</b>	
	Falling	<b>FALL</b>	
7.TSUP	Setpoint ramp up	Auto / <b>0</b> ... 400	s
8.TSDO	Setpoint ramp down	<b>0</b> ... 400	s

8.2 Tabular overview of the parameters

Parameter	Function		Parameter values	Unit	
9.SFCT	Setpoint function				
	Linear			<b>Lin</b>	
		Equal percentage	1 : 25	1 - 25	
			1 : 33	1 - 33	
	1 : 50		1 - 50		
	Inverse equal percentage	25 : 1	n1 - 25		
		33 : 1	n1 - 33		
		50 : 1	n1 - 50		
Freely adjustable			FrEE		
10.SLO ... 30.SL20 <sup>1)</sup>	Setpoint turning point				
10.SLO	At	0 %	0 ... 100.0	%	
11.SL1 ....		5 % ...			
29.SL19		95 %			
30.SL20		100 %			
31.DEBA	Deadband of closed-loop controller		<b>Auto</b> / 0.1 ... 10.0	%	
32.YA	Start of manipulated variable limit		<b>0.0</b> ... 100.0	%	
33.YE	End of the manipulated variable limit		0.0 ... <b>100.0</b>	%	
34.YNRM	Standardization of manipulated variable				
		To mechanical travel	<b>MPOS</b>		
		To flow	FLoW		
35.YDIR	Direction of action of manipulated variable for display and position feedback				
		Rising	<b>riSE</b>		
		Falling	FALL		
36.YCLS	Tight closing/fast closing with manipulated variable				
		None	<b>no</b>		
		Tight closing Up	uP		
		Tight closing Down	do		
		Tight closing Up and Down	uP do		
		Fast closing Up	Fu		
		Fast closing Down	Fd		
		Fast closing Up and Down	Fu Fd		
		Tight closing Up and fast closing Down	uP Fd		
	Fast closing Up and tight closing Down	Fu do			
37.YCDO	Value for fast closing/tight closing Down		<b>0.0</b> ... 100.0	%	
38.YCUP	Value for fast closing/tight closing Up		0.0 ... <b>100.0</b>	%	



Parameter	Function	Parameter values		Unit
39.BIN1 <sup>2)</sup>	Function binary input 1	NO contact	NC contact	
	None	OFF		
	Message only	on	-on	
	Block configuration	bloc1		
	Block configuring and manual operation	bloc2		
	Move valve to position YE	uP	-uP	
	Move valve to position YA	doWn	-doWn	
	Block movement	StoP	-StoP	
40.BIN2 <sup>2)</sup>	Function binary input 2	NO contact	NC contact	
	None	OFF		
	Message only	on	-on	
	Move valve to position YE	uP	-uP	
	Move valve to position YA	doWn	-doWn	
	Block movement	StoP	-StoP	
	Partial stroke test	PST	-PST	
41.AFCT <sup>3)</sup>	Alarm function	Normal	Inverted	
	None	OFF		
	A1 = Min, A2 = Max	$\overline{A1} \overline{A2}$	$\overline{A1} A2$	
	A1 = Min, A2 = Min	$\overline{A1} \overline{A2}$	$\overline{A1} A2$	
	A1 = Max, A2 = Max	$A1 A2$	$\overline{A1} \overline{A2}$	
42.A1	Response threshold, alarm 1	0.0 ... 10.0 ... 100		%
43.A2	Response threshold, alarm 2	0.0 ... 90.0 ... 100		%
44. <sup>4)</sup> FCT <sup>3)</sup>	Fault message function	Normal	Inverted	
	Fault	$\overline{F}$	$F$	
	Fault + not automatic <sup>4)</sup>	$\overline{F} \overline{A}$	$\overline{F} A$	
	Fault + not automatic + BIN <sup>4)</sup>	$\overline{F} \overline{A} B$	$\overline{F} A B$	
45. <sup>4)</sup> TIM	Monitoring period for setting the fault message 'Control deviation'	Auto / 0 ... 100		s
46. <sup>4)</sup> LIM	Response threshold of fault message 'Control deviation'	Auto / 0 ... 100		%
47. <sup>4)</sup> STRK	Limit monitoring for the number of total strokes	0 ... 1.00E9		
48.PRST	Preset			
	Reset all parameters which can be reset by 'Init', 'PArA' and 'diAg'.	ALL		
	Reset initialization parameters '1.YFCT' to '5.INITM'.	Init		
	Reset parameters '6.SDIR' to '47. <sup>4)</sup> STRK' and '51.FSTY' to '53.FSVL'.	PArA		
	Reset parameters A to P of the extended diagnostics function as well as parameter '50.XDIAG'.	diAg		

8.2 Tabular overview of the parameters

Parameter	Function	Parameter values	Unit	
49.PNEUM	Pneumatics type			
		Standard pneumatic block		<b>Std</b>
		Fail in place pneumatic block		FIP
		Operation with boosters		booSt
50.XDIAG	Activation of extended diagnostics			
		Off		<b>OFF</b>
		Single stage message		On1
		Two stage message		On2
		Three stage message		On3
51.FSTY	Safety position			
		Parameterized safety setpoint		FSVL
		Last setpoint		FSSP
		Open vent valve		<b>FSAC</b>
52.FSTI	Monitoring period for setting the safety setting	<b>0 ... 100</b>	s	
53.FSVL	Safety setpoint	<b>0.0 ... 100.0</b>	%	
54.STNR	Station number	<b>0 ... 126</b>		
55.IDENT	Device operating mode (ID No.)			
		Vendor-independent profile ID number		9710
		Device-spec. ID number for full functionality		8079
		Automatic adaptation by the control system		<b>AdAPT</b>

- 1) Setpoint turning points only appear when '9.SFCT = FrEE' is selected.
- 2) 'Normally closed' means: Operation when a switch is open or Low level  
'Normally open' means: Action on switch closed or High level
- 3) 'Normal' means: High level, no fault message  
'Inverted' means: Low level, no fault message
- 4) '+' means: Logical OR combination

### 8.2.3 Overview of advanced diagnostics parameters A to P

#### Introduction

These parameters are used to set the extended diagnostics functions of the positioner.

---

#### Note

#### Factory setting

Factory-set parameter values are printed in bold in the following table.

---

**Note****Display**

Parameters A to P and their sub-parameters are only displayed when the extended diagnostics has been activated in parameter "'50.XDIAG' Activation of extended diagnostics (Page 160)" with setting "On1", "On2" or "On3".

**Overview parameter A**

Parameter	Function	Parameter values	Unit
A.4PST	Partial stroke test with the following parameters:		
A1.STPOS	Start position	0.0 ... <b>100.0</b>	%
A2.STTOL	Start tolerance	0.1 ... <b>2.0</b> ... 10.0	%
A3.STRKH	Stroke height	0.1 ... <b>10.0</b> ... 100.0	%
A4.STRKD	Stroke direction	uP / do / uP do	
A5.RPMD	Ramp mode	<b>OFF</b> / On	
A6.RPRT	Ramp rate	0.1 ... <b>1.0</b> ... 100.0	%/s
A7.FLBH	Behavior after failed PST	<b>Auto</b> / HOLD / AirIn / AirOu	
A8.INTRV	Test interval	<b>OFF</b> / 1 ... 365	Days
A9.PSTIN	Reference stroke time for partial stroke test	<b>NOINI</b> / (C)##.# / FdInI / rEAL	s
AA.FACT1	Factor 1	0.1 ... <b>1.5</b> ... 100.0	
Ab.FACT2	Factor 2	0.1 ... <b>3.0</b> ... 100.0	
AC.FACT3	Factor 3	0.1 ... <b>5.0</b> ... 100.0	

**Overview parameter b**

Parameter	Function	Parameter values	Unit
b.4DEVI	Monitoring of dynamic control valve behavior with the following parameters:		
b1.TIM	Time constant	<b>Auto</b> / 1 ... 400	s
b2.LIMIT	Limit	0.1 ... <b>1.0</b> ... 100.0	%
b3.FACT1	Factor 1	0.1 ... <b>5.0</b> ... 100.0	
b4.FACT2	Factor 2	0.1 ... <b>10.0</b> ... 100.0	
b5.FACT3	Factor 3	0.1 ... <b>15.0</b> ... 100.0	

**Overview parameter C**

Parameter	Function	Parameter values	Unit
C.4LEAK	Monitoring/compensation of pneumatic leakage with the following parameters:		
C1.LIMIT	Limit	0.1 ... <b>30.0</b> ... 100.0	%
C2.FACT1	Factor 1	0.1 ... <b>1.0</b> ... 100.0	
C3.FACT2	Factor 2	0.1 ... <b>1.5</b> ... 100.0	
C4.FACT3	Factor 3	0.1 ... <b>2.0</b> ... 100.0	

**Overview parameter d**

Parameter	Function	Parameter values	Unit
d.↳STIC	Monitoring of stiction (slipstick) with the following parameters:		
d1.LIMIT	Limit	0.1 ... <b>1.0</b> ... 100.0	%
d2.FACT1	Factor 1	0.1 ... <b>2.0</b> ... 100.0	
d3.FACT2	Factor 2	0.1 ... <b>5.0</b> ... 100.0	
d4.FACT3	Factor 3	0.1 ... <b>10.0</b> ... 100.0	

**Overview parameter E**

Parameter	Function	Parameter values	Unit
E.↳DEBA	Monitoring of deadband with the following parameters:		
E1.LEVL3	Threshold	0.1 ... <b>2.0</b> ... 10.0 *)	%

\*) The values are monitored in the range of '0.1' to '2.9'. Values between '3.0' and '10.0' are not monitored.

**Overview parameter F**

Parameter	Function	Parameter values	Unit
F.↳ZERO	Monitoring of lower endstop with the following parameters:		
F1.LEVL1	Threshold 1	0.1 ... <b>1.0</b> ... 10.0	%
F2.LEVL2	Threshold 2	0.1 ... <b>2.0</b> ... 10.0	
F3.LEVL3	Threshold 3	0.1 ... <b>4.0</b> ... 10.0	

**Overview parameter G**

Parameter	Function	Parameter values	Unit
G.↳OPEN	Monitoring of upper endstop with the following parameters:		
G1.LEVL1	Threshold 1	0.1 ... <b>1.0</b> ... 10.0	%
G2.LEVL2	Threshold 2	0.1 ... <b>2.0</b> ... 10.0	
G3.LEVL3	Threshold 3	0.1 ... <b>4.0</b> ... 10.0	

**Overview parameter H**

Parameter	Function	Parameter values	Unit
H.↳TMIN	Monitoring of lower limit temperature with the following parameters:		
H1.TUNIT	Temperature unit	°C      °F	°C/°F
H2.LEVL1	Threshold 1	-40 ... <b>-25</b> ... 90      -40 ... 194	
H3.LEVL2	Threshold 2	-40 ... <b>-30</b> ... 90      -40 ... 194	
H4.LEVL3	Threshold 3	<b>-40</b> ... 90      -40 ... 194	

### Overview parameter J

Parameter	Function	Parameter values		Unit
J.↳TMAX	Monitoring of upper limit temperature with the following parameters:			
J1.TUNIT	Temperature unit	°C	°F	°C/°F
J2.LEVL1	Threshold 1	-40 ... <b>75</b> ... 90	-40 ... 194	
J3.LEVL2	Threshold 2	-40 ... <b>80</b> ... 90	-40 ... 194	
J4.LEVL3	Threshold 3	-40 ... <b>90</b>	-40 ... 194	

### Overview parameter L

Parameter	Function	Parameter values		Unit
L.↳STRK	Monitoring of number of total strokes with the following parameters:			
L1.LIMIT	Limit	1 ... <b>1E6</b> ... 1E8		
L2.FACT1	Factor 1	0.1 ... <b>1.0</b> ... 40.0		
L3.FACT2	Factor 2	0.1 ... <b>2.0</b> ... 40.0		
L4.FACT3	Factor 3	0.1 ... <b>5.0</b> ... 40.0		

### Overview parameter O

Parameter	Function	Parameter values		Unit
O.↳DCHG	Monitoring of number of changes in direction with the following parameters:			
O1.LIMIT	Limit	1 ... <b>1E6</b> ... 1E8		
O2.FACT1	Factor 1	0.1 ... <b>1.0</b> ... 40.0		
O3.FACT2	Factor 2	0.1 ... <b>2.0</b> ... 40.0		
O4.FACT3	Factor 3	0.1 ... <b>5.0</b> ... 40.0		

### Overview parameter P

Parameter	Function	Parameter values		Unit
P.↳PAVG	Monitoring of position average value with the following parameters:			
P1.TBASE	Time basis of average value generation	0.5h / 8h / 5d / 60d / 2.5y		
P2.STATE	Status of monitoring of position average value	IdLE / rEF / ###.# / Strt		
P3.LEVL1	Threshold 1	0.1 ... <b>2.0</b> ... 100.0		%
P4.LEVL2	Threshold 2	0.1 ... <b>5.0</b> ... 100.0		%
P5.LEVL3	Threshold 3	0.1 ... <b>10.0</b> ... 100.0		%

## 8.3 Description of parameters

### 8.3.1 Initialization parameters 1 to 5

#### 8.3.1.1 '1.YFCT' type of actuator

Requirement:	Type of actuator as well as mounting type and direction of action are known.	
Possible settings:	Actuator with normal direction of action	Actuator with inverted direction of action
	<ul style="list-style-type: none"> <li>• turn</li> <li>• WAY</li> <li>• FWAY</li> <li>• LWAY</li> <li>• ncSt</li> <li>• ncSL</li> <li>• ncSLL</li> </ul>	<ul style="list-style-type: none"> <li>• -turn</li> <li>• -WAY</li> <li>• -FWAY</li> <li>• -LWAY</li> <li>• -ncSt</li> <li>• -ncSL</li> <li>• -ncLL</li> </ul>
Purpose:	<p>Use this parameter to adjust the positioner to the respective actuator.</p> <ul style="list-style-type: none"> <li>• turn/-turn: Use this setting for a part-turn actuator with a directly mounted positioner.</li> <li>• WAY/-WAY: Use this setting. <ul style="list-style-type: none"> <li>– For a linear actuator with a carrier pin mounted on the lever.</li> <li>– In conjunction with devices which use an internal potentiometer.</li> </ul> </li> <li>• FWAY/-FWAY: Use this setting. <ul style="list-style-type: none"> <li>– For a linear actuator with a carrier pin mounted on the actuator spindle.</li> <li>– In conjunction with devices which use an internal potentiometer.</li> </ul> </li> <li>• LWAY/-LWAY: Use this setting for an external linear potentiometer on a linear actuator (e.g. with cylinder drives).</li> <li>• ncSt/-ncSt: Use this setting for a part-turn actuator for: <ul style="list-style-type: none"> <li>– An NCS sensor 6DR4004-. N.10 and -.N.40</li> <li>– A positioner 6DR5...-0..9.-....- L1A with internal NCS module</li> <li>– A positioner 6DR59* with accessory NCS module 6DR4004-5L/-5LE</li> <li>– External position detection systems 6DR4004-2ES, -3ES and -4ES</li> <li>– Internal NCS module</li> </ul> </li> <li>• ncSL/-ncSL: Use this setting for an NCS sensor 6DR4004-.N.20 on a linear actuator for strokes &lt; 14 mm (0.55 inch).</li> </ul>	

- ncSLL/-ncLL: Use this setting for a linear actuator for:
  - An NCS sensor 6DR4004-.N.30 for strokes > 14 mm (0.55 inch).
  - A positioner 6DR5...-0..9.-....- L1A with internal NCS module
  - A positioner 6DR59\* with accessory NCS module 6DR4004-5L/-5LE
  - External position detection systems 6DR4004-2ES, -3ES and -4ES
  - An internal NCS module. No limitations apply to the internal NCS module.

In the case of actuators with inverted direction of action, use the settings with the minus sign, e.g. -turn.

Description:

**Meaning of actuator with normal direction of action:**

- Part-turn actuator closes when the drive shaft, positioner shaft or magnet of the NCS sensor rotates in the **clockwise** direction.
- Linear actuator closes when the actuator spindle moves downwards and the positioner shaft or magnet of the NCS sensor rotates in the **anti-clockwise** direction.

**Meaning for actuator with inverted direction of action:**

- Part-turn actuator closes when the drive shaft, positioner shaft or magnet of the NCS sensor rotates in the **anti-clockwise** direction.
- Linear actuator closes when the actuator spindle moves downwards and the positioner shaft or magnet of the NCS sensor rotates **clockwise**.

**Additional information:**

- The '3.YWAY' Range of stroke (Page 144) parameter is displayed only for 'WAY', '-WAY', 'ncSLL' or '-ncLL'.
- turn/-turn: The '2.YAGL' Rated angle of rotation of feedback (Page 143) parameter is automatically set to 90° and cannot be changed.
- WAY/-WAY: The positioner compensates the non-linearity. The non-linearity is caused by the transformation of the linear movement of the linear actuator into the rotary movement of the positioner shaft. For correct compensation see section "Preparing linear actuators for commissioning (Page 118)".

Factory setting:

WAY

### 8.3.1.2 '2.YAGL' Rated angle of rotation of feedback

Condition:

Transmission ratio selector and the value set in the '2.YAGL' parameter match. Only then does the value shown on the display match the actual position.

Possible settings:

- 33°
- 90°

8.3 Description of parameters

Purpose:	<p>Use this parameter for a linear actuator. For a linear actuator, set an angle of 33° or 90° depending on the range of stroke. The current setting of the actuator is then measured more accurately. The following is applicable:</p> <ul style="list-style-type: none"> <li>• 33°: Strokes ≤ 20 mm</li> <li>• 90°: Strokes 25 mm to 35 mm</li> <li>• 90°: Strokes &gt; 40 mm to 130 mm</li> </ul> <p>Use the mounting kit:</p> <ul style="list-style-type: none"> <li>• 6DR4004-8V for strokes up to 35 mm</li> <li>• 6DR4004-8L for strokes greater than 35 mm up to 130 mm</li> </ul> <p>'2.YAGL' can only be adjusted if '1.YFCT' is set to 'WAY'/'-WAY' or 'FWAY'/'-FWAY'.</p> <p>With all other settings of '1.YFCT', an angle of 90° is automatically set for '2.YAGL'.</p>
Factory setting:	33°

**See also**


Sequence of automatic initialization (Page 111)

**8.3.1.3 '3.YWAY' Range of stroke**



Condition:	<ul style="list-style-type: none"> <li>• Positioner is mounted.</li> <li>• Carrier pin is mounted on the lever in accordance with the actuator's range of stroke as described in section Mounting to linear actuator (Page 42).</li> </ul>
Possible settings:	<ul style="list-style-type: none"> <li>• OFF</li> <li>• 5.0   10.0   15.0   20.0   25.0   30.0   35.0   40.0   50.0   60.0   70.0   90.0   110.0   130.0</li> </ul>
Purpose:	<p>Use this parameter to display the determined stroke value in mm when initialization of a linear actuator has been completed.</p> <p>If you select the 'OFF' setting, the real stroke is not displayed after initialization.</p> <p>From the possible settings shown above, select the value which corresponds to the range of stroke of your actuator in mm.</p> <p>If the range of stroke of the actuator does not correspond to a possible setting, use the next higher value. Use the value specified on the nameplate of the actuator for this purpose.</p> <p>'3.YWAY' is only displayed if '1.YFCT' is set to 'WAY'/'-WAY' or 'ncSLL'/'-ncLL'.</p>
Factory setting:	OFF



### 8.3.1.4 '4.INITA' Initialization (automatically)

Possible settings:	<ul style="list-style-type: none"> <li>• NOINI</li> <li>• no / ###.#</li> <li>• Strt</li> </ul>
Purpose:	<p>Use this parameter to start the automatic initialization process.</p> <ol style="list-style-type: none"> <li>1. Select the "Strt" setting.</li> <li>2. Then press the  button for at least 5 seconds.</li> </ol> <p>The sequence of the initialization process from "RUN 1" to "RUN 5" is output in the bottom line of the display.</p>
Factory setting:	NOINI

### 8.3.1.5 '5.INITM' Initialization (manual)

Possible settings:	<ul style="list-style-type: none"> <li>• NOINI</li> <li>• no / ###.#</li> <li>• Strt</li> </ul>
Purpose:	<p>Use this parameter to start the manual initialization process.</p> <ol style="list-style-type: none"> <li>1. Select the "Strt" setting.</li> <li>2. Then press the  button for at least 5 seconds.</li> </ol>
Description:	<p>If the positioner has already been initialized and if the "4.INITA" and "5.INITM" values are set, it is possible to reset the positioner to the non-initialized status. To do this, press the  button for at least 5 seconds.</p>
Factory setting:	NOINI

## 8.3.2 Application parameters 6 to 55

### 8.3.2.1 '6.SDIR' Setpoint direction


Possible settings:	<ul style="list-style-type: none"> <li>• riSE</li> <li>• FALL</li> </ul>
Purpose:	<p>This parameter is used to set the setpoint direction. The setpoint direction is used to reverse the direction of action of the setpoint.</p> <ul style="list-style-type: none"> <li>• Rising (riSE): A higher value at the setpoint input results in opening of the valve.</li> <li>• Falling (FALL): A higher value at the setpoint input results in closing of the valve.</li> </ul> <p>The setpoint direction is primarily used for the split-range mode and for single-acting actuators with the safety setting 'uP'.</p>
Factory setting:	riSE



Valve characteristics		Set with parameter value
Inverse equal percentage	25:1	n1-25
Inverse equal percentage	33:1	n1-33
Inverse equal percentage	50:1	n1-50
Freely adjustable		FrEE

### 8.3.2.4 '10.SL0' ... '30.SL20' Setpoint turning point

Adjustment range: 0.0 ... 100.0  
 Purpose: These parameters are used to assign a flow coefficient in units of 5% to each setpoint turning point. The setpoint turning points form a polyline with 20 linear segments which models the valve characteristic; see figure below.  
 Factory setting: 0, 5 ... 95, 100



Setpoint characteristic curves, standardization of manipulated variables, and tight closing function

Input of the setpoint turning points is only possible if the "9.SFCT" Setpoint function (Page 146)" parameter is set to "FrEE". You can only enter one monotone rising characteristic curve and two consecutive interpolation points must differ by at least 0.2%.



### 8.3.2.7 '34.YNRM' Manipulated variable standardization

Possible settings:

- MPOS
- FLoW

Purpose:

Use the '32.YA' Manipulated variable limiting Start / '33.YE' Manipulated variable limiting End (Page 148) parameters to limit the manipulated variable. This limitation causes two different scaling types 'MPOS' and 'FLoW' for the display and for the position feedback through the current output.

The MPOS scale shows the mechanical positions from 0% to 100% between the upper and lower endstops of the initialization. The position is not influenced by the '32.YA' Manipulated variable limiting Start / '33.YE' Manipulated variable limiting End (Page 148) parameters. The 'YA' and 'YE' parameters are shown in the MPOS scale.

The FLoW scale is the standardization from 0% to 100% in the range between the 'YA' and 'YE' parameters. Over this range, the setpoint is also always 0% to 100%. This results in a more or less flow-proportional display and position feedback. The flow-proportional display and position feedback also results from the use of valve characteristics.

In order to calculate the control deviation, the setpoint in the display is also shown in the corresponding scale.

The following uses the example of an 80-mm linear actuator to illustrate the dependence of the stroke on the scaling as well as on the 'YA' and 'YE' parameters; see the following figure.

Factory setting:

MPOS




Figure 8-1 YNRM = MPOS or YNRM = FLoW; default: YA = 0 % and YE = 100 %

8.3 Description of parameters




Figure 8-2 Example: YNRM = MPOS with YA = 10 % and YE = 80 %




Figure 8-3 Example: YNRM = FLoW with YA = 10 % and YE = 80 %

8.3.2.8 '35.YDIR' Direction of action of manipulated variable for display and position feedback

Possible settings: 

- riSE
- FALL

Purpose: This parameter is used to set the direction of action of the display and the position feedback. The direction can be rising or falling.

Factory setting: riSE

8.3.2.9 '36.YCLS' Tight closing/fast closing with manipulated variable

Possible settings:

no	None
uP	Tight closing Up
do	Tight closing Down
uP do	Tight closing Up and Down
Fu	Fast closing Up
Fd	Fast closing Down
Fu Fd	Fast closing Up and Down
uP Fd	Tight closing Up and fast closing Down
Fu do	Fast closing Up and tight closing Down

Purpose:	<p>This parameter is used to drive the control valve to the mechanical stops. If the parameter is not activated, the control valve controls the two positions which were determined during the initialization.</p> <p>With tight closing, the control valve requires longer to leave the stops. With fast closing, the stops of the control valve are left immediately.</p> <p>The tight closing and fast closing functions are activated on one side or for both stops. Parameter 'YCLS' becomes effective if the effective setpoint:</p> <ul style="list-style-type: none"> <li>• Is at or below the value set in the '37.YCDO' Value for tight closing/fast closing Down (Page 151)' parameter.</li> <li>• Is at or above the value set in the '38.YCUP' Upper value for tight closing / fast closing (Page 152)' parameter.</li> </ul>
Factory setting:	no
See the figure in the description of the '34.YNRM' Manipulated variable standardization (Page 149) parameter and the figure in the description of the '10.SL0' ... '30.SL20' Setpoint turning point (Page 147) parameters.	

**Note****Activated tight closing/fast closing function**

If the function is activated, then the monitoring of control deviation is turned off in the respective overflow direction for the '46.LLIM' Response threshold of fault message 'Control deviation' (Page 157)' parameter. The following applies: 'YCDO: < 0 %' and 'YCUP: > 100 %'. This functionality is especially advantageous for valves with lining. For long-term monitoring of the position of the stops, we recommend that you activate the 'F.4ZERO' and 'G.4OPEN' parameters.

**8.3.2.10 '37.YCDO' Value for tight closing/fast closing Down**

Requirement:	Parameter '36.YCLS (Page 150)' is set to 'do', 'uP do', 'Fd', 'Fu Fd', 'uP Fd' or 'Fu do'
Adjustment range:	0.0 ... 100.0
Purpose:	Use the parameter '37.YCDO' to set the value as of which the "Tight closing/fast closing Down" function is activated. If the effective setpoint is at or below the value set here, the actuator moves in tight closing Down or fast closing Down.
Factory setting:	0.0

**Note**

The value in the parameter "37.YCDO" is always smaller than that in "38.YCUP (Page 152)". The tight closing function has a fixed hysteresis of 1%. The parameter "37.YCDO" refers to the mechanical stops. "37.YCDO" is independent of the value that is set in the parameters "6.SDIR (Page 145)" and "35.YDIR (Page 150)".

**8.3.2.11 '38.YCUP' Value for tight closing/fast closing Up**

Requirement:	Parameter '36.YCLS (Page 150)' is set to 'uP', 'uP do', 'Fu', 'Fu Fd', 'uP Fd' or 'Fu do'
Adjustment range:	0.0 ... 100.0
Purpose:	Use the parameter '38.YCUP' to set the value as of which the tight closing Up or fast closing Up is activated. If the effective setpoint is at or above the value set here, the actuator moves in tight closing Up or fast closing Up.
Factory setting:	100.0

---

**Note**

The value in the parameter "37.YCDO (Page 151)" is always smaller than that in "38.YCUP". The tight closing function has a fixed hysteresis of 1%. The parameter "38.YCUP" refers to the mechanical stops. "38.YCUP" is independent of the value that is set in the parameters "6.SDIR (Page 145)" and "35.YDIR (Page 150)".

---

**8.3.2.12 '38.YCUP' Upper value for tight closing / fast closing**

Requirement:	' 36.YCLS' Tight closing/fast closing with manipulated variable (Page 150) Parameter is set to 'do', 'uP do', 'Fd', 'Fu Fd', 'uP Fd' or 'Fu do'
Adjustment range:	0.0 ... 100.0
Purpose:	Use the 'YCUP' parameter to set the value as of which the tight closing Up or fast closing Up is activated. If the effective setpoint is at or above the value set here, the actuator moves in tight closing Up or fast closing Up.
Factory setting:	99.5

---

**Note**

The value in the 'YCDO' parameter is always smaller than that in 'YCUP'. The tight closing/fast closing function has a fixed hysteresis of 1%. The 'YCUP' parameter is relative to the mechanical stops. The 'YCUP' is independent of the values set in the '6.SDIR' Setpoint direction (Page 145) and '35.YDIR' Direction of action of manipulated variable for display and position feedback (Page 150) parameters.

---



## 8.3.2.13 '39.BIN1' / '40.BIN2' Function of binary inputs

Setting option

- Binary input 1

**Normally open**

OFF  
on  
bloc1  
bloc2  
uP  
doWn  
StoP  
PST

**Normally closed**

OFF  
-on  
-uP  
-doWn  
-StoP  
-PST

- Binary input 2

**Normally open**

OFF  
on  
uP  
doWn  
StoP  
PST

**Normally closed**


OFF  
-on  
-uP  
-doWn  
-StoP  
-PST

Purpose:

These parameters determine the function of the binary inputs. The possible functions are described below. The direction of action can be adapted to a normally closed or normally open mode.

- BIN1 or BIN2 = On or -On  
Binary messages from peripherals, e.g. from pressure or temperature switches, are read over the communication interface or fed through a logical OR combination with other messages to trigger the error message output.
- BIN1 = bLoc1  
Use this parameter value to interlock the "Configuration" mode against adjustment. The lock is performed e.g. with a jumper between terminals 9 and 10.
- BIN1 = bLoc2  
If binary input 1 has been activated, the "Manual" as well as "Configuration" modes are blocked.
- BIN1 or BIN2 =  
contact uP or doWn closes, or  
contact -uP or -doWn opens  
If the binary input is activated, the actuator uses the value defined by the "'32.YA' Manipulated variable limiting Start / '33.YE' Manipulated variable limiting End (Page 148)" parameter for controlling in "Automatic" mode.
- BIN1 or BIN2 contact closes = StoP or -StoP contact opens  
In "Automatic" mode, the piezo valves are blocked when the binary input is activated. The actuator remains at the last position. Leakage measurements can be performed in this way without using the initialization function.

8.3 Description of parameters

- BIN1 or BIN2 = PSt or -PSt  
Using binary inputs 1 or 2, a partial-stroke test can be triggered by actuation of your choice of a normally closed or normally open switch.
- BIN1 or BIN2 = OFF  
No function  
Special function of binary input 1: If binary input 1 is activated in "P-manual mode" by means of a jumper between terminals 9 and 10, the firmware version is displayed when the button  is pressed.

If one of the above functions is activated simultaneously with the "BIN1" and "BIN2" parameters, then: "Blocking" has priority over "uP". "uP" has priority over "doWn". "doWn" has priority over "PST".

Factory setting: OFF

**8.3.2.14 '41.AFCT' Alarm function**

Possible settings: See representation below

Purpose: This parameter can be used to determine the value at which going above or below a given offset or angle will result in a message. The triggering of alarms (limits) is relative to the MPOS scale. Alarms are signaled through the alarm module. In addition, alarms can also be read via the communication interface.

The direction of action of the binary outputs can be adjusted from "High active" to "Low active" for the next system.

Factory setting: OFF

Direction of action and hysteresis		
Limit	Alarm module	
	A1	A2
	<b>Examples</b>	
	A1 = 48	
	A2 = 52	AFCT = MIN / MAX
	Way = 45	<b>Active</b>
	Way = 50	
	Way = 55	<b>Active</b>
	A1 = 48	
	A2 = 52	AFCT = -MIN / -MAX
	Way = 45	<b>Active</b>
	Way = 50	Active
	Way = 55	<b>Active</b>
	A1 = 52	
	A2 = 48	AFCT = MIN / MAX
	Way = 45	<b>Active</b>
	Way = 50	Active
	Way = 55	<b>Active</b>
	A1 = 52	
	A2 = 48	AFCT = -MIN / -MAX
	Way = 45	<b>Active</b>
	Way = 50	
	Way = 55	<b>Active</b>

**Note**

If the extended diagnostic is activated using parameter "'50.XDIAG' Activation of extended diagnostics (Page 160)" with setting "On3", then the alarms are not output through the alarm module. Alarm A1 is output with setting "On2". However, notification via the communication interface is possible at any time.

**8.3.2.15 '42.A1' / '43.A2' Alarm response threshold**

Adjustment range:	0.0 ... 100.0	
Purpose:	These parameters are used to specify when an alarm should be displayed. The response thresholds of the alarms (in percent) refer to the MPOS scale in the '34.YNRM' Manipulated variable standardization (Page 149) parameter. The MPOS scale corresponds to the mechanical travel. Depending on the setting of the alarm function in the '41.AFCT' Alarm function (Page 154) parameter, the alarm is triggered upon an upward violation (Max) or downward violation (Min) of this response threshold.	
Factory setting:	With 'A1': 10.0	With 'A2': 90.0

**8.3.2.16 '44.\FCT' Function fault message**

Condition:	At least one of the following modules is fitted	
	<ul style="list-style-type: none"> <li>• Alarm module</li> <li>• Slot initiator alarm module (SIA module)</li> <li>• Mechanical limit switch module</li> </ul>	
Possible settings:	Normal direction of action	Inverted direction of action
	<ul style="list-style-type: none"> <li>• 4</li> <li>• 4nA</li> <li>• 4nAb</li> </ul>	<ul style="list-style-type: none"> <li>• -4</li> <li>• -4nA</li> <li>• -4nAb</li> </ul>
Purpose:	<p>The fault message in the form of monitoring of control deviation over time can also be triggered due to the following events:</p> <ul style="list-style-type: none"> <li>• Power failure</li> <li>• Processor fault</li> <li>• Actuator fault</li> <li>• Valve fault</li> <li>• Compressed air failure</li> <li>• Threshold 3 message of extended diagnostics. See parameter '50.XDIAG' Activation of extended diagnostics (Page 160).</li> </ul> <p>The fault message cannot be switched off, but it can be suppressed (factory setting) when you exit 'Automatic' mode. Set the '4FCT' parameter to '4nA' to also generate a fault message here.</p> <p>You also have an option to "or" the fault message with the status of the binary inputs. To do this, first set the '39.BIN1' / '40.BIN2' Function of binary inputs (Page 153) parameter to 'on' or '-on'. Subsequently set the '4FCT' parameter to '4nAb'.</p> <p>Select the '-4' setting if you want the fault message to be output with inverted direction of action.</p>	
Factory setting:	4	

### 8.3.2.17 '45.\TIM' Monitoring time for setting of fault message 'Control deviation'

Possible settings:	<ul style="list-style-type: none"><li>• Auto</li><li>• 0 ... 100</li></ul>
Purpose:	The 'TIM' parameter is used to set the time in seconds within which the positioner must have reached the regulated condition. The corresponding response threshold is specified in the parameter. When the configured time is exceeded, the fault message output is set.
Factory setting:	Auto

---

#### Note

##### Activated tight closing/fast closing function

If the function is activated, then for the 'LIM' parameter the monitoring of control deviation is turned off in the appropriate overflow direction. The following applies: 'YCD0: < 0 %' and 'YCUP: > 100 %'. This functionality is especially advantageous for valves with lining. For long-term monitoring of the end positions, we recommend that you activate the 'F.LZERO' and 'G.LOPEN' parameters.

---

### 8.3.2.18 '46.\LIM' Response threshold of fault message 'Control deviation'

Possible settings:	<ul style="list-style-type: none"><li>• Auto</li><li>• 0 ... 100</li></ul>
Purpose:	This 'LIM' parameter is used to set a value for the permissible size of the control deviation to trigger a fault message. The value is given in percent. If the 'TIM' and 'LIM' parameters are set to 'Auto', then the fault message is set if the slow step zone is not reached within a certain period of time. Within 5 to 95% of the actuator travel, this time is twice the initialization travel time, and ten times the initialization travel time outside of 10 to 90%.
Factory setting:	Auto

---

#### Note

##### Activated tight closing/fast closing function

If the function is activated, then for the 'LIM' parameter the monitoring of control deviation is turned off in the appropriate overflow direction. The following applies: 'YCD0: < 0 %' and 'YCUP: > 100 %'. This functionality is especially advantageous for valves with lining. For long-term monitoring of the end positions, we recommend that you activate the 'F.LZERO' and 'G.LOPEN' parameters.

---

**8.3.2.19 '47.\STRK' Limit monitoring for the number of total strokes**

Possible settings:	0 ... 1.00E9
Purpose:	Use this parameter to set a limit for the number of total strokes. This parameter corresponds to the profile parameter 'TOTAL_VALVE_TRAVEL_LIMIT' and was applied for compatibility reasons.
Description:	If the configured limit is exceeded, the 'CB_TOT_VALVE_TRAV' bit is set in the profile parameter 'CHECK_BACK'. This function enables preventive maintenance of the control valve.
Factory setting:	1E9

**See also**

Monitoring of number of total strokes 'L.\STRK' (Page 182)

'50.XDIAG' Activation of extended diagnostics (Page 160)

Diagnostic value '1.STRKS - Number of total strokes' (Page 259)

**8.3.2.20 '48.PRST' Preset**


Possible settings:	<ul style="list-style-type: none"> <li>• ALL</li> <li>• Init</li> <li>• PArA</li> <li>• diAg</li> </ul>
Purpose:	<p>Use this parameter to restore the factory settings for most parameters. The following parameter groups are available:</p> <ul style="list-style-type: none"> <li>• ALL: Reset all parameters together which can be reset by 'Init', 'PArA' and 'diAg'.</li> <li>• Init: Reset initialization parameters '1.YFCT' to '5.INITM'.</li> <li>• PArA: Reset parameters '6.SDIR' to '47.\STRK' and '51.FSTY' Safety position (Page 161) to '53.FSVL' Safety setpoint (Page 162).</li> <li>• diAg: Reset parameters A to P of the extended diagnostics function as well as parameter '50.XDIAG'.</li> </ul>

An overview of the parameters and factory settings can be found in section Tabular overview of the parameters (Page 134).

In order to select one of the parameter groups listed above, repeatedly press the ▾ button until the desired setting is output in the display. Start the function by keeping the ▲ button pressed until 'oCAY' is output in the display. The values of the parameter group are now the factory settings.

Description:	If you wish to use a previously initialized positioner on a different control valve, set the parameters to the factory settings prior to a new initialization. To do this, use the 'ALL' or 'Init' setting. Restore the factory settings if you have changed several parameters at once without being able to predict their effect and the undesired reactions which may occur as a result. To do this, use the 'ALL' setting.
Factory setting:	ALL

### 8.3.2.21 '49.PNEUM' Pneumatics type

Requirements:	FIP	You have a positioner with the "Fail in place" function with order suffix -Z, order code F01.
Possible settings:	booSt	You operate the positioner with a booster.
	Std	Standard pneumatic block
	FIP	Fail in place pneumatic block
	booSt	Operation with boosters
Purpose:		Start the function by pressing the  button for at least 5 seconds. The display shows 'WAit' during these 5 seconds. Set the desired function after 5 seconds.
	Std	Setting for a standard pneumatic block
	FIP	If you order a positioner for Fail in Place applications, it is then equipped with a special pneumatic block. The "PNEUM" parameter is preset to "FIP". The parameter must be set to "FIP" again when the basic electronics are replaced.
	booSt	Use this function if you operate the positioner with a booster. This function then shows the actuator overshoot. You can find a description of how to operate the booster under Booster (Page 339).

### 8.3.2.22 '50.XDIAG' Activation of extended diagnostics

Use this parameter to activate the extended diagnostics functions and simultaneously the online diagnostics. You also define which maintenance level is to be signaled. Maintenance levels in the order of increasing importance are maintenance required, maintenance demanded, maintenance alarm. At the factory, extended diagnostics are deactivated. 'XDIAG' parameter is set to 'OFF'. To activate extended diagnostics, there are three modes available:

- On1: Extended diagnostics is activated. Threshold 3 messages will be output via the error message output. Single stage message (maintenance alarm).
- On2: Extended diagnostics is activated. Threshold 2 messages will be activated via alarm output 2. Threshold 3 messages will also be output via the error message output. Two-stage message (maintenance demanded, maintenance alarm).
- On3: Extended diagnostics is activated. Threshold 1 messages will be activated via alarm output 1. Threshold 2 messages will be activated via alarm output 2. Threshold 3 messages will also be output via the error message output. Three-stage message (maintenance required, maintenance demanded, maintenance alarm).

---

**Note**

**Activation of extended diagnostics**

Please note that the parameters of extended diagnostics from 'A.\PST' to 'P.\PAVG' will only be shown in the display following selection of one of the modes 'On1' to 'On3'.

In the factory settings, the 'A.\PST' to 'P.\PAVG' parameters are deactivated by default. 'XDIAG' parameter is set to 'OFF'. The corresponding parameters are only displayed after you have activated the appropriate menu item with 'On'.

---

**Note**

**Cancellation of messages**

If a threshold is exceeded or fallen below, the positioner outputs a message in the form of an error code and a column in the display. The message is cancelled if, for example:

- The counter is reset.
- The threshold is set to a new value.
- The device is re-initialized at the upper and lower endstops.
- Monitoring is deactivated.

---

With extended diagnostics, the threshold of the message is displayed using columns ① in addition to the error code ② (Overview of error codes (Page 272)). These columns ① and the error code ② are shown on the display as follows:




Figure 8-4 Display of a threshold 1 error message with one column (maintenance required)






Figure 8-5 Display of a threshold 2 error message with two columns (maintenance demanded)




Figure 8-6 Display of a threshold 3 error message with three columns (maintenance alarm)  
The factory setting is 'OFF'.

## See also

Monitoring the position average value 'P.\IPAVG' (Page 185)

### 8.3.2.23 '51.FSTY' Safety position

Possible settings:	<ul style="list-style-type: none"> <li>• FSVL</li> <li>• FSSP</li> <li>• FSAC</li> </ul>
Purpose:	Use this parameter to move the actuator to a defined safety position when communication fails.
Description:	<p>Three settings are available:</p> <ul style="list-style-type: none"> <li>• FSVL: the actuator is controlled using the configured safety setpoint. This value also becomes effective following failure of the auxiliary power supply.</li> <li>• FSSP: the actuator is controlled using the last effective setpoint.</li> <li>• FSAC: the positioner responds as described in "Reaction to failure of auxiliary powers (Page 95)."</li> </ul>
Fail in Place	<p>The following must be observed when using the "Fail in Place" function:</p> <p>The "51.FSTY" parameter must be set to "FSSP" so that the positioner retains the current position even following switching on again.</p>
Factory setting:	FSAC

### 8.3 Description of parameters

#### 8.3.2.24 '52.FSTI' Monitoring time to set the safety position

Possible settings:	0 ... 100
Purpose:	If communication fails, the positioner switches to the safety position after the set value expires. This parameter is used to set the value in seconds.
Factory setting:	0

#### 8.3.2.25 '53.FSVL' Safety setpoint

Possible settings:	0.00 ... 100
Purpose:	Default value of the safety position.
Description:	Note that the safety setpoint of 0% set here always refers to the mechanical position in which the actuator is depressurized. The mechanical position is especially important if you have set the '6.SDIR' Setpoint direction (Page 145) parameter to 'FALL' and expect 100% mechanical position at 0% setpoint default. The 'FALL' setting corresponds a declining characteristic curve of the setpoint.
Factory setting:	0.0

#### 8.3.2.26 '54.STNR' Station number

Possible settings:	0 ... 126
Purpose:	A separate station number must be set on each device in order to address the devices on the bus separately.
Factory setting:	126

#### 8.3.2.27 '55.IDENT' Device operating mode (ID No.)

Possible settings:	<ul style="list-style-type: none"><li>• 9710</li><li>• 8079</li><li>• AdAPT</li></ul>
Purpose:	The positioner identifies two device operating modes with respect to the response to the DP master of class 1: <ul style="list-style-type: none"><li>• [9710] Vendor-independent profile ID number. Can be replaced by positioners of other manufacturers complying with PROFIBUS PA profile 3.0.</li><li>• [8079] Device-specific ID number for full functionality. Complete functional range of the positioner (condition at delivery).</li><li>• AdAPT Automatic adaptation by the control system.</li></ul>

Description:	A specific GSD file is allocated to every device operating mode. If the configuration of your PROFIBUS PA path does not match the set device operating mode, the device cannot accept the cyclic data exchange. The station number and the device operating mode cannot be modified during ongoing communication with a master of class 1. A successfully established connection with a cyclic master can be detected when the positioner responds to the setpoint of the master. A blinking decimal point in the top line of the positioner display indicates communication with an acyclic master.
Factory setting:	1

**See also**

Cyclic data transfer (Page 209)

**8.3.3 Extended diagnostics parameters A to P****8.3.3.1 Partial stroke test 'A.\PST'****A.\PST - Partial Stroke Test**

Condition:	The parameter "52.XDIAG" is set to "On1", "On2" or "On3".
Possible settings:	<ul style="list-style-type: none"> <li>• OFF</li> <li>• On</li> </ul>
Purpose:	<p>Use this parameter to activate and deactivate the partial stroke test. To activate monitoring, assign the parameter value "On". Sub-parameters are displayed.</p> <p>Trigger the partial stroke test using:</p> <ul style="list-style-type: none"> <li>• Buttons on the device</li> <li>• A binary input</li> <li>• Communication</li> <li>• A cyclic test interval</li> </ul> <p>The current status of the partial stroke test is displayed in the diagnostic value "12.PST".</p> <p>Diagnostic value "13.PRPST" and "14.NXPST" provide additional information on the partial stroke test.</p>
Factory setting:	OFF

**A1.STPOS - Start position**

Adjustment range:	0.0 ... 100.0
Purpose:	Use this sub-parameter to define the start position of the partial stroke test in percent. Set the start position in a range from "0.0" to "100.0". The triggering of alarms (limits) is relative to the MPOS scale. The actuator moves during the partial stroke test from the start position to the target position. The target position is determined from the interaction between start position (A1.STPOS), stroke height (A3.STRKH) and stroke direction (A4.STRKD).
Factory setting:	100.0

**A2.STTOL - Start tolerance**

Adjustment range:	0.1 ... 10.0
Purpose:	Use this sub-parameter to assign the start tolerance of the partial stroke test in percent. Set the start tolerance relative to the start position in a range from "0.1" to "10.0".
Example:	You have set "50.0" as start position and "2.0" as start tolerance. In this case, a Partial Stroke Test is initiated during operation only between a position of 48% and 52%.
Factory setting:	2.0

**A3.STRKH - Stroke height**

Adjustment range:	0.1 ... 100.0
Purpose:	Use this sub-parameter to assign the stroke height of the partial stroke test in percent. Set the stroke height in a range from "0.1" to "100.0".
Factory setting:	10.0

**A4.STRKD - Stroke direction**

Possible settings:	<ul style="list-style-type: none"> <li>• uP</li> <li>• do</li> <li>• uP do</li> </ul>
Purpose:	Use this sub-parameter to assign the stroke direction of the partial stroke test. <b>uP:</b> Actuator only moves upward <ul style="list-style-type: none"> <li>• The actuator moves from its start position to the upper target position.</li> <li>• After reaching the upper target position, the actuator moves back to the start position.</li> </ul>

Formula (uP):	Upper target position = Start position (A1.STPOS) ± Start tolerance (A2.STTOL) + Stroke height (A3.STRKH) <b>do:</b> Actuator only moves downward <ul style="list-style-type: none"> <li>The actuator moves from its start position to the lower target position.</li> <li>After reaching the lower target position, the actuator moves back to the start position.</li> </ul>
Formula (do):	Low target position = Start position (A1.STPOS) ± Start tolerance (A2.STTOL) - Stroke height (A3.STRKH) <b>uP do:</b> Actuator moves up and down <ul style="list-style-type: none"> <li>The actuator first moves from its start position to the upper target position.</li> <li>It then moves from the upper target position to the lower target position.</li> <li>After reaching the lower target position, the actuator moves back to the start position.</li> </ul>
Formula (uP do)	Target position = Start position (A1.STPOS) ± Start tolerance (A2.STTOL) ± Stroke height (A3.STRKH)
Factory setting:	do

### A5.RPMD - Ramp mode

Setting options:	<ul style="list-style-type: none"> <li>OFF</li> <li>On</li> </ul>
Purpose:	Enable or disable ramp mode. <ul style="list-style-type: none"> <li>OFF: The partial stroke test is executed in an uncontrolled manner.</li> <li>On: The partial stroke test is executed in a controlled manner. Control is at the ramp rate set in the "A6.RPRT" parameter.</li> </ul> Use ramp mode to shorten or extend the time of the partial stroke test. Extend the partial stroke test to give the higher-level control loop a chance to react to the partial stroke test.
Factory setting:	OFF

### A6.RPRT - Ramp rate

Adjustment range:	0.1 ... 100.0
Purpose:	Change the ramp rate to shorten or extend the duration of the partial stroke test. The ramp rate refers to the total stroke of the control valve and is set in % stroke per second (%/s). Smaller values extend the duration, larger values shorten the duration of the partial stroke test. Example: Setting "10.0" means that the partial stroke test is run with 10% stroke per second.
Factory setting:	1.0

**A7.FLBH - Behavior after failed PST**


Setting options:	<ul style="list-style-type: none"> <li>• Auto</li> <li>• HOLd</li> <li>• AirIn</li> <li>• AirOu</li> </ul>
Purpose:	<p>Assign how the positioner is to respond if a partial stroke test fails. Note: A partial stroke test fails if the limit threshold assigned in "Factor 3 (AC.FACT3)" is exceeded.</p> <ul style="list-style-type: none"> <li>• Auto: Switch to "Automatic" mode. "AUT" is displayed on the device.</li> <li>• HOLd: Hold current position.</li> <li>• AirIn: Pressurize actuator with supply air PZ.</li> <li>• AirOu: Depressurize actuator.</li> </ul>
Factory setting:	Auto

**A8.INTRV - Test interval**

Adjustment range:	OFF, 1 ... 365
Purpose:	Use this sub-parameter to enter the interval time for the cyclic partial stroke test in days. Set the test interval in a range from 1 to 365.
Factory setting:	OFF

**A9.PSTIN - Reference stroke time for partial stroke test**

Indication on the display:	<ul style="list-style-type: none"> <li>• NOINI</li> <li>• (C)##.#</li> <li>• FdIni</li> <li>• rEAL</li> </ul>
Purpose:	Status for reference stroke time in seconds
Description:	<p>Use this sub-parameter to measure the reference stroke time for the partial stroke test.</p> <p>The reference stroke time corresponds to the controlled movement from the start position to the target position.</p> <p>If the positioner has already been initialized, the calculated average travel time of the control valve is displayed as a reference value.</p> <ul style="list-style-type: none"> <li>• NOINI: Positioner has not yet been initialized.</li> <li>• (C)##.#: An average travel time of 1.2 seconds, for example, is shown in the display as "C 1.2", whereby "C" stands for 'calculated'. The average travel time can be used as a reference stroke time. However, it merely represents a rough guideline value.</li> <li>• FdIni: If the starting position cannot be approached or the stroke target cannot be achieved, "FdIni" is displayed. "FdIni" stands for "failed PST initialization".</li> </ul>

- rEAL: Set the sub-parameters "A1.STPOS" to "A5.RPMD" according to your requirements. Then start measuring the reference stroke time by pressing the  button for at least 5 seconds. The display shows "rEAL" during these 5 seconds. The device then moves to the configured start position automatically and executes the desired stroke. The current position in percent is continuously shown on the display. "inPST" for "initialize partial stroke test" appears in the lower line of the display.

Factory setting: NOINI

### AA.FACT1 - Factor 1

Adjustment range: 0.1 ... 100.0

Purpose: Use this sub-parameter to assign the factor to form threshold 1. Set the factor in a range from "0.1" to "100.0". The threshold is the product of the reference stroke time and "AA.FACT1". The process to determine the reference stroke time is described under "A9.PSTIN". The threshold 1 message is displayed when threshold 1 is exceeded. This message is only output if threshold 2 or 3 is not exceeded at the same time. The process to activate and display this message is described in the "XDIAG" parameter.

Factory setting: 1.5

### Ab.FACT2 - Factor 2

Adjustment range: 0.1 ... 100.0

Purpose: Use this sub-parameter to assign the factor to form threshold 2. Set the factor in a range from "0.1" to "100.0". The threshold is the product of the reference stroke time and "Ab.FACT2". The process to determine the reference stroke time is described under "A9.PSTIN". The threshold 2 message is displayed when threshold 2 is exceeded. This message is only output if threshold 3 is not exceeded at the same time. The process to activate and display this message is described in the "XDIAG" parameter.

Factory setting: 3.0

### AC.FACT3 - Factor 3

Adjustment range:	0.1 ... 100.0
Purpose:	Use this sub-parameter to assign the factor to form threshold 3. Set the factor in a range from "0.1" to "100.0". The threshold is the product of the reference stroke time and "AC.FACT3". The process to determine the reference stroke time is described under "A9.PSTIN". The threshold 3 message is displayed when threshold 3 is exceeded. The process to activate and display this message is described in the "XDIAG" parameter. The positioner responds in accordance with the option set in the sub-parameter "A7.FLBH".
Factory setting:	5.0

#### 8.3.3.2 Monitoring of dynamic control valve behavior 'b.\DEVl'

##### b.\DEVl - Monitoring of dynamic control valve behavior

Requirement:	The '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is set to 'On1', 'On2' or 'On3'.
Possible settings:	<ul style="list-style-type: none"><li>• OFF</li><li>• On</li></ul>
Purpose:	This parameter allows you to monitor the dynamic control valve behavior. The actual position course is compared with the expected position course for this purpose. This comparison helps in drawing a conclusion about the correct operational response of the control valve. Monitoring is performed in three steps. To activate monitoring, set the parameter to 'On'. Sub-parameters are displayed. Appropriately set the sub-parameters. The current value is displayed in Diagnostics value '15.DEVI - Dynamic control valve behavior' (Page 263). The positioner triggers a message if the current value exceeds one of the three thresholds.
Factory setting:	OFF

##### b1.TIM - Time constant

Possible settings:	<ul style="list-style-type: none"><li>• Auto</li><li>• 1 ... 400</li></ul>
Purpose:	Use this sub-parameter to define the attenuation effect of the low-pass filter. The unit is seconds. The time constant 'b1.TIM' is calculated from the travel times 'uP' and 'doWn' determined during the initialization. This time constant becomes effective when the 'b1.TIM' parameter is set to 'Auto'.



If the time constant is inadequate, the setting of 'b1.TIM' can be changed manually. Set the time constant in a range from '1' to '400'. In this case:

- Setting '1' indicates a very weak attenuation.
- Setting '400' indicates a strong attenuation.

The currently determined deviation is displayed in Diagnostics value '15.DEVI - Dynamic control valve behavior' (Page 263). The positioner triggers a message if the current value exceeds one of the three parameterizable thresholds.

Factory setting: Auto

### b2.LIMIT - Limit

Adjustment range: 0.1 ... 100.0

Purpose: Use this sub-parameter to set a base limit in percent. The base limit defines the magnitude of the permissible deviation from the expected position course. The limit serves as a reference variable for the fault message factors.

Set the base limit in a range from '0.1' to '100.0'.

Factory setting: 1.0

### b3.FACT1 - Factor 1

Adjustment range: 0.1 ... 100.0

Purpose: Use this sub-parameter to set the factor for formation of threshold 1. Set the factor in a range from '0.1' to '100.0'. The threshold is the product of 'b2.LIMIT' and 'b3.FACT1'.

The threshold 1 message is displayed when threshold 1 is exceeded. This message is only output if threshold 2 or 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.

Factory setting: 5.0

### b4.FACT2 - Factor 2

Adjustment range: 0.1 ... 100.0

Purpose: Use this sub-parameter to set the factor for formation of threshold 1. Set the factor in a range from '0.1' to '100.0'. The threshold is the product of 'b2.LIMIT' and 'b4.FACT2'.

The threshold 2 message is displayed when threshold 2 is exceeded. This message is only output if threshold 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.

Factory setting: 10.0

### 8.3 Description of parameters

#### b5.FACT3 - Factor 3

Adjustment range:	0.1 ... 100.0
Purpose:	Use this sub-parameter to set the factor for formation of threshold 1. Set the factor in a range from '0.1' to '100.0'. The threshold is the product of 'b2.LIMIT' and 'b5.FACT3'. The threshold 3 message is displayed when threshold 3 is exceeded. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	15.0

#### 8.3.3.3 Monitoring/compensation of pneumatic leakage 'C.\LEAK'

##### C.\LEAK - Monitoring/compensation of pneumatic leakage

---

###### Note

###### Accuracy of results

Note that this monitoring only delivers results in the case of single-acting, spring-loaded actuators and a setpoint from 5% to 95%.

---

###### Note

###### Activated tight closing/fast closing function

Note that monitoring with an activated '36.YCLS' Tight closing/fast closing with manipulated variable (Page 150) function only delivers results in the case of a setpoint with the following values:

- Value for tight closing/fast closing **Down** (YCDO) +5% to
- value for tight closing/fast closing **Up** (YCUP) -5%

'37.YCDO' Value for tight closing/fast closing Down (Page 151)

and '38.YCUP' Upper value for tight closing / fast closing (Page 152)

---

###### Note

###### Update of the message

When the leakage has been rectified, the new status is displayed as message after some time.

- To determine the current leakage, start the online leakage test with Diagnostic value '11.LEAK - Leakage test' (Page 261).
-

Condition:	The '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is set to 'On1', 'On2' or 'On3'. Operating mode 'Automatic' (AUT) is set for the leakage compensation.
Possible settings:	<ul style="list-style-type: none"> <li>• OFF</li> <li>• On</li> </ul>
Purpose:	<p>This parameter is used to activate leak monitoring and leakage compensation. Leakages mainly occur in the actuator or in the pipe installation. To activate monitoring or compensation, set the parameter to 'On'. Sub-parameters are displayed. Appropriately set the sub-parameters.</p> <p>The <b>leakage compensation</b> compensates the leakage in control phases with constant setpoint. The control quality is increased by reducing or preventing the typical, periodic oscillations of leaky valves. The leakage compensation compensates leakages up to 2% of the positioner's air performance.</p> <p>The two following diagnostics values indicate the length and period of the current leakage compensation pulse: Diagnostics value '50.LKPUL - Length of the leakage compensation pulse' (Page 271), Diagnostics value '51.LKPER - Period of the leakage compensation pulse' (Page 271)</p> <p>The <b>leak monitoring</b> is carried out in three stages for all control phases (dynamic and static setpoints).</p> <p>The current value of the monitoring is displayed in Diagnostic value '16.ONLK - Pneumatic leakage' (Page 263).</p>
Factory setting:	OFF

## C1.LIMIT - Limit

Adjustment range:	0.1 ... 100.0
Purpose:	Use this sub-parameter to set the limit of the leakage indicator in percent. Set the limit in a range from '0.1' to '100.0'. If no leakage exists, monitoring of the pneumatic leakage is automatically calibrated in such a way during the initialization (section Commissioning (Page 107)) that the leakage indicator remains below the value 30. A value above 30 means that a leakage exists. '30.0' is therefore an advisable setting for the parameter. After a certain time this limit can be varied slightly depending on the application.

To optimize the sensitivity of the monitoring of the pneumatic leakage to your specific application, follow these steps:

1. After initializing the positioner automatically, use a calibration device to initiate a ramp movement.
2. Conditions for the ramp movement:
  - The ramp covers the normal operating range of the valve.
  - The steepness of the ramp matches the dynamic requirements of the corresponding application.
  - The characteristic of the ramp corresponds to the characteristic of the setpoint that actually occurs.
3. During the ramp movement, the Diagnostic value '16.ONLK - Pneumatic leakage' (Page 263) provides information about the actual values. Define the limit of the leakage indicator accordingly.

The positioner triggers a message if the current value exceeds one of the three thresholds. How to set the three thresholds is described below.

Factory setting: 30.0

### C2.FACT1 - Factor 1

Adjustment range: 0.1 ... 100.0

Purpose: Use this sub-parameter to set the factor for formation of threshold 1. Set the factor in a range from '0.1' to '100.0'. The threshold is the product of 'C1.LIMIT' and 'C2.FACT1'.

A leakage was detected when threshold 1 is exceeded. The control quality is not affected. The threshold 1 message is shown. This message is only output if threshold 2 or 3 is not exceeded at the same time.

The process to activate and display this message is described in the 'XDIAG' parameter.

Factory setting: 1.0

### C3.FACT2 - Factor 2

Adjustment range: 0.1 ... 100.0

Purpose: Use this sub-parameter to set the factor for formation of threshold 2. Set the factor in a range from '0.1' to '100.0'. The threshold is the product of 'C1.LIMIT' and 'C3.FACT2'.

A leakage was detected when threshold 2 is exceeded. The control quality is affected. Maintenance is recommended. The threshold 2 message is shown. This message is only output if threshold 3 is not exceeded at the same time.

The process to activate and display this message is described in the 'XDIAG' parameter.

Factory setting: 1.5

**C4.FACT3 - Factor 3**

Adjustment range:	0.1 ... 100.0
Purpose:	Use this sub-parameter to set the factor for formation of threshold 3. Set the factor in a range from '0.1' to '100.0'. The threshold is the product of 'C1.LIMIT' and 'C4.FACT3'. A leakage was detected when threshold 3 is exceeded. The control quality is strongly affected. Maintenance is necessary. The threshold 3 message is shown. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	2.0

**8.3.3.4 Monitoring of stiction (slipstick) 'd.\\$STIC'****d.\\$STIC - Monitoring of stiction (slipstick)**

Condition:	The '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is set to 'On1', 'On2' or 'On3'.
Possible settings:	<ul style="list-style-type: none"> <li>• OFF</li> <li>• On</li> </ul>
Purpose:	Use this parameter to continuously monitor the current stiction (slipstick effect) of the control valve. If the parameter is activated, the positioner detects the slipstick that can occur. Sudden changes in the valve position, so-called slip jumps, indicate excessive stiction. Where slip jumps are detected, the filtered step height is stored as a slipstick value. If slip jumps no longer exist, the stiction (slipstick effect) is reduced slowly. Monitoring is performed in three steps. To activate monitoring, set the parameter to 'On'. Sub-parameters are displayed. Appropriately set the sub-parameters. The current value is displayed in Diagnostic value '17.STIC - Stiction (slipstick)' (Page 264). The positioner triggers a message if the current value exceeds one of the thresholds.
Factory setting:	OFF

---

**Note****Incorrect interpretation in case of travel times below one second**

If the travel times are less than one second, the positioner does not accurately differentiate between a normal movement of the actuator and a sudden change. Therefore, increase the travel time if required.

---

### d1.LIMIT - limit for slipstick detection

Adjustment range:	0.1 ... 100.0
Purpose:	Use this sub-parameter to set the base limit for slipstick detection in percent. Set the base limit in a range from '0.1' to '100.0'.
Factory setting:	1.0

### d2.FACT1 - Factor 1

Adjustment range:	0.1 ... 100.0
Purpose:	Use this sub-parameter to set the factor for formation of threshold 1. Set the factor in a range from '0.1' to '100.0'. The threshold is the product of the values entered for 'd1.LIMIT' and 'd2.FACT1'. The threshold 1 message is displayed when threshold 1 is exceeded. This message is only output if threshold 2 or 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	2.0

### d3.FACT2 - Factor 2

Adjustment range:	0.1 ... 100.0
Purpose:	Use this sub-parameter to set the factor for formation of threshold 2. Set the factor in a range from '0.1' to '100.0'. The threshold is the product of the values entered for 'd1.LIMIT' and 'd3.FACT2'. The threshold 2 message is displayed when threshold 2 is exceeded. This message is only output if threshold 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	5.0

### d4.FACT3 - Factor 3

Adjustment range:	0.1 ... 100.0
Purpose:	Use this sub-parameter to set the factor for formation of threshold 3. Set the factor in a range from '0.1' to '100.0'. The threshold is the product of the values entered for 'd1.LIMIT' and 'd4.FACT3'. The threshold 3 message is displayed when threshold 3 is exceeded. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	10.0

### See also

Diagnostics value '15.DEVI - Dynamic control valve behavior' (Page 263)

### 8.3.3.5 Monitoring of deadband 'E.\DEBA'

#### E.\DEBA - Monitoring of deadband

Requirement:	The '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is set to 'On'. The '31.DEBA' Deadband of controller (Page 148) parameter is set to 'Auto'.
Possible settings:	<ul style="list-style-type: none"> <li>• OFF</li> <li>• On</li> </ul>
Purpose:	Use this parameter to continuously monitor the automatic adaptation of the deadband. Monitoring is performed in one step. To activate monitoring, set the parameter to 'On'. The sub-parameter is displayed. Appropriately set the sub-parameter. The current value is displayed in Diagnostic value '26.DBUP - Deadband up' / '27.DBDN - Deadband down' (Page 267). The positioner triggers a message if the current value exceeds the threshold.
Factory setting:	OFF

#### E1.LEVL3 - Threshold

Adjustment range:	0.1 ... 10.0
Purpose:	Use this sub-parameter to set the threshold to the deadband in percent. Set the threshold in a range from '0.1' to '2.9'. The values are monitored in the range of '0.1' to '2.9'. Values between '3.0' and '10.0' are not monitored. The threshold 3 message is displayed when the current deadband exceeds the threshold during the test. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	2.0

---

#### Note

##### Fault message display

The three-stage fault message display has not been implemented for monitoring of the deadband. The positioner triggers only threshold 3 messages depending on the setting.

---

### 8.3.3.6 Monitoring the lower endstop "F.\ZERO"

#### F.\ZERO - Monitoring of lower endstop

**Note**

**Fault detection**

Monitoring of lower endstop not only responds to faults in the valve. If the limit thresholds of the lower endstop are exceeded due to misalignment of the position feedback, the misalignment also triggers a diagnostics message.

Requirement:	The '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is set to 'On1', 'On2' or 'On3'. The '36.YCLS' Tight closing/fast closing with manipulated variable (Page 150) parameter is set to one of the following values: 'do', 'uP do', 'Fd', 'Fu Fd', 'uP Fd', 'Fu do'.
Possible settings:	<ul style="list-style-type: none"> <li>• OFF</li> <li>• On</li> </ul>
Purpose:	<p>Use this parameter to activate continuous monitoring of the lower endstop. Monitoring is always carried out if the '37.YCDO' Value for tight closing/fast closing Down (Page 151) parameter is set to one of the following values: 'do', 'uP do', 'Fd', 'Fu Fd', 'uP Fd', 'Fu do'</p> <p>It checks whether the lower endstop has changed compared to its value during initialization. Monitoring is performed in three steps. Set the following sub-parameters appropriately. To activate monitoring, set the parameter to 'On'. Sub-parameters are displayed.</p> <p>The current value is displayed in Diagnostic value '18.ZERO - Lower endstop' (Page 264). The positioner triggers a message if the current value undershoots one of the three thresholds.</p>
Factory setting:	OFF

#### F1.LEVL1 - threshold 1

Adjustment range:	0.1 ... 10.0
Purpose:	<p>Use this sub-parameter to set threshold 1 for the lower endstop in percent. Set the threshold in a range from '0.1' to '10.0'.</p> <p>The positioner triggers a threshold 1 message if the difference between the lower endstop and the initialization value undershoots threshold 1. This message is only output if threshold 2 or 3 is not undershot at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.</p>
Factory setting:	1.0



## F2.LEVL2 - threshold 2

Adjustment range:	0.1 ... 10.0
Purpose:	Use this sub-parameter to set threshold 2 for the lower endstop in percent. Set the threshold in a range from '0.1' to '10.0'. The positioner triggers a threshold 2 message if the difference between the lower endstop and the initialization value undershoots threshold 2. This message is only output if threshold 3 is not undershot at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	2.0

## F3.LEVL3 - threshold 3

Adjustment range:	0.1 ... 10.0
Purpose:	Use this sub-parameter to set threshold 3 for the lower endstop in percent. Set the threshold in a range from '0.1' to '10.0'. The positioner triggers a threshold 3 message if the difference between the lower endstop and the initialization value undershoots threshold 3. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	4.0

### 8.3.3.7 Monitoring the upper endstop 'G.\\OPEN'

#### G.\\OPEN - Monitoring of upper endstop

---

##### Note

##### Fault detection

Monitoring of upper endstop not only responds to faults in the valve. If the limit thresholds of the upper endstop are exceeded due to misalignment of the position feedback, the misalignment also triggers a message.

---

Requirement:	The '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is set to 'On1', 'On2' or 'On3'. The '36.YCLS' Tight closing/fast closing with manipulated variable (Page 150) parameter is set to one of the following values: 'uP', 'uP do', 'Fu', 'Fu Fd', 'uP Fd', 'Fu do'
Possible settings:	<ul style="list-style-type: none"><li>• OFF</li><li>• On</li></ul>

8.3 Description of parameters

**Purpose:** Use this parameter to activate continuous monitoring of the upper endstop. Monitoring is always carried out if the '38.YCUP' Upper value for tight closing / fast closing (Page 152) parameter is set to one of the following values: 'uP', 'uP do', 'Fu', 'Fu Fd', 'uP Fd', 'Fu do'. It checks whether the upper endstop has changed compared to its value during initialization. Monitoring is performed in three steps. Set the following sub-parameters appropriately. To activate monitoring, set the parameter to 'On'. Sub-parameters are displayed. The value is displayed in Diagnostic value '19.OPEN - Upper endstop' (Page 264). The positioner triggers a message if the current value exceeds one of the three thresholds.

**Factory setting:** OFF

**G1.LEVL1 - threshold 1**

**Adjustment range:** 0.1 ... 10.0

**Purpose:** Use this sub-parameter to set threshold 1 for the upper endstop in percent. Set the threshold in a range from '0.1' to '10.0'. The positioner triggers a threshold 1 message if the difference between the upper endstop and the initialization value exceeds threshold 1. This message is only output if threshold 2 or 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.

**Factory setting:** 1.0

**G2.LEVL2 - threshold 2**

**Adjustment range:** 0.1 ... 10.0

**Purpose:** Use this sub-parameter to set threshold 2 for the upper endstop in percent. Set the threshold in a range from '0.1' to '10.0'. The positioner triggers a threshold 2 message if the difference between the upper endstop and the initialization value exceeds threshold 2. This message is only output if threshold 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.

**Factory setting:** 2.0

**G3.LEVL3 - threshold 3**

Adjustment range:	0.1 ... 10.0
Purpose:	Use this sub-parameter to set threshold 3 for the upper endstop in percent. Set the threshold in a range from '0.1' to '10.0'. The positioner triggers a threshold 3 message if the difference between the upper endstop and the initialization value exceeds threshold 3. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	4.0

**8.3.3.8 Monitoring the lower limit temperature 'H.\\TMIN'****H.\\TMIN - Monitoring the lower limit temperature**

Requirement:	The '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is set to 'On1', 'On2' or 'On3'.
Possible settings:	<ul style="list-style-type: none"> <li>• OFF</li> <li>• On</li> </ul>
Purpose:	The current temperature inside the enclosure of the field device is recorded by a sensor on the basic electronics. Use this parameter to activate continuous monitoring of the lower limit temperature inside the enclosure. Monitoring is performed in three steps. To activate monitoring, set the parameter to 'On'. Sub-parameters are displayed. Appropriately set the sub-parameters. The value is displayed in Diagnostic value '31.TMIN - Minimum temperature' / '32.TMAX - Maximum temperature' (Page 268). The positioner triggers a message if the current value undershoots one of the three thresholds.
Factory setting:	OFF

**H1.TUNIT - temperature unit**

Possible settings:	°C °F
Purpose:	Use this sub-parameter to set the temperature unit '°C' or '°F'. The selected temperature unit is then also applicable for all other temperature-based parameters.
Factory setting:	°C

**H2.LEVL1 - threshold 1**

Adjustment range:	-40.0C ... 90.0C -40.0F ... 194.0F
Purpose:	Use this sub-parameter to set the temperature for threshold 1. The positioner triggers a threshold 1 message if the current temperature inside the enclosure undershoots threshold 1. This message is only output if threshold 2 or 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	-25.0C

**H3.LEVL2 - threshold 2**

Adjustment range:	-40.0C ... 90.0C -40.0F ... 194.0F
Purpose:	Use this sub-parameter to set the temperature for threshold 2. The positioner triggers a threshold 2 message if the current temperature inside the enclosure undershoots threshold 2. This message is only output if threshold 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	-30.0C

**H4.LEVL3 - threshold 3**

Adjustment range:	-40.0C ... 90.0C -40.0F ... 194.0F
Purpose:	Use this sub-parameter to set the temperature for threshold 3. The positioner triggers a threshold 3 message if the current temperature inside the enclosure undershoots threshold 3. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	-40.0C

**8.3.3.9 Monitoring the upper limit temperature 'J.\TMAX'****J.\TMAX - Monitoring the upper limit temperature**

Requirement:	The '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is set to 'On1', 'On2' or 'On3'.
Possible settings:	<ul style="list-style-type: none"> <li>• OFF</li> <li>• On</li> </ul>

Purpose:	The current temperature inside the enclosure of the field device is recorded by a sensor on the basic electronics. Use this parameter to activate continuous monitoring of the upper limit temperature inside the enclosure. Monitoring is performed in three steps. To activate monitoring, set the parameter to 'On'. Sub-parameters are displayed. Appropriately set the sub-parameters. The value is displayed in Diagnostic value '31.TMIN - Minimum temperature' / '32.TMAX - Maximum temperature' (Page 268). The positioner triggers a message if the current value exceeds one of the three thresholds.
Factory setting:	OFF

### J1.TUNIT - temperature unit

Possible settings:	°C °F
Purpose:	Use this sub-parameter to set the temperature unit '°C' or '°F'. The selected temperature unit is then also applicable for all other temperature-based parameters.
Factory setting:	°C

### J2.LEVL1 - threshold 1

Adjustment range:	-40.0C ... 90.0C -40.0F ... 194.0F
Purpose:	Use this sub-parameter to set the temperature for threshold 1. The positioner triggers a threshold 1 message if the current temperature inside the enclosure exceeds threshold 1. This message is only output if threshold 2 or 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	75.0C

### J3.LEVL2 - threshold 2

Adjustment range:	-40.0C ... 90.0C -40.0F ... 194.0F
Purpose:	Use this sub-parameter to set the temperature for threshold 2. The positioner triggers a threshold 2 message if the current temperature inside the enclosure exceeds threshold 2. This message is only output if threshold 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	80.0C

**J4.LEVL3 - threshold 3**

Adjustment range:	-40.0C ... 90.0C -40.0F ... 194.0F
Purpose:	Use this sub-parameter to set the temperature for threshold 3. The positioner triggers a threshold 3 message if the current temperature inside the enclosure exceeds threshold 3. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	90.0C

**8.3.3.10 Monitoring of number of total strokes 'L.\STRK'****L.\STRK - Monitoring of number of total strokes**

Condition:	The '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is set to 'On1', 'On2' or 'On3'.
Possible settings:	<ul style="list-style-type: none"> <li>• OFF</li> <li>• On</li> </ul>
Purpose:	Use this parameter to continuously monitor the total strokes covered by the actuator. A total stroke corresponds to the path from the lower endstop of the actuator to the upper endstop and back again, in other words twice the travel. During operation, partial strokes of the actuator are added together into total strokes. Monitoring is performed in three steps. To activate monitoring, set the parameter to 'On'. Sub-parameters are displayed. Appropriately set the sub-parameters.  The current value is displayed in Diagnostic value '1.STRKS - Number of total strokes' (Page 259). The positioner triggers a message if the current value exceeds one of the three thresholds. This message is only output if threshold 2 or 3 is not exceeded at the same time.
Factory setting:	OFF

**L1.LIMIT - Limit**

Adjustment range:	1 ... 1.00E8
Purpose:	Use this sub-parameter to set the base limit for the number of total strokes. Set the base limit in a range from '1' to '1.00E8'.
Factory setting:	1.00E6

### L2.FACT1 - Factor 1

Adjustment range:	0.1 ... 40.0
Purpose:	Use this sub-parameter to set the factor for formation of threshold 1. Set the factor in a range from '0.1' to '40.0'. The threshold is the product of 'L1.LIMIT' and 'L2.FACT1'. The threshold 1 message is displayed when threshold 1 is exceeded. This message is only output if threshold 2 or 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	1.0

### L3.FACT2 - Factor 2

Adjustment range:	0.1 ... 40.0
Purpose:	Use this sub-parameter to set the factor for formation of threshold 2. Set the factor in a range from '0.1' to '40.0'. The threshold is the product of 'L1.LIMIT' and 'L3.FACT2'. The threshold 2 message is displayed when threshold 2 is exceeded. This message is only output if threshold 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	2.0

### L4.FACT3 - Factor 3

Adjustment range:	0.1 ... 40.0
Purpose:	Use this sub-parameter to set the factor for formation of threshold 3. Set the factor in a range from '0.1' to '40.0'. The threshold is the product of 'L1.LIMIT' and 'L4.FACT3'. The threshold 3 message is displayed when threshold 3 is exceeded. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	5.0

#### 8.3.3.11 Monitoring of number of changes in direction 'O.\DCHG'

##### O.\DCHG - Monitoring of number of changes in direction

Condition:	The '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is set to 'On1', 'On2' or 'On3'.
Possible settings:	<ul style="list-style-type: none"><li>• OFF</li><li>• On</li></ul>

8.3 Description of parameters

Purpose:	Use this parameter to continuously monitor the number of changes in direction of the actuator beyond the deadband. Monitoring is performed in three steps. Set the following sub-parameters appropriately. To activate monitoring, set the parameter to 'On'. Sub-parameters are displayed.  The current value is displayed in Diagnostic value '2.CHDIR - Number of changes in direction' (Page 259). The positioner triggers a message if the current value exceeds one of the three thresholds.
Factory setting:	OFF

**O1.LIMIT - Limit**

Adjustment range:	1 ... 1.00E8
Purpose:	Use this sub-parameter to set the base limit for the changes of direction of the actuator. Set the base limit in a range from '1' to '1.00E8'.
Factory setting:	1.00E6

**O2.FACT1 - Factor 1**

Adjustment range:	0.1 ... 40.0
Purpose:	Use this sub-parameter to set the factor for formation of threshold 1. Set the factor in a range from '0.1' to '40.0'. The threshold is the product of 'O1.LIMIT' and 'O2.FACT1'.  The threshold 1 message is displayed when threshold 1 is exceeded. This message is only output if threshold 2 or 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	1.0

**O3.FACT2 - Factor 2**

Adjustment range:	0.1 ... 40.0
Purpose:	Use this sub-parameter to set the factor for formation of threshold 2. Set the factor in a range from '0.1' to '40.0'. The threshold is the product of 'O1.LIMIT' and 'O3.FACT2'.  The threshold 2 message is displayed when threshold 2 is exceeded. This message is only output if threshold 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	2.0



**O4.FACT3 - Factor 3**

Adjustment range:	0.1 ... 40.0
Purpose:	Use this sub-parameter to set the factor for formation of threshold 3. Set the factor in a range from '0.1' to '40.0'. The threshold is the product of 'O1.LIMIT' and 'O4.FACT3'. The threshold 3 message is displayed when threshold 3 is exceeded. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	5.0


**8.3.3.12 Monitoring the position average value 'P.\Pavg'****P.\Pavg - Monitoring the position average value**

Requirement:	The '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is set to 'On1', 'On2' or 'On3'.
Possible settings:	<ul style="list-style-type: none"> <li>• OFF</li> <li>• On</li> </ul>
Purpose:	Use this parameter to activate the test to calculate and monitor the average value of position. During the test, the average values of position and reference are always compared at the end of a time interval. The current value is displayed in Diagnostic value '20.PAVG - Average value of position' (Page 265). The positioner triggers a message if the current average value of position undershoots one of the three thresholds.
Factory setting:	OFF

**P1.TBASE - Time basis of average value generation**

Possible settings:	0.5h / 8h / 5d / 60d / 2.5y
Purpose:	Use this sub-parameter to set the time interval to calculate the average value of position. The following values are available to define the time intervals: <ul style="list-style-type: none"> <li>• 30 minutes</li> <li>• 8 hours</li> <li>• 5 days</li> <li>• 60 days</li> <li>• 2.5 years</li> </ul> After starting the calculation for average value of reference and expiry of the time interval, a position average over the interval period is determined and compared with the average value of reference. The test is then restarted.
Factory setting:	0.5h

### P2.STATE - Status of monitoring position average value

Possible settings:	IdLE / rEF / ###.# / Strt
Purpose:	Use this sub-parameter to start the calculation for average value of position. If an average value of reference has never been determined, the parameter value is 'IdLE'. Then start the calculation by pressing the  button for 5 seconds. The value in the display changes from 'IdLE' to 'rEF'. The average value of reference is calculated. When the time interval expires, the calculated average value of reference is shown on the display.
Factory setting:	IdLE

---

#### Note

#### Current average value of position

The respective current average value of position is displayed in the Diagnostic value '20.PAVG - Average value of position' (Page 265). If no average value of position has been calculated, 'COMP' is displayed as the diagnostic value.

---

### P3.LEVL1 - threshold 1

Possible settings:	0.1 ... 100.0
Purpose:	Use this sub-parameter to set threshold 1 for the maximum deviation of the current average value of position from the average value of reference. The value is given in percent. Set the threshold in a range from '0.1' to '100.0'. The positioner triggers the threshold 1 message if the difference between the average value of position and the average value of reference exceeds threshold 1. This message is only output if threshold 2 or 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	2.0

**P4.LEVL2 - threshold 2**

Possible settings:	0.1 ... 100.0
Purpose:	Use this sub-parameter to set threshold 2 for the maximum deviation of the current average value of position from the average value of reference. The value is given in percent. Set the threshold in a range from '0.1' to '100.0'. The positioner triggers the threshold 2 message if the difference between the average value of position and the average value of reference exceeds threshold 2. This message is only output if threshold 3 is not exceeded at the same time. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	5.0

**P5.LEVL3 - threshold 3**

Possible settings:	0.1 ... 100.0
Purpose:	Use this sub-parameter to set threshold 3 for the maximum deviation of the current average value of position from the average value of reference. The value is given in percent. Set the threshold in a range from '0.1' to '100.0'. The positioner triggers the threshold 3 message if the difference between the average value of position and the average value of reference exceeds threshold 3. The process to activate and display this message is described in the 'XDIAG' parameter.
Factory setting:	10.0



# Functions/operations using PROFIBUS PA

## 9.1 System integration

A control system (master) uses acyclic and cyclic data transfer to operate and monitor the positioner. You must set an address of the positioner in advance so that it can communicate with the master as a slave.

The PROFIBUS address is set to 126 in the as-delivered condition. You set the PROFIBUS address on the device or use a configuration tool like SIMATIC PDM to set the address through the bus.

## 9.2 Acyclic data transfer

### 9.2.1 Acyclic data transfer using SIMATIC PDM

#### SIMATIC PDM

The acyclic data transfer is mainly used to transfer parameters during commissioning and maintenance, for batch processes or to display other measured variables that do not participate in the cyclic transmission of useful data.

The data is transferred between a class 2 master and a field device using the so-called C2 connections. The device supports up to four C2 connections, so the multiple class 2 masters can access the same positioner simultaneously.

SIMATIC PDM is preferably used for the acyclic data transfer. It is a software package for project planning, parameterization, commissioning, diagnostics and maintenance of the positioner and other field devices.

SIMATIC PDM enables access to process values, alarms, status and diagnostics information of the device. You can use SIMATIC PDM to execute the following functions for field devices:

- Display
- Set
- Change
- Compare
- Check for plausibility
- Manage and simulate

### Procedure for acyclic data transfer:

We recommend the following general procedure:

1. First read the current settings from the device using the "Load to PG/PC" menu item.
2. Check the current settings.
3. Make any necessary settings.
4. Load the parameter settings into the device using the "Download to device" menu item.
5. Save the settings in the SIMATIC PDM as well.

The menu bar of SIMATIC PDM contains the "File", "Device", "View", "Diagnostics" and "Help" menus. The "Device" and "View" menus, which also contain other sub-menus, are described below in detail.

## 9.2.2 'Device' menu

### 9.2.2.1 Load to device

Use this sub-menu to load the parameters from the offline display of SIMATIC PDM into the device. Call up the function using the following button:



Figure 9-1 Load to device

### 9.2.2.2 Load into PG/PC

Use this sub-menu to read the parameters from the device. These parameters are then displayed in SIMATIC PDM. Call up the function using the following button:



Figure 9-2 Load to PG/PC

### 9.2.2.3 Assign address and TAG

Use this sub-menu to assign a new address and TAG. Note that this is only possible if the slave is not yet integrated into the cyclic service.

### 9.2.2.4 Value comparison

Use this dialog box to start the comparison of device parameters. The parameter values of a device which are always saved in the project form the basis for the comparison of values.

The parameter values of a device which are saved in the project can be compared with the following data types.

- Offline data: The parameter values of a device which are saved in the project.
- Online data: Parameter values currently saved in the device.

### 9.2.2.5 Object properties

#### "General" tab

In this "General" tab you can find information on the PDM object and enter optional additional information.

In the "General" tab you can find:

- Object name
- Description
- Message
- Properties

#### "Device" tab

In this "Device" tab you display the device data.

The contents of the fields cannot be changed. The contents are derived from the Device Description assigned to the object if these have been entered in it.

Certain entries are displayed as keys and not as plain text.

In the "Device" tab you can find:

- Device type
- Manufacturer
- Order No.
- Catalog path
- Device DDL
- EDD version
- Device version

#### "Diagnostics" tab

In this "Diagnostics" tab you can display information for device communication. The symbol which is displayed on the device is formed in accordance with this information.

## 9.2 Acyclic data transfer

In the "Diagnostics" tab you can find:

- Communication
- Last test
- Message text

### "Communication" tab

In this "Communication" tab you can display the address of a device. If the device has been configured in the process device network view, you can change the address.

In the "Communication" tab you can find:

- Redundancy

### "Document manager" tab

In this "Document manager" tab, you can assign documents to a PDM object.

## 9.2.2.6 Calibration report

The "Calibration report" section contains information on the following topics:

### "Test environment" tab

In this "Test environment" tab you can find:

- Data on the field device
- Data on the operator and test date of the calibration report
- Operator remarks concerning the test
- Comment field
- Settings for scheduling

### "Diagnostics" tab

In this "Diagnostics" tab you can find:

- Information on display of the communication connection status
- Information on display of the device status
- Date of the last change
- Messages of the last test



### "Measuring range settings" tab

In this "Measuring range settings" tab you can find:

- Channel-specific Information (configurable: maximum 8 channels)
- Channel selection
- Configurable settings per channel:
  - Measuring circuit unit
  - Measuring range
  - Output unit
  - Permissible deviation in output range (setpoint/actual value)
  - Comment fields

### "Appendices" tab

Configure files which are to be linked to the report.

In the "Appendices" tab you can find:

- Possible file types:
  - pdf
  - doc; docx
  - xls; xlsx
  - txt
  - jpg

### "Comments" tab

Additional comments for various types of comment

In the "Comments" tab you can find:

- Wiring errors
- Unsuitable measuring point
- Device error
- Error comment

#### 9.2.2.7 Change log

The change log is used to record the actions carried out on system objects using SIMATIC PDM.

##### Properties:

- The change log is part of the associated SIMATIC project.
- The change log is a circular log (first in - first out). Some fields in the change log are created automatically. The information is entered in the language which is pre-selected in the SIMATIC project.

**Requirements for using the "Change log" function:**

You require the license key for "SIMATIC PDM Extended" in order to use the "Change log" function.

**Entries in the change log:**

Actions are shown in the dialog window "SIMATIC PDM change log" which have been executed in the project or also on individual objects (devices). The displayed actions depend on the object displayed in SIMATIC PDM.

You can restrict the displayed information by setting the filter. The drop-down list "Action" of the filter shows the actions which can be displayed.

**9.2.2.8 Wizard**

This menu item is only available if the extended diagnostics has been previously activated in the parameter list. In this menu you can display and execute the various diagnostics options: The following diagnostics options can be activated and parameterized:

**'Quick Start' wizard**

Use the 'Wizard - Quick Start' button to start up the device.

**'Partial Stroke Test' wizard**

Use the 'Wizard - Partial Stroke Test' button to set a diagnostics function which moves and monitors the stroke over a certain distance.

**'Full Stroke Test' wizard**

Use the 'Wizard - Full Stroke Test' button to set a diagnostics function which moves and monitors the stroke over the complete distance.

**'Step Response Test' wizard**

Use the 'Wizard - Step Response Test' button to set a diagnostics function which moves and monitors the stroke over an intentional distance.

**'Multi-Step Response Test' wizard**

Use the 'Wizard - Multi-Step Response Test' button to set a diagnostics function which repeatedly moves and monitors the stroke over an intentional distance.

**'Valve Performance Test' wizard**

Use the 'Wizard - Valve Performance Test' button to set a diagnostics function which determines the characteristic values of the valve in accordance with IEC 61298-2.

### 9.2.2.9 Partial stroke test (PST)

#### Availability

This menu item is only available if previously activated in the parameter list using the 'Extended diagnostics' menu. You can then activate and parameterize the partial stroke test.

#### Functions

Use the 'Partial stroke test' button to access the functions of the partial stroke test:

- Execute the partial stroke test.
- Cancel the partial stroke test.
- Deactivate diagnostics

Changes become effective as soon as the Transfer button is pressed.

### 9.2.2.10 PST trace characteristic

#### Availability

This menu item is only available if the extended diagnostics has been previously activated in the parameter list. Use this menu item to call the following sub-menus:

- Read trace
- Export as \*.csv file
- Import a .csv file

#### Read trace

When executing a partial stroke test, the temporal course of the actual value is scanned in the background and saved in the RAM of the positioner with a maximum of 1000 data points. Use this menu item to read in the saved data in SIMATIC PDM. The end of the reading process is displayed in the SIMATIC PDM status bar.

#### Export as \*.csv file

Use this menu item to save the currently read in temporal course of the partial stroke test in the SIMATIC PDM as a csv file.

### 9.2.2.11 Offline leakage test

#### Application

Use this menu command to open an online dialog in which you can recognize following execution whether a leakage is present in the actuator or in the piping.

## 9.2 Acyclic data transfer

You will also obtain information about the states in the diagnostic field 'Leakage test status'.

- Not executed (only '-' is shown in the positioner display)
- Running
- Stopped
- Complete

If you run the test using the 'Start offline leakage test' button in the online dialog, the leakage is measured at the position at which the positioner is currently located. The measured leakage [%/min] is subsequently saved in the '11.LEAK' parameter. With the "Test area" parameter you move the path by which the drive may move during this test.

### See also

Monitoring the lower endstop 'F.\\ZERO' (Page 176)

### 9.2.2.12 Maintenance and diagnostics

#### Application

The sub-menu "Maintenance and diagnostics" is only available if the extended diagnostics has been activated. You can then activate and parameterize the following extended diagnostics parameters:

- Monitoring of dynamic control valve behavior 'b.\\DEVI' (Page 168)
- Monitoring/compensation of pneumatic leakage 'C.\\LEAK' (Page 170)
- Monitoring of stiction (slipstick) 'd.\\STIC' (Page 173)
- Monitoring of deadband 'E.\\DEBA' (Page 175)
- Monitoring the lower endstop 'F.\\ZERO' (Page 176)
- Monitoring the upper endstop 'G.\\OPEN' (Page 177)
- Monitoring the lower limit temperature 'H.\\TMIN' (Page 179)
- Monitoring the upper limit temperature 'J.\\TMAX' (Page 180)
- Monitoring of number of total strokes 'L.\\STRK' (Page 182)
- Monitoring of number of changes in direction 'O.\\DCHG' (Page 183)
- Monitoring the position average value 'P.\\PAVG' (Page 185)

Changes become effective as soon as the Transfer button is pressed.

### 9.2.2.13 Initialization parameters

#### Use

Not only you can display the initialization parameters in this menu, but also change them specifically. Allow only specialists to change the initialization parameters.

You also need this function if you need to replace the electronic unit. However you cannot initialize at the moment.

### 9.2.2.14 Initialization

#### Application

With SIMATIC PDM, you also have the option to initialize the positioner for the first time.

#### First initialization

##### WARNING

##### Start initialization

You are not located on-site at the positioner. In order to prevent personal injuries and material damage, take in-house precautionary measures before starting the initialization process.

##### Note

Also ensure that you always start the initialization process from the acyclic master even if the positioner is in automatic mode and contains setpoints of a cyclic master.

If required, you can interrupt the ongoing initialization by pressing the "Stop initialization" button. You can also press the operating mode button or disconnect the power supply to interrupt the initialization process on the device.

Proceed as follows to initialize the positioner using SIMATIC PDM for the first time:

1. Go to the "Device" menu and then to the "Initialization" sub-menu. A window containing an overview of the initialization status then opens.
2. Press the "Start initialization" button. A warning is then displayed. Follow this warning without fail to prevent personal injuries and damage to the system.
3. Acknowledge the warning.

The initialization process starts once you acknowledge the warning. You can monitor the progress in the "Status (initialization)" field in the open window of the initialization menu. As soon as the initialization is completed successfully, the positioner continues working in the operating mode from which the initialization process was started. If a fault message appears, an on-site correction is required.

### 9.2.2.15 Operation

Open the 'Device > Operation' menu. An online dialog is opened with two tabs. Go to the 'Operation' tab.

## Target mode

The following target modes (operating modes of function blocks) are possible:

- Automatic (AUT)
- Manual (MAN)
- Out of service (O/S)

Note that the target modes refer to the operating modes of function blocks of the PROFIBUS PA block model, and should not be confused with the "Automatic" and "Manual" operating modes of the positioner.

The above target modes are effective when the positioner is in automatic mode (AUT). If the positioner is in manual mode (MAN), they are only effective after an on-site switchover to automatic mode (AUT).

These target modes are saved in the positioner in the power failure-safe manner.

## Automatic mode

As long as the positioner is not integrated into the cyclic service as a slave, SIMATIC PDM can be used to send a setpoint to it in a cyclic manner.

Make the following settings:

1. Go to the "Operating mode" tab.
2. Set the target mode to "Automatic".
3. Enter a value between 0 and 100% for the desired setpoint, quality as "Good" and the status as "OK".
4. Transfer these settings to the positioner.

The positioner is controlled using the desired setpoint until a cyclic master starts communication with a slave or you switch over the positioner to the "Manual" mode on-site.

---

### Note

Note that the positioner responds with the "Poor" quality and the "Constant value" status after sending the data.

If you exit this target mode and no other master sends a setpoint to the positioner, it is controlled using the configured fail-safe value after the set monitoring time expires.

---

## Manual mode

You can use SIMATIC PDM to send a setpoint to the positioner even when cyclic communication is active. To do this, you need only set priority over the cyclic master beforehand.

Make the following settings:

1. Go to the "Operating mode" tab.
2. Set the target mode to "Manual".

3. Enter a value between 0 and 100% as a starting value, "Good" as the quality and "OK" as the status.
4. Transfer these settings to the positioner.

The positioner is now controlled using the desired starting value and reports this manual mode through "MM" on the display.

Note that the starting value entered in the manual mode is directly written in the starting block of the positioner without scaling.

You can switch the positioner to the manual mode on-site and move the actuator using buttons. The setpoint is tracked as per the current actual value. The manual mode and the current position are retained after switching back to the automatic mode.

After a power failure, the positioner is controlled in the manual mode depending on the direction of action of the actuator using the value set in the "YA" or "YE" parameters.

---


#### Note

You must set the target mode to "Automatic" to reactivate the setpoints of the cyclic master.

---

### Out of service (O/S)

You can use SIMATIC PDM to put the positioner out of service irrespective of the cyclic communication.

 <b>CAUTION</b>
<b>Depressurize</b>
<p>In order to prevent physical injuries and material damage, you must ensure that the actuator is depressurized when it is put out of service.</p>

Make the following settings:

1. Go to the "Operating mode" tab.
2. Set the target mode to "Out of service (O/S)".
3. Transfer these settings to the positioner.

The successful transmission is reported by "OS--" on the display of the positioner.

You can switch the positioner to the manual mode on-site and move the actuator using buttons in this target mode also. "MAN--" is then shown on the display.

The "Out of service (O/S)" mode is retained after switching back to the automatic mode. The actuator remains depressurized after a power failure.

---

#### Note

You must set the target mode to "Automatic" to reactivate the setpoints of the cyclic master.

---

### 9.2.2.16 Simulation

#### Register

Use this sub-menu to access the "Simulation" online menu that is split into the following four tabs:

- Simulation of actual value
- Simulation of device status
- Simulation of device diagnostics

#### Simulation of actual value

You can activate the actual value simulation in this tab and also define the actual value to be simulated and its quality and status. The following feedback values are available:

- Setpoint
- Actual value
- Setpoint deviation
- Checkback

Changes become effective as soon as the Transfer button is pressed.

#### Simulation of device status

You can activate simulation of the device status in this tab and then select the diagnostics messages to be simulated. This concerns the content of the "DIAGNOSTICS physical block parameter" that generates different diagnostics messages depending on whether the condensed status has been activated or deactivated. Changes become effective as soon as the Transfer button is pressed.

#### Simulation of device diagnostics

In this tab you enable simulation of device diagnostics.

You can then select the desired diagnostics events in the simulation of device diagnostics, and use device diagnostics and message text to obtain the feedback indicating that the corresponding event has been triggered in the device. Changes become effective as soon as the Transfer button is pressed.

### 9.2.2.17 Date and time in the device

#### Application

Use this menu item to open an online dialog in which you can set the date and time in the device.



### 9.2.2.18 Write protection

#### Application

Following completion of commissioning, you can set the write protection to prevent undesired changes by an acyclic master.

However, you can change the parameters of the positioner on-site as before.

#### Enabling write protection

1. Call the "Write protection" sub-menu.
2. Set 'Write protection' in the sub-menu to 'On'.

If you still try to write, the PDM displays the 'Connection terminated' message.

---

#### Note

##### Write protection

1. If 'On' is displayed for 'Hardware write protection' in the online dialog 'Write protection', the application parameter '39.BIN1' / '40.BIN2' Function of binary inputs (Page 153) 'bLoc1' or 'bLoc2' has been set on the positioner. Writing via SIMATIC PDM is thus also blocked. The write protection directly activated in the positioner can only be canceled again directly on the positioner.
  2. In SIMATIC PDM, the write protection can only be changed via the online dialog 'Write protection' in the 'Device' menu. You cannot change the write protection via the tree topology in the parameter table 'Security'.
- 

### 9.2.2.19 Reset parameters in PDM

#### Application

Use this menu item to open a dialog box to reset all SIMATIC PDM parameters to their factory settings (default values).

SIMATIC PDM parameters are reset when you press the 'OK' button. You can then transfer the parameters to the SIMATIC PDM memory using 'File->Save'.

Select 'Device->Load to device' to transfer the reset parameters to the positioner as well.

### 9.2.2.20 Reset parameters on the device

#### Application

Use this menu item to open an online dialog to reset the parameters in the positioner to their factory settings (default values).

## 9.2 Acyclic data transfer

The following parameters can be selected for resetting:

- Initialization parameters
- Device parameters (except 49.PNEUM, 54.STNR and 55.IDENT)
- Parameters of extended diagnostics
- Offline test parameters

The parameters are reset when you press the 'OK' button.

Select 'Device->Load to PG/PC' to transfer the reset parameters of the positioner to SIMATIC PDM as well.

### 9.2.2.21 Reset the field device

#### Resetting to delivery state

If the positioner has been maladjusted such that it can no longer perform its control task, you can use the 'Reset' function to restore the delivery state. This function resets all parameters to their factory settings except for the PROFIBUS address.

Resetting is displayed in the online dialog by the diagnostics message 'Device status' as "Restart (cold startup) carried out". You must then reset all parameters and execute an initialization process.

#### Warm restart

With the warm restart you initiate a complete restart of the positioner. This interrupts and then reestablishes communication.

This restart is displayed in the online dialog by the diagnostics message 'Device status' as "New startup (warm startup) carried out". If no measured values are available, the automation or control system reads in the "Uncertain, initial value, constant value" status.

#### Resetting the address (STRN) to 126

If no device in your system has the preset address 126, you can add your positioner to the PROFIBUS path during ongoing operation of the automation or control system. You must subsequently change the address of the newly connected device to a different value.

If you remove a positioner from the PROFIBUS path, you must reset its address to 126 using this function 'Resetting the address (STRN) to 126' so that you can re-integrate a positioner in this or another system depending on the requirement.

The address cannot be reset if a cyclic master is already communicating with the positioner.

## 9.2.3 'View' menu

### 9.2.3.1 Process variables / diagnostics cockpit

#### "Cockpit overview" tab

This "Cockpit overview" tab contains:

- Bar graph displays of actual value and setpoint [stroke/%)
- Bar graph of absolute control deviation [control deviation/%)
- Bar graph of current temperature '30.TEMP' [temperature/°C)
- Information on the TAG, description, message and setpoint function '9.SFCT'

#### "Trend view (setpoint/actual value)" tab

This "Trend view (setpoint/actual value)" tab displays the setpoint/actual value as a bar and as a trend.

Furthermore, menu items exist with which you can call the following sub-menus:

- Export as \*.csv file
- Import a .csv file
- Connect axes
- Print

#### "Status" tab

In the "Status" tab you can find:

- Information about checkback, binary input 1 and binary input 2
- Information about limit status

There is an additional 'Detailed status' button in which you can obtain detailed device diagnostics 1 and device diagnostics 2.

#### "More cockpit options" tab

You can find additional buttons in the "More cockpit options" tab:

- Min/Max temperature
- Trend charts 'Temperature' and 'Control deviation'
- Setpoint function
- Diagnostics system status
- Maintenance counter

### 9.2.3.2 Starting the lifelist

#### Application

In this menu it is possible to identify active field devices without configuring. Use 'Lifelist' to carry out a scan on one of the following PDM objects:

- PROFIBUS DP network
- PROFIBUS PA network
- HART modem network
- Foundation Fieldbus network

### 9.2.4 'Diagnostics' menu

#### 9.2.4.1 Updating diagnostics














Use this sub-menu to update the diagnostics information in SIMATIC PDM that is visualized using symbols. The symbols are shown before the device name. Call up the function using the following button:





Figure 9-3 Updating diagnostics

The following table shows the symbols and the associated diagnostics information.

Meaning	Symbols
<b>Deactivated</b> No device description (EDD) from the device catalog has yet been assigned to the field device / Field device cannot be accessed.	
<b>Not validated</b> A device description from the device catalog has been assigned to the field device.	
<b>Communication disrupted</b> Communication error; communication has been interrupted or no communication could take place with the device at the configured address. The device cannot provide detailed diagnostics information.	
<b>Assignment error</b> The field device is incompatible with the configured field device or the device has been configured incorrectly. The device cannot provide detailed diagnostics information.	
<b>Maintenance alarm</b> Maintenance is required immediately as there is a device fault.	

Meaning	Symbols
<p><b>Maintenance demand</b></p> <p>Maintenance is required to prevent a possible device fault from occurring. Additional diagnostics information is available.</p>	
<p><b>Maintenance required</b></p> <p>Maintenance must be scheduled. No functional restriction has been diagnosed for the field device, service is requested. Additional diagnostics information is available.</p>	
<p><b>Manual mode</b></p> <p>There is a communication connection with the field device. The device is in manual mode.</p>	
<p><b>Simulation mode</b></p> <p>There is a communication connection with the field device. The device is in manual mode. For example, the device is in manual mode "Out of service".</p>	
<p><b>Out of service</b></p> <p>There is a communication connection with the field device. The device is in manual mode. For example, the device is in manual mode "Out of service".</p>	
<p><b>Configuration error</b></p> <p>Field device fault due to a parameter or configuration error in the hardware components. A maintenance alarm is triggered automatically.</p>	
<p><b>Configuration warning</b></p> <p>Field device warning due to invalid parameters for which substitute values are used. A maintenance request is triggered automatically.</p>	
<p><b>Configuration changed</b></p> <p>The parameters set for the device do not match the parameter data saved in the project. Communication with the device is possible to carry out a value comparison or to change parameter settings.</p>	
<p><b>Unknown diagnostics status</b></p> <p>Unknown field device status due to invalid parameters for which substitute values are used. A maintenance request is triggered automatically.</p>	
<p><b>Process value alarm</b></p> <p>At least one process value has exceeded or fallen below a hardware interrupt limit whose parameters were assigned in the device. Communication with the device is possible.</p>	
<p><b>Process value warning</b></p> <p>At least one process value has exceeded or fallen below a process warning limit whose parameters were assigned in the device. Communication with the device is possible.</p>	
<p><b>Process value tolerance</b></p> <p>At least one process value has exceeded or fallen below a process tolerance limit whose parameters were assigned in the device. Communication with the device is possible.</p>	
<p><b>No messages</b></p> <p>No functional restrictions or diagnostics information known.</p>	

Meaning	Symbols
<p><b>No diagnostics check</b></p> <p>No functional restrictions known. The field device does not support additional diagnostics information.</p>	
<p><b>Test mode (background color of diagnostics icon)</b></p> <p>The device is in local test mode. All the displayed information or diagnostics may be simulated. The information transferred to the automation systems (process values and status) may also be simulated.</p>	

### 9.2.4.2 Device diagnostics

#### "Diagnostics" tab

In this "Diagnostics" tab you can find:

- Communication
- Device status
- Last test
- Message text

#### "Messages" tab

In this "Messages" tab you can find:

- Device status
- Checkback
- Limit status (group signal of all three-stage diagnostics events, detailed diagnostics events can be found under the "Device diagnostics" tab)
- Binary input 1
- Binary input 2

#### "Device diagnostics" tab

In this "Device diagnostics" tab you can find:

- Device diagnostics 1
- Device diagnostics 2
- Quality
- Status

### 9.2.4.3 Maintenance information

#### "Current" tab

In this "Current" tab you can find information about the values of the positioner which were determined during the last initialization. The following values are displayed:

- Manipulated variable zero point / upper endstop
- Travel time UP / DOWN
- Impulse length UP / DOWN
- Deadband UP / DOWN
- Slow step zone UP / DOWN
- Determined actuator travel
- Leakage

The 'Save maintenance information (last maintenance)' button requests you to enter a maintenance date. The current values are saved in the positioners and in the "Last maintenance" tab. The values can be used as reference values in the "Last maintenance" tab for comparison purposes during subsequent reinitialization of the positioner.

Use the 'Reset maintenance information' button to reset the maintenance date to '01.01.2000'. This date informs the positioner that no maintenance has been carried out yet.

#### "Last maintenance" tab

In this "Last maintenance" tab, you can find the values which have been saved from the "Current" tab. These values include a save date.

#### "Maintenance counter" tab

In this "Maintenance counter" tab, you can find an overview of the number of:

- 100% strokes
- Changes of direction
- Fault messages
- Alarms
- Operating hours
- Switching cycles

Press the 'Reset maintenance counter' button to access a selection menu to reset all maintenance counters at one go or individually.

#### "Temperature" tab

This "Temperature" tab displays the minimum, current and maximum temperatures [Temperature/°C] as a bar graph and as a trend.

#### 9.2.4.4 Trend characteristic

##### Application

The temporal course of the corresponding measured variable over the selected interval is shown in a trend characteristic. The trend characteristic provides an overview of the previous development of the measured value and can be used as the basis to estimate the future course.

If sufficient measured values are available, trends over the last 30 minutes, eight hours, five days, two months and 30 months can be processed.

You can use the menu item "Trend charts" to display trends of the following sub-menus:

- Actual value
- Control deviation
- Leakage
- Stiction (slipstick)
- Zero point
- Upper endstop
- Temperature
- Deadband

#### 9.2.4.5 Histograms

##### Application

A class division over the entire measuring range of a variable is included in a histogram. The time spent by the measured variable within different classes is also displayed.

You can use the position histogram to assess whether a control valve has been designed practically and whether it was essentially in the expected operating point during its use so far.

You can use the menu item "Histograms" to display histograms of the following sub-menus:

- Position
- Control deviation
- Temperature

#### 9.2.4.6 Alarm logbook

##### Application

You can use the menu item "Alarm logbook" to display information about the time stamp, operating hours, interrupts and status.



### 9.2.4.7 Characteristic curve

#### Characteristic curve

The characteristic curves of devices are displayed here if it has been set to "free (user-defined)".

If tight closing is active, the tight closing limits are also displayed irrespective of the setting of the characteristic curve.

## 9.3 Cyclic data transfer

The cyclic data transfer is used to transfer the useful data relevant for the process automation between the class 1 master (control or automation system) and the positioner.

### 9.3.1 Configuration

#### Configuring with the GSD

Information about input and output ranges as well as the consistency of the cyclically transferred data is defined in the GSD file that is used by the device to check the configuration telegram and to declare it as valid if required.

The useful data to be transferred in the cyclic operation is determined during the projecting planning. The data volume to be transferred can thus be optimized. The GSD files of all common devices are already stored in the Siemens control systems. GSD files can be imported later. You can download the GSD files from:

[www.siemens.de/sipartps2](http://www.siemens.de/sipartps2)

Under "More Info", click on "→ Downloads".

#### Configuring the useful data

The useful data made available to the control system or the controller through PROFIBUS depends on the selected desired configuration.

---

**Note****Configuration tool**

In case of STEP 7, the configuration tool used is HW config.

---

9.3 Cyclic data transfer




Figure 9-4 Example of a small PROFIBUS DP/PA system

- |                             |                                                         |
|-----------------------------|---------------------------------------------------------|
| ① PC or PG (master class 2) | ⑦ PA devices                                            |
| ② Power supply              | ⑧ DP/PA coupler/link                                    |
| ③ PROFIBUS DP               | ⑨ CPU SIMATIC S7 (master class 1)                       |
| ④ PROFIBUS PA               | ⑩ MPI cable (required for commissioning and monitoring) |
| ⑤ Splitter                  |                                                         |
| ⑥ Bus terminator            |                                                         |

A small STEP 7 program that establishes cyclic exchange with the positioner using PROFIBUS PA (positioner) is given below.




Figure 9-5 STEP 7 sample program

In this example, all data in the input and output directions supported by the device are transferred. The selected peripheral starting address is 256 (W#16#100).

**Note**

Only the older SIMATIC CPUs require the SFC14 and SFC16 modules for consistent reading and writing.

Legend of the sample program			
Byte	Function	Composition	Number of bytes
Byte 15	Input data	READBACK	5
		RCAS_OUT	5
		CHECKBACK	3
		POS_D	2
Byte 10	Output data	SP	5
		RCAS_IN	5

### 9.3.2 Useful data through PROFIBUS

#### Cyclic useful data

The positioner can exchange a combination of the following cyclic useful data through PROFIBUS:

Name		Abbreviation	Direction from the positioner's point of view	Length in byte	Comprising:
German	English				
Setpoint	Setpoint	SP	Input	5	Value/Status
Readback	Readback	RB	Output	5	Value/Status
Position discrete	Position discrete	POS_D	Output	2	Value/Status
Checkback	Checkback	CB	Output	3	Value
Remote Cascade Input	Remote Cascade Input	RCAS_IN	Input	5	Value/Status
Remote Cascade Output	Remote Cascade Output	RCAS_OUT	Output	5	Value/Status

#### Setpoint

The setpoint is divided into a floating point value (4 bytes) and the corresponding status (1 byte, see further below).

#### Actual value

The actual value indicates the valve position. The actual value is divided into a floating point value (4 bytes) and the corresponding status (1 byte).

#### Position discrete

The discrete valve position is displayed as a value (1 byte) having the following meaning:

0 = not initialized

1 = valve closed

2 = valve open

3 = valve in the intermediate position: Even this value has a status (1 byte).

#### Checkback

The checkback is displayed in 3 bytes in a bit-coded format:

	Bit	Meaning of "1"	Remarks
0	0	Device in the fail safe position	The position is determined by the "49.FSTY" parameter.
	1	Request for on-site operation	Reports that a button has been pressed.
	2	The device is operated on-site.	The device is parameterized on-site, e.g. using the "1.YFCT" parameter or is not initialized.
	3	Emergency operation active	The device is in the manual mode. Representation on the display: MAN or P

	Bit	Meaning of "1"	Remarks
	4	Deviation of the movement direction	Not required for the positioner.
	5	End stop reached (valve completely open)	Not required for the positioner.
	6	End stop reached (valve completely closed)	Not required for the positioner.
	7	Run time overshoot	The device could not be adjusted. Monitoring time and threshold in the "44.TIM" and "45.LIM" parameters exceeded, e.g. due to the lack of compressed air
1	0	The valve is opened.	The "Ventilate actuator" command issued
	1	The valve is closed.	The "Depressurize actuator" command issued
	2	Parameters were changed.	Set temporarily after switching back from the "Configuration" mode if one or more parameters were changed.
	3	Simulation mode	The simulation mode was released. Master class 2 can overwrite the current actual value, e.g., to test the response of limits in the control system.
	4	Not occupied in profile 3.	-
	5	Fault in the closed-loop control.	Not required for the positioner.
	6	Closed-loop control inactive	Not required for the positioner.
	7	Self-monitoring active	Not required for the positioner.
2	0	Path integral exceeded	Set if the set limit for the path integral has been exceeded.
	1	Additional input active	Binary 1 was activated.
	2	Additional input active	Binary 2 was activated.
	3	Fault message output active	Fault message output was activated.
	4	Alarm output A1 active	Alarm output 1 was activated.
	5	Alarm output A2 active	Alarm output 2 was activated.

### Remote cascade input

The remote cascade input is used as a setpoint in the remote cascade mode (actual mode = remote cascade). The remote cascade input comprises the floating point value (4 bytes) and the status (1 byte).

### Remote cascade output

This output delivers the current setpoint in the AUTO and Remote cascade modes. The status is specially used for the transfer from AUTO to Remote cascade.

In combination with the input variable parameter (primary value scale), not only you can define the setpoints as a percentage of the valve position, but also in terms of physical variables such as cubic meter per day or liter per minute. Even the actual values are adjusted as per this scale.

#### 9.3.2.1 Possible combinations of the useful data

#### Useful data and position in the address room

You can select a combination of values for the communication of cyclic useful data between the master and the positioner:

**SP**

Setpoint:

Output (master view)		
Starting address	0	SP - floating point number
	1	
	2	
	3	
	4	SP - status

**RCAS\_OUT, RCAS\_IN**

Remote cascade output, remote cascade input:

Input (master view)		
Starting address	0	RCAS_OUT - floating point number
	1	
	2	
	3	
	4	RCAS_OUT - status

Output (master view)		
Starting address	0	RCAS_IN - floating point number
	1	
	2	
	3	
	4	RCAS_IN - status

**READBACK, POS\_D, SP**

Actual value, discrete position, setpoint:

Input (master view)		
Starting address	0	READBACK - floating point number
	1	
	2	
	3	
	4	READBACK - status
	5	POS_D
	6	POS_D - status

Output (master view)		
Starting address	0	SP - floating point number
	1	
	2	
	3	
	4	SP - status

### Checkback, SP

Checkback, setpoint:

Input (master view)		
Starting address	0	CHECKBACK
	1	
	2	

Output (master view)		
Starting address	0	SP - floating point number
	1	
	2	
	3	
	4	SP - status

### READBACK, CHECKBACK, POS\_D, SP

Actual value, discrete position, checkback, setpoint:

Input (master view)		
Starting address	0	READBACK - floating point number
	1	
	2	
	3	
	4	READBACK - status
	5	POS_D
	6	POS_D - status
	7	CHECKBACK
	8	
9		

9.3 Cyclic data transfer

Output (master view)		
Starting address	0	SP - floating point number
	1	
	2	
	3	
	4	SP - status

**RCAS\_OUT, CHECKBACK, RCAS\_IN**

Remote cascade output, checkback, remote cascade input:

Input (master view)		
Starting address	0	READBACK - floating point number
	1	
	2	
	3	
	4	READBACK - status
	5	POS_D
	6	POS_D - status

Output (master view)		
Starting address	0	RCAS_IN - floating point number
	1	
	2	
	3	
	4	RCAS_IN - status



**READBACK, RCAS\_OUT, POS\_D, CHECKBACK, SP, RCAS\_IN**

Actual value, remote cascade output, discrete position, checkback, setpoint, remote cascade input:

Input (master view)		
Starting address	0	READBACK - floating point number
	1	
	2	
	3	
	4	READBACK - status
	5	RCAS_OUT - floating point number
	6	
	7	
	8	
	9	RCAS_OUT - status
	10	POS_D
	11	POS_D - status
	12	CHECKBACK
	13	
	14	

Output (master view)		
Starting address	0	SP - floating point number
	1	
	2	
	3	
	4	SP - status
	5	RCAS_IN - floating point number
	6	
	7	
	8	
	9	RCAS_IN - status

**9.3.2.2 Diagnostics**

**Function**

The positioner can report active information about its device status. These diagnoses are important information that can be used by an automation system to initiate remedial measures.

Standard mechanisms of PROFIBUS-DP are used to transfer the diagnostics information and report it actively to the class 1 master. PROFIBUS-DP has a protocol to transfer the information that has higher priority than the useful data to the class 1 master.

9.3 Cyclic data transfer

The contents of the "Device status" parameter from the physical block are reported along with the information whether a status change (event received/event sent) has occurred.

**Diagnostics as per PROFIBUS DP (DDL\_M\_Slave\_Diag)**

The positioner delivers the diagnostics data in the following format:

Input (master view)			
Starting address	0	Station_status_1	
	1	Station_status_2	
	2	Station_status_3	Standard DP - diagnostics
	3	Diag_Master_Add	
	4	Ident_Number	
	5	Ident_Number	
	6	Header	
	7	Status_Type	Status coding as per DPV1
	8	Slot_Number	
	9	Specifier	
	10	Diagnostics (0)	Diagnostics object of the physical block
	11	Diagnostics (1)	
	12	Diagnostics (2)	
	13	Diagnostics (3)	

**Specifier**

The following specifiers are available:

- 1: Incoming event
- 2: Outgoing event

**9.3.3 Adjustable status (condensed status)**

Diagnostics messages are generated in the DIAGNOSTICS physical block parameter depending on the diagnostics events in the device. At the same time, the statuses of three PowerTags (FEEDBACK\_VALUE, READBACK and POS\_D) that are sent to the master by the SIPART PS2 PA positioner are affected.

In the device, there is now an option to use diagnostics messages and predefined status messages that are permanently associated with the triggering diagnostics events. The condensed status must be deactivated for this purpose.

If the condensed status is activated, the diagnostics messages in a specific frame can be allocated to a smaller number of collective diagnostics messages and selectable status messages. This "routing" of diagnostics events is shown in the following picture.




Figure 9-6 Routing of a diagnostics event

**Note**

Please note that the condensed status cannot be changed using the SIMATIC PDM when the device is in a cyclic operation with a master class 1.

9.3 Cyclic data transfer




Figure 9-7 Activating the condensed status for the device parameterization - with an example of HW configuration with SIMATIC S7




Figure 9-8 Activating the condensed status for the device parameterization - with an example of SIMATIC PDM

### 9.3.3.1 Diagnostics messages in case of deactivated condensed status

The diagnostics messages of the DIAGNOSTICS physical block parameter in case of the deactivated condensed status are shown in the following table:

Byte	Bit	Name and meaning	Cause	Measure
0	0 ... 2	Not used	-	-
	3	DIA_TEMP_ELECTR Electronic unit temperature too high	The temperature measured at the device electronic unit has exceeded one or more set thresholds.	Check why the temperature is beyond the specified range.
	4	DIA_MEM_CHKSUM Memory error	During operation, the memory is constantly checked for the checksum and write/read errors. This message is generated in case of an error.	Replace the electronic unit.
	5	Not used	-	-
	6	DIA_NOT_INIT Device not initialized	The initialization process required for the device functioning has not yet been carried out successfully.	Carry out the device initialization process.
	7	DIA_INIT_ERR Error in initialization	Values obtained during the initialization process cannot be used.	Carry out the device initialization process again. Check the relevant parameter settings.

Byte	Bit	Name and meaning	Cause	Measure
1	0	DIA_ZERO_ERR Lower end stop beyond the tolerance	The lower end stop is beyond the set tolerance.	Check the valve. Flow restrictors and/or the seat ring are probably worn out.
	1	DIA_SUPPLY Error in the compressed air supply	A run time overshoot was detected. In all probability, the energy (compressed air) is not available.	Establish the compressed air supply and check the feed lines.
	2	Not used	-	-
	3	DIA_WARMSTART Warm restart executed (goes to "0" after 10 s)	Power was fed to the device.	Check the cabling and the supply unit.
			SIMATIC PDM was used to trigger a warm restart.	
			The internal watchdog has responded.	
	4	DIA_COLDSTART Restart executed (goes to "0" after 10 s)	The device was reset to factory settings.	-
	5	DIA_MAINTENANCE Maintenance required	To determine the cause, check in DIAGNOSTICS_EXTENSION and DIAGNOSTICS_EXTENSION_2 which diagnostics event has triggered the message.	Depends on the triggering diagnostics event.
6	DIA_CHARACTER Characteristic curve invalid	The parameterized characteristic curve does not have the required monotony, number of support points, or the x values are not arranged in 5% distances. The original characteristic curve is used further.	Modify the configuration data (change the GSD) such that it is consistent with the identification number set in the device.	
7	IDENT_NUMBER_VIOLATION Identification number changed	You have changed the PROFIBUS identification number parameter during the active cyclic operation. The device reports the identification number violation and displays a failure warning. In case of a warm restart, the device no longer participates in the cyclic transfer of useful data without changing the system configuration.	Modify the configuration data (change the GSD) such that it is consistent with the identification number set in the device.	
2	0 ... 7	Reserved	-	-
3	0 ... 6	Reserved	-	-
	7	EXTENSION_AVAILABLE Extension available	Further information about the triggering diagnostics event is available in DIAGNOSTICS_EXTENSION and DIAGNOSTICS_EXTENSION_2.	-

### 9.3.3.2 Diagnostics messages in case of activated condensed status

#### Thematic classification

Collective diagnosis messages of the DIAGNOSIS physical block parameter when the condensed status is activated are given below. The Group column contains a thematic classification of diagnostics messages. The same meaning is also used for status messages:

**Maintenance:**

M1	MAINTENANCE REQUIRED
M12	MAINTENANCE REQUIRED, MAINTENANCE DEMAND
M	MAINTENANCE REQUIRED, MAINTENANCE DEMAND, MAINTENANCE ALARM

**Process-dependent:**

P	PROCESS RELATED
---	-----------------

**Function check:**

F	FUNCTION CHECK
---	----------------



### Collective diagnostics messages

Collective diagnostics messages in the case of the activated condensed status are shown in the following table:

Byte	Bit	Name and meaning	Cause	Measures	Group
0	0 ... 7	Reserved	-	-	-
1	0 ... 2	Reserved	-	-	-
	3	DIA_WARMSTART Warm restart executed (goes to "0" after 10 s)	To determine the cause, check in DIAGNOSIS_EXTENSION and DIAGNOSIS_EXTENSION_2 which diagnosis event has triggered the message.	Check the wiring and the supply voltage.	-
	4	DIA_COLDSTART Restart executed (goes to "0" after 10 s)	-	-	-
	5	DIA_MAINTENANCE Maintenance required	You have changed the PROFIBUS identification number parameter during the active cyclic operation. The device reports the identification number violation and displays a failure warning. In case of a restart, the device will no longer participate in cyclic user data exchange unless the system configuration is changed.	Depends on the triggering diagnostics event.	M1, M12, M
	6	Reserved	-	-	-
7	IDENT_NUMBER_VIOLATION Identification number changed	To determine the cause, check in DIAGNOSIS_EXTENSION and DIAGNOSIS_EXTENSION_2 which diagnosis event has triggered the message.	Modify the configuration data (change the GSD) such that it is consistent with the identification number set in the device.	-	

9.3 Cyclic data transfer

Byte	Bit	Name and meaning	Cause	Measures	Group
2	0	DIA_MAINTENANCE_ALARM Maintenance alarm	To determine the cause, check in DIAGNOSIS_EXTENSION and DIAGNOSIS_EXTENSION_2 which diagnosis event has triggered the message.	Depends on the triggering diagnostics event.	M
	1	DIA_MAINTENANCE_DEMANDED Maintenance demand	To determine the cause, check in DIAGNOSIS_EXTENSION and DIAGNOSIS_EXTENSION_2 which diagnosis event has triggered the message.	Depends on the triggering diagnostics event.	M12, M
	2	DIA_FUNCTION_CHECK Function check	The device is in on-site operation or the FEEDBACK_VALUE is simulated	-	F
	3	DIA_INV_PRO_COND Invalid process conditions	To determine the cause, check in DIAGNOSIS_EXTENSION and DIAGNOSIS_EXTENSION_2 which diagnosis event has triggered the message.	Depends on the triggering diagnostics event.	P
	4 ... 7	Reserved	-	-	-
3	0 ... 6	Reserved	-	-	-
	7	EXTENSION_AVAILABLE Extension available	Further information about the triggering diagnosis event is available in DIAGNOSIS_EXTENSION and DIAGNOSIS_EXTENSION_2.	-	-

9.3.3.3 Definition of the status

Status byte

The status is used to provide information about the quality of the input and output values. This information is classified into four stages. Quality stages such as "Bad", "Uncertain", "Good" and "Good (cascade)" are accompanied with further information. In this case, it deals with the sub-status and the limit bits. The status byte has the following structure:

Status byte structure							
7	6	5	4	3	2	1	0
Quality		Sub-status				Limit bits	

Quality	00	Bad
	01	Uncertain
	10	Good
	11	Good (cascade)
Limit bits	00	Good

- 01 Lower limit reached
- 10 Upper limit reached
- 11 Value is constant.

The meaning of the sub-status depends on whether the condensed status is activated or not. The sub-status is therefore specified separately for both the cases.

### 9.3.3.4 Sub-status for deactivated condensed status

Bit								Name profile	German name
7	6	5	4	3	2	1	0		
0	0	0	0	0	0	x	x	Bad, non specific	Schlecht
0	0	0	0	0	1	x	x	Bad, configuration error	Schlecht, Konfigurationsfehler
0	0	0	0	1	0	x	x	Bad, not connected	Schlecht, keine Verbindung
0	0	0	0	1	1	x	x	Bad, device failure	Schlecht, Gerätefehler
0	0	0	1	0	0	x	x	Bad, sensor failure	Schlecht, Sensorfehler
0	0	0	1	1	1	x	x	Bad, out of service	Schlecht, Außer Betrieb
0	1	0	0	0	0	x	x	Uncertain, non specific	Unsicher
0	1	0	1	0	0	x	x	Uncertain, sensor conversion not accurate	Unsicher, Wert ungenau
0	1	0	1	1	1	x	x	Uncertain, configuration error	Unsicher, Konfigurationsfehler
0	1	1	0	0	0	x	x	Uncertain, simulated value	Unsicher, Simulationswert
1	0	0	0	0	0	x	x	Good, ok	Gut, Ok
1	0	0	0	0	1	x	x	Good, update event	Gut, Aktiver Blockalarm
1	0	1	0	0	1	x	x	Good, maintenance required	Gut, Instandhaltungsbedarf
1	1	0	0	0	0	x	x	Good (Cascade), ok	Gut (Kaskade), Ok
1	1	0	0	0	1	x	x	Good (Cascade), initialisation acknowledged	Gut (Kaskade), Initialisierung bestätigt
1	1	0	0	1	0	x	x	Good (Cascade), initialisation request	Gut (Kaskade), Initialisierung angefordert
1	1	0	0	1	1	x	x	Good (Cascade), not invited	Gut (Kaskade), Nicht eingeladen
1	1	0	1	1	0	x	x	Good (Cascade), local override	Gut (Kaskade), Vor-Ort-Bedienung
1	1	1	0	0	0	x	x	Good (Cascade), initiate fail safe	Gut (Kaskade), Sicherheitsstellung anfahren

### 9.3.3.5 Sub-status for activated condensed status

Bits								Name		Group
7	6	5	4	3	2	1	0	Profile	German	
0	0	1	0	0	1	x	x	Bad, maintenance alarm	Schlecht, Instandhaltungsalarm	M
0	0	1	0	1	0	x	x	Bad, process related, no maintenance	Schlecht, Prozess-Störung, kein Wartungsbedarf	P
0	0	1	1	1	1	x	x	Bad, function check /local override; value not usable	Schlecht, Funktion überprüfen / Handbetrieb	F
0	1	1	0	1	0	x	x	Uncertain, maintenance demand	Uncertain, maintenance demand	M

9.3 Cyclic data transfer

Bits								Name		Group
7	6	5	4	3	2	1	0	Profile	German	
0	1	1	1	1	0	x	x	Uncertain, process related, no maintenance	Unsicher, Prozess-Störung, kein Wartungsbedarf	P
1	0	0	0	0	0	x	x	Good, ok	Gut, Ok	-
1	0	1	0	0	1	x	x	Good, maintenance required	Gut, Instandhaltungsbedarf	M1, M12, M
1	0	1	0	1	0	x	x	Good, maintenance demand	Good, maintenance requirement	M12, M
1	0	1	1	1	1	x	x	Good, function check	Gut, Funktion überprüfen / Handbetrieb	F

**9.3.3.6 List of diagnostics events with status and diagnostics message for deactivated condensed status**

A list of diagnostics events with status and diagnostics message for deactivated condensed status is given in the following table. DIAGNOSTICS\_EXTENSION and DIAGNOSTICS\_EXTENSION\_2 are physical block parameters.

**DIAGNOSTICS\_EXTENSION physical block parameter**

Byte	Bit	No.	Diagnostics events	Hard-coded effect of a diagnostics event	
				Quality status code	DIAGNOSTICS bit
0	0	1	Run time error of the actuator	Bad, maintenance requirement	DIA_SUPPLY
	1	2	The device is not in the "Automatic mode"	Uncertain, simulation value	None
	2	3	Binary 1 is active (only message)	Good, maintenance required	DIA_MAINTENANCE
	3	4	Action triggered by binary input 1	Uncertain, simulation value	None
	4	5	Binary 2 is active (only message)	Good, maintenance required	DIA_MAINTENANCE
	5	6	Action triggered by binary input 2	Uncertain, simulation value	None
		7 ... 21	Reserved	-	-
2	5	22	Limit for alarm A1 exceeded	Good, maintenance required	DIA_MAINTENANCE
	6	23	Limit for alarm A2 exceeded	Good, maintenance required	DIA_MAINTENANCE
	7	24	Error in the device electronic unit	Bad, device error	DIA_MEM_CHKSUM

Byte	Bit	No.	Diagnostics events	Hard-coded effect of a diagnostics event	
				Quality status code	DIAGNOSTICS bit
3	0	25	The device is not yet ready for operation (not initialized)	Bad, configuration error	DIA_NOT_INIT
	1	26	The device is not yet ready for operation (initialization error)	Bad, configuration error	DIA_INIT_ERR
	3	27	Reserved	-	-
	3	28	Reserved	-	-
	4	29	Device in the Manual mode (FB in the Manual mode)	Depends on the set status	None
	5	30	Device in the Simulation mode (FEEDBACK is simulated)	Depends on the simulated status	None
	6	31	Device in the TRACE mode	-	None
	7	32	Diagnostics simulation (diagnostics events are simulated)	Depends on the simulated diagnostics event	Depends on the simulated diagnostics event
			33 ... 48	Reserved	-

**DIAGNOSTICS\_EXTENSION\_2 physical block parameter**

Byte	Bit	No.	Diagnostics events	Hard-coded effect of a diagnostics event	
				Quality status code	DIAGNOSTICS bit
0	0	49	General control valve fault (limit 1)	Good, maintenance required	DIA_MAINTENANCE
	1	50	General control valve fault (limit 2)	Good, maintenance required	DIA_MAINTENANCE
	2	51	General control valve fault (limit 3)	Good, maintenance required	DIA_MAINTENANCE
	3	52	Pneumatic leakage (limit 1)	Good, maintenance required	DIA_MAINTENANCE
	4	53	Pneumatic leakage (limit 2)	Good, maintenance required	DIA_MAINTENANCE
	5	54	Pneumatic leakage (limit 3)	Good, maintenance required	DIA_MAINTENANCE
	6	55	Static friction (limit 1)	Good, maintenance required	DIA_MAINTENANCE
	7	56	Static friction (limit 2)	Good, maintenance required	DIA_MAINTENANCE
1	0	57	Static friction (limit 3)	Good, maintenance required	DIA_MAINTENANCE
	1	58	Lower end stop monitoring (limit 1)	Good, maintenance required	DIA_ZERO_ERR
	2	59	Lower end stop monitoring (limit 2)	Good, maintenance required	DIA_ZERO_ERR
	3	60	Lower end stop monitoring (limit 3)	Good, maintenance required	DIA_ZERO_ERR
	4	61	Upper end stop monitoring (limit 1)	Good, maintenance required	DIA_ZERO_ERR
	5	62	Upper end stop monitoring (limit 2)	Good, maintenance required	DIA_MAINTENANCE
	6	63	Upper end stop monitoring (limit 3)	Good, maintenance required	DIA_MAINTENANCE
	7	64	Limit 1 for path integral (100% strokes) exceeded	Good, maintenance required	DIA_MAINTENANCE

9.3 Cyclic data transfer

Byte	Bit	No.	Diagnostics events	Hard-coded effect of a diagnostics event	
				Quality status code	DIAGNOSTICS bit
2	0	65	Limit 2 for path integral (100% strokes) exceeded	Good, maintenance required	DIA_MAINTENANCE
	1	66	Limit 3 for path integral (100% strokes) exceeded	Good, maintenance required	DIA_MAINTENANCE
	2	67	Limit 1 for changes of direction exceeded	Good, maintenance required	DIA_MAINTENANCE
	3	68	Limit 2 for changes of direction exceeded	Good, maintenance required	DIA_MAINTENANCE
	4	69	Limit 3 for changes of direction exceeded	Good, maintenance required	DIA_MAINTENANCE
	5	70	Limit 1 for position average exceeded	Good, maintenance required	DIA_MAINTENANCE
	6	71	Limit 2 for position average exceeded	Good, maintenance required	DIA_MAINTENANCE
	7	72	Limit 3 for position average exceeded	Good, maintenance required	DIA_MAINTENANCE
3	0	73	PST reference time exceeded (limit 1)	Good, maintenance required	DIA_MAINTENANCE
	1	74	PST reference time exceeded (limit 2)	Good, maintenance required	DIA_MAINTENANCE
	2	75	PST reference time exceeded (limit 3)	Good, maintenance required	DIA_MAINTENANCE
		76 ... 80	Reserved	-	-
4	0	81	Permissible device temperature exceeded (limit 1)	Good, maintenance required	DIA_TEMP_ELECTR
	1	82	Permissible device temperature exceeded (limit 2)	Good, maintenance required	DIA_TEMP_ELECTR
	2	83	Permissible device temperature exceeded (limit 3)	Good, maintenance required	DIA_TEMP_ELECTR
	3	84	Permissible device temperature undershot (limit 1)	Good, maintenance required	DIA_TEMP_ELECTR
	4	85	Permissible device temperature undershot (limit 2)	Good, maintenance required	DIA_TEMP_ELECTR
	5	86	Permissible device temperature undershot (limit 3)	Good, maintenance required	DIA_TEMP_ELECTR
	6	87	Limit for dead zone monitoring exceeded	Good, maintenance required	DIA_TEMP_ELECTR
		88 ... 96	Reserved	-	-

**9.3.3.7 List of diagnostics events with status and diagnostics message for activated condensed status**

A list of diagnostics events with status and diagnostics message for activated condensed status is given in the following table. DIAGNOSTICS\_EXTENSION and DIAGNOSTICS\_EXTENSION\_2 are physical block parameters.

Different status and diagnostics messages can be allocated to individual diagnostics events as per the following tables. The frame in which an allocation is possible is defined by the group in the selection column. The following principle is used: in case of three-stage diagnostics events of the MAINTENANCE group, the effect of the higher lever events can be downgraded, but that of the lower level events cannot be upgraded.

**DIAGNOSTICS\_EXTENSION physical block parameter**

Byte	Bit	No.	Diagnostics events	Effect of the event <sup>1)</sup>		Group
				Quality status code	DIAGNOSTICS bit	
0	0	1	Run time error of the actuator	Good, Ok	DIA_MAINTENANCE_ALARM	M
	1	2	The device is not in the "Automatic mode"	Good, check function / manual mode	DIA_FUNCTION_CHECK	F
	2	3	Binary 1 is active (only message)	Good, Ok	DIA_MAINTENANCE_DEMANDED	M, F, P
	3	4	Action triggered by binary input 1	Good, Ok	DIA_FUNCTION_CHECK	M, F, P
	4	5	Binary 2 is active (only message)	Good, Ok	DIA_MAINTENANCE_DEMANDED	M, F, P
	5	6	Action triggered by binary input 2	Good, Ok	DIA_FUNCTION_CHECK	M, F, P
		7 ... 21	Reserved	-	-	-
2	5	22	Limit for alarm A1 exceeded	Good, maintenance requirement	DIA_MAINTENANCE	None, hard-coded
	6	23	Limit for alarm A2 exceeded	Good, maintenance requirement	DIA_MAINTENANCE	None, hard-coded
	7	24	Error in the device electronic unit	Bad, maintenance requirement	DIA_MAINTENANCE_ALARM	None, hard-coded

9.3 Cyclic data transfer

Byte	Bit	No.	Diagnostics events	Effect of the event <sup>1)</sup>		Group
				Quality status code	DIAGNOSTICS bit	
3	0	25	The device is not yet ready for operation (not initialized)	Bad, maintenance requirement	DIA_MAINTENANCE_ALARM	None, hard-coded
	1	26	The device is not yet ready for operation (initialization error)	Bad, maintenance requirement	DIA_MAINTENANCE_ALARM	None, hard-coded
	3	27	Reserved	-	-	-
	3	28	Reserved	-	-	-
	4	29	Device in the Manual mode (FB in the Manual mode)	-	DIA_FUNCTION_CHECK	None, hard-coded
	5	30	Device in the Simulation mode (FEEDBACK is simulated)	Depends on the simulated status	DIA_FUNCTION_CHECK	None, hard-coded
	6	31	Device in the TRACE mode	-	DIA_FUNCTION_CHECK	None, hard-coded
	7	32	Diagnostics simulation (diagnostics events are simulated)	Depends on the simulated diagnostics event	Depends on the simulated diagnostics event	-
		33 ... 48	Reserved	-	-	-

<sup>1)</sup> Effects of the event can be set using the DIAG\_EVENT\_SWITCH or DIAG\_EVENT\_SWITCH\_2 parameters (default settings in this case)

**DIAGNOSTICS\_EXTENSION\_2 physical block parameter**

Byte	Bit	No.	Diagnostics events	Effect of the event <sup>1)</sup>		Group
				Quality status code	DIAGNOSTICS bit	
0	0	49	General control valve fault (limit 1)	Good, maintenance requirement	DIA_MAINTENANCE	M1
	1	50	General control valve fault (limit 2)	Good, maintenance requirement	DIA_MAINTENANCE_DEMANDED	M12
	2	51	General control valve fault (limit 3)	Uncertain, maintenance demand	DIA_MAINTENANCE_ALARM	M
	3	52	Pneumatic leakage (limit 1)	Good, maintenance requirement	DIA_MAINTENANCE	M1
	4	53	Pneumatic leakage (limit 2)	Good, maintenance demand	DIA_MAINTENANCE_DEMANDED	M12
	5	54	Pneumatic leakage (limit 3)	Uncertain, maintenance demand	DIA_MAINTENANCE_ALARM	M
	6	55	Static friction (limit 1)	Good, maintenance requirement	DIA_MAINTENANCE	M1
	7	56	Static friction (limit 2)	Good, maintenance demand	DIA_MAINTENANCE_DEMANDED	M12



Byte	Bit	No.	Diagnostics events	Effect of the event <sup>1)</sup>		
				Quality status code	DIAGNOSTICS bit	Group
1	0	57	Static friction (limit 3)	Uncertain, maintenance demand	DIA_MAINTENANCE_ALARM	M
	1	58	Lower end stop monitoring (limit 1)	Good, maintenance requirement	DIA_MAINTENANCE	M1
	2	59	Lower end stop monitoring (limit 2)	Good, maintenance demand	DIA_MAINTENANCE_DEMANDED	M12
	3	60	Lower end stop monitoring (limit 3)	Uncertain, maintenance demand	DIA_MAINTENANCE_ALARM	M
	4	61	Upper end stop monitoring (limit 1)	Good, maintenance requirement	DIA_MAINTENANCE	M1
	5	62	Upper end stop monitoring (limit 2)	Good, maintenance demand	DIA_MAINTENANCE_DEMANDED	M12
	6	63	Upper end stop monitoring (limit 3)	Uncertain, maintenance demand	DIA_MAINTENANCE_ALARM	M
	7	64	Limit 1 for path integral (100% strokes) exceeded	Good, maintenance requirement	DIA_MAINTENANCE	M1
2	0	65	Limit 2 for path integral (100% strokes) exceeded	Good, maintenance demand	DIA_MAINTENANCE_DEMANDED	M12
	1	66	Limit 3 for path integral (100% strokes) exceeded	Uncertain, maintenance demand	DIA_MAINTENANCE_ALARM	M
	2	67	Limit 1 for changes in direction exceeded	Good, maintenance requirement	DIA_MAINTENANCE	M1
	3	68	Limit 2 for changes of direction exceeded	Good, maintenance demand	DIA_MAINTENANCE_DEMANDED	M12
	4	69	Limit 3 for changes of direction exceeded	Uncertain, maintenance demand	DIA_MAINTENANCE_ALARM	M
	5	70	Limit 1 for position average exceeded	Good, maintenance requirement	DIA_MAINTENANCE	M1, P
	6	71	Limit 2 for position average exceeded	Good, maintenance demand	DIA_MAINTENANCE_DEMANDED	M12, P
	7	72	Limit 3 for position average exceeded	Uncertain, maintenance demand	DIA_MAINTENANCE_ALARM	M, P
3	0	73	PST reference time exceeded (limit 1)	Good, maintenance requirement	DIA_MAINTENANCE	M1
	1	74	PST reference time exceeded (limit 2)	Good, maintenance demand	DIA_MAINTENANCE_DEMANDED	M12
	2	75	PST reference time exceeded (limit 3)	Uncertain, maintenance demand	DIA_MAINTENANCE_ALARM	M
		76 ... 80	Reserved	-	-	-

9.3 Cyclic data transfer

Byte	Bit	No.	Diagnostics events	Effect of the event <sup>1)</sup>		
				Quality status code	DIAGNOSTICS bit	Group
4	0	81	Permissible device temperature exceeded (limit 1)	Uncertain, process fault, no maintenance required	DIA_INV_PRO_COND	M1, P
	1	82	Permissible device temperature exceeded (limit 2)	Uncertain, process fault, no maintenance required	DIA_INV_PRO_COND	M12, P
	2	83	Permissible device temperature exceeded (limit 3)	Uncertain, process fault, no maintenance required	DIA_INV_PRO_COND	M, P
	3	84	Permissible device temperature undershot (limit 1)	Uncertain, process fault, no maintenance required	DIA_INV_PRO_COND	M1, P
	4	85	Permissible device temperature undershot (limit 2)	Uncertain, process fault, no maintenance required	DIA_INV_PRO_COND	M12, P
	5	86	Permissible device temperature undershot (limit 3)	Uncertain, process fault, no maintenance required	DIA_INV_PRO_COND	M, P
	6	87	Limit for dead zone monitoring exceeded	Uncertain, maintenance demand	DIA_MAINTENANCE_ALARM	M
		88 ... 96	Reserved	-	-	-

<sup>1)</sup> Effects of the event can be set using the DIAG\_EVENT\_SWITCH or DIAG\_EVENT\_SWITCH\_2 parameters (default settings in this case)

## Functional safety

### 10.1 Range of applications for functional safety

The positioner is suitable for use on valves that satisfy the special requirements in terms of functional safety up to SIL 2 in accordance with IEC 61508 or IEC 61511. The 6DR5.1.-0....-.....-Z C20 versions are available for this.

These are single-acting positioners for mounting on pneumatic actuators with spring return.

The positioner automatically depressurizes the valve actuator on demand or in case of faults, which thus switches the valve to the specified safety position.

This positioner meets the following requirement:

- Functional safety up to SIL 2 in accordance with IEC 61508 or IEC 61511 for safe venting

#### See also

Functional safety in process instrumentation (<http://www.siemens.com/SIL>)

### 10.2 Safety function

#### Safety function on positioner

Depressurizing of the connected actuator is the safety function for the positioner. The built-in spring brings the valve to the required safety position. Depending on the direction of action of this spring, the valve is completely opened or closed.

This safety function can be triggered by:

- The signal at the input for the safety shutdown (terminals 81 and 82) is  $< 4.5$  V.  
This function is also referred to as "safety shutdown" in the device documentation.
- Failure of the auxiliary power supply via the bus connection.

The safety function is not affected by other device functions, particularly the microcontroller, software and communication interface. With respect to this safety function, the positioner must therefore be considered as a type A subsystem in accordance with EN 61508-2.

Situations in which it is not possible to depressurize the actuator on demand or in the case of a fault represent a dangerous failure.

**⚠ WARNING**

**Disregarding conditions for fulfilling the safety function**

Disregarding conditions can result in a malfunction of the process system or application, for example, process pressure too high, maximum level exceeded.

The mandatory settings and conditions are listed in sections Settings (Page 238) and Safety characteristics (Page 239).

- These conditions must be met in order to fulfill the safety function.


The pneumatic block of the positioner pressurizes and depressurizes the actuator. The pneumatic block contains two pilot valves. The characteristic service life of the pneumatic block depends on the load. On average it is approx. 200 million switching cycles for each of the two pilot valves with symmetrical load. The number of control procedures for the switching cycles is called in the local display or via the communication function. For more details, see Diagnostic value '42.VENT1' / '43.VENT2' (Page 268).

**NOTICE**

**Freezing of the exhaust air outlets**

When devices of the type 6DR5..0/1/2/3 are used, the exhaust air outlets ② may freeze. The function of the device is impaired.

- Do **not** install the positioner with the base plate ① pointing up.



① Base plate

② Exhaust air outlets

Figure 10-1 Exhaust air outlets, base plate

### Safety-instrumented system in single-channel operation (SIL 2)




Figure 10-2 Safety-instrumented system in single-channel operation

The combination of transmitter, automation system and final controlling element forms a safety-instrumented system that performs a safety function.

The transmitter generates a process-related measured value that is transferred to the automation system. The automation system monitors this measured value. If the measured value exceeds the range of the high or low limit, the automation system generates a shutdown signal for the connected final controlling element, which switches the associated valve to the specified safety position.

## 10.3 Safety Integrity Level (SIL)

The international standard IEC 61508 defines four discrete Safety Integrity Levels (SIL) from SIL 1 to SIL 4. Each level corresponds to a range of probability for failure of a safety function.

### Description

The following table shows the dependency of the SIL on the "average probability of dangerous failures of a safety function of the entire safety-instrumented system" ( $PFD_{AVG}$ ). The table deals with "Low demand mode", i.e. the safety function is required a maximum of once per year on average.

Table 10-1 Safety Integrity Level

SIL	Interval
4	$10^{-5} \leq PFD_{AVG} < 10^{-4}$
3	$10^{-4} \leq PFD_{AVG} < 10^{-3}$
2	$10^{-3} \leq PFD_{AVG} < 10^{-2}$
1	$10^{-2} \leq PFD_{AVG} < 10^{-1}$

The "average probability of dangerous failures of the entire safety-instrumented system" ( $PFD_{AVG}$ ) is normally split between the following three components:




Figure 10-3 PFD distribution

The following table shows the achievable Safety Integrity Level (SIL) for the entire safety-instrumented system for type A devices depending on the safe failure fraction (SFF) and the hardware fault tolerance (HFT).

- Type A devices include analog transmitters and shut-off valves **without** complex components, e.g. microprocessors (see also IEC 61508, Section 2).
- The specific values for your device are listed in the manufacturer's declaration (SIL Declaration of Conformity, Functional Safety according to IEC 61508 and IEC 61511): Certificates (<http://www.siemens.com/processinstrumentation/certificates>).

SFF	HFT for type A devices		
	0	1	2
< 60%	SIL 1	SIL 2	SIL 3
60 to 90 %	SIL 2	SIL 3	SIL 4
90 to 99 %	SIL 3	SIL 4	SIL 4
> 99%	SIL 3	SIL 4	SIL 4

## 10.4 Settings

**⚠ WARNING**

**Safety function: Positioning "Jumper" on the basic electronics**

The safety function is not activated in the delivered state; the "Jumper" is in the "Normal" position. "Normal" means: Without safety function, no depressurizing of the connected actuator. To activate the safety function, proceed as follows:

- Insert the "Jumper" in the left position facing the terminals. This corresponds to the position "Shut Down enabled" on the wiring diagram present on the module cover, see "Figure 3-6 View of the positioner (cover open; polycarbonate enclosure) (Page 28)".

Or

- Remove the "Jumper" from the basic electronics.

Special parameter settings are not necessary.

### Protection against configuration changes

You should attach the housing cover so that the device is protected against unwanted and unauthorized changes/operation.

## Checking the safety function

### Prerequisite for checking the safety function

- Positioner is in operation.
- The actuator belonging to the positioner is **not** in the safety position.

### Procedure

1. In order to test the safety shutdown, apply a LOW level, i.e. a voltage of maximum 4.5 V, to the input for the safety shutdown.
2. Verify that the valve returns to the safety position.
3. In order to test the response of the actuator, apply a HIGH level, i.e. a voltage >13 V, to the input for the safety shutdown.
4. Set the setpoint to 50% using a local operation (manual operation) or bus communication.
5. Reduce the inlet pressure (PZ) to a third of the maximum supply pressure.
6. Verify that the valve returns to the safety position.
7. Check the filters in the pneumatic connections for contamination and clean them if necessary.

## See also

Overview of device components (Page 28)

Safety function (Page 235)

## 10.5 Safety characteristics

The safety characteristics necessary for use of the system are listed in the SIL declaration of conformity. These values apply under the following conditions:

- The positioner is only used in applications with low demand rate for the "Low demand mode".
- "Jumper" on the basic electronic system was plugged into the left position facing the terminals at position "Shut Down enabled" or removed completely.
- The positioner is blocked against unwanted and unauthorized changes/operation.
- The shut-off signal for the positioner is generated at the input for the safety shutdown (terminals 81 and 82) by a safe system which meets at least SIL 2. The LOW level has a maximum of 4.5 V at the input terminals.
- The connected actuator must be single-acting and return the valve to the safe end position by spring force in the following scenario:
  - At a chamber pressure (Y1 connection) up to a third of the maximum available intake pressure (P<sub>z</sub> connection)
- The air outlet does not contain any additional cross-sectional contractions leading to an increased dynamic pressure. In particular, a silencer is only allowed if icing or other contamination is ruled out.

- The restrictor in the Y1 circuit may not be completely closed during operation.
- The auxiliary pneumatic power is free of oil, water and dirt in line with: DIN/ISO 8573-1, maximum class 3
- The average temperature viewed over a long period is 40 °C.
- Fault rates are calculated on the basis of a mean time to repair (MTTR) of 8 hours.
- In case of a fault, the pneumatic outlet of the positioner is depressurized. A spring in the pneumatic actuator must move the valve to the pre-defined, safe end position.
- A dangerous failure of the positioner is when the pressure outlet is not depressurized, or the safety position is not reached, with a LOW level of maximum 4.5 V at the input for the safety shutdown.

**See also**

Settings (Page 238)

## 10.6 Maintenance/check

**Interval**

We recommend that the functioning of the positioner is checked at regular intervals of one year.

**Checking the safety function**

Check the safety function as detailed in chapter "Settings (Page 238)"

**Checking safety**

Verify the safety function of the entire safety circuit on a regular basis in accordance with IEC 61508/61511. The test intervals are determined in the course of calculations for each safety circuit of a system ( $PFD_{AVG}$ ).



## Service and maintenance

### 11.1 Basic safety instructions

**⚠ WARNING****Impermissible repair of the device**

- Repair must be carried out by Siemens authorized personnel only.

**⚠ WARNING****Dust layers above 5 mm**

Risk of explosion in hazardous areas.

Device may overheat due to dust build up.

- Remove dust layers in excess of 5 mm.

**NOTICE****Penetration of moisture into the device**

Device damage.

- Make sure when carrying out cleaning and maintenance work that no moisture penetrates the inside of the device.

**⚠ CAUTION****Releasing button lock**

Improper modification of parameters could influence process safety.

- Make sure that only authorized personnel may cancel the button locking of devices for safety-related applications.

#### 11.1.1 Cleaning the enclosure

##### Cleaning the enclosure

- Clean the outside of the enclosure with the inscriptions and the display window using a cloth moistened with water or a mild detergent.
- Do not use any aggressive cleansing agents or solvents, e.g. acetone. Plastic parts or the painted surface could be damaged. The inscriptions could become unreadable.

 **WARNING**

**Electrostatic charge**

Risk of explosion in hazardous areas if electrostatic charges develop, for example, when cleaning plastic surfaces with a dry cloth.

- Prevent electrostatic charging in hazardous areas.

## 11.2 Cleaning of the screens

The positioner is maintenance-free to a large extent. Screens are installed in the pneumatic connections of the positioners to protect them from rough dirt particles. If there are dirt particles in the pneumatic auxiliary power supply, they damage the screens and hamper the function of the positioner. Clean the screens as described in the following two chapters.

### 11.2.1 Positioners 6DR5..0, 6DR5..3 and 6DR5..5

#### Procedure for removal and cleaning of the screens

1. Disconnect the pneumatic auxiliary power supply.
2. Remove the pneumatic pipelines.
3. Unscrew the cover of the 6DR5..0 or 6DR5..3 enclosure.
4. Unscrew the three screws on the pneumatic terminal strip.
5. Remove the screens and O-rings behind the terminal strip.
6. Clean the screens, e.g. using compressed air.

#### Procedure for installation of the screens

 **CAUTION**

**Damage to the polycarbonate enclosure 6DR5..0**

- The enclosure is damaged due to screwing in the self-tapping screws improperly.
- Ensure that the available thread pitches are used.
- Turn the screws anticlockwise until they engage noticeably in the thread pitch.
- Tighten the self-tapping screws only after they have engaged.

1. Insert the screens into the recesses of the enclosure.
2. Place the O-rings on the screens.
3. Insert the pneumatic terminal strip.

4. Tighten the three screws. Note: With the polycarbonate enclosure, the screws are self-tapping.
5. Place the cover and tighten it.
6. Connect the pneumatic pipelines again.

## 11.2.2 Positioners 6DR5..1, 6DR5..2 and 6DR5..6

### Removal, cleaning and installation of the screens

1. Disconnect the pneumatic auxiliary power supply.
2. Remove the pneumatic connecting cables.
3. Remove the metal screen from the bores carefully.
4. Clean the metal screens, e.g. using compressed air.
5. Insert the screens.
6. Connect the pneumatic pipelines again.

## 11.3 Maintenance and repair work

### 11.3.1 Maintenance during continued operation in a hazardous area

#### WARNING

##### Maintenance during continued operation in a hazardous area

There is a risk of explosion when carrying out repairs and maintenance on the device in a hazardous area.

- Isolate the device from power.

- or -

- Ensure that the atmosphere is explosion-free (hot work permit).

#### WARNING

##### Impermissible accessories and spare parts

Risk of explosion in areas subject to explosion hazard.

- Only use original accessories or original spare parts.
- Observe all relevant installation and safety instructions described in the instructions for the device or enclosed with the accessory or spare part.

 **WARNING**

**Improper connection after maintenance**

Risk of explosion in areas subject to explosion hazard.

- Connect the device correctly after maintenance.
- Close the device after maintenance work.

Refer to Connect (Page 77).

### 11.3.2 Repair/Upgrading

Send defective devices to the repairs department, together with information on the malfunction and the cause of the malfunction. When ordering replacement devices, please provide the serial number of the original device. You can find the serial number on the nameplate.

#### See also

Nameplate layout (Page 26)

Technical support (Page 311)

## 11.4 Replace basic electronics

### Requirements

- You are familiar with the general procedure described in the section "General information about the installation of option modules (Page 53)".

### Procedure

---

#### Note

##### Possible Movement of the Drive

While replacing the basic electronics, the drive can unintentionally vent itself.

- Observe the procedure described below.
- 

#### Removing

1. Switch off the supply air PZ and depressurize the actuator.
2. Open the positioner as in the description depending on the device version:
  - Opening the standard and intrinsically safe version (Page 53)
  - Opening the device version with "flameproof enclosure" (Page 56)

3. Remove the ribbon cable from the basic electronics.
4. Remove the two mounting screws of the basic electronics.
5. Remove the basic electronics.
6. Place the new basic electronics onto the four holders of the rack.

### **Installing**

1. Tighten the two mounting screws of the basic electronics.
2. Tighten the screws.
3. Close the positioner as in the description depending on the device version:
  - Closing the standard and intrinsically safe version (Page 55)
  - Closing the device version with "flameproof enclosure" (Page 59)
4. For a positioner with order option -Z F01 "Fail in Place", adjust the parameter "49.PNEUM" from "Std" to "FIP".
5. Switch on the supply air PZ again.
6. Initialize the positioner as described in section "Commissioning (Page 107)".

### **See also**

'51.FSTY' Safety position (Page 161)

## **11.5 Replace pneumatic block**

### **Requirement**

- You are familiar with the general procedure described in the section "General information about the installation of option modules (Page 53)".

**Procedure**




Figure 11-1 Pneumatic block

**Removing**

1. Switch off the supply air PZ and depressurize the actuator.
2. Open the positioner as in the description depending on the device version:
  - Opening the standard and and intrinsically safe version (Page 53)
  - Opening the device version with "flameproof enclosure" (Page 56)
3. Remove the ribbon cable from the basic electronics.
4. Tighten the two fixing screws of the basic electronics.
5. Remove the basic electronics.
6. Remove the fixing screws ③ of the pneumatic block ②.  
 Four screws for the single-acting pneumatic block. Five screws for the double-acting pneumatic block.
7. Remove the pneumatic block ② and the cord seal ①.
8. Blow the existing dirt from the surface on which the pneumatic block was placed.

**Installation**

1. Insert the new cord seal ① into the new pneumatic block ②.
2. Press the cord seal ① into the groove on the pneumatic block ② on all sides.
3. Place the new pneumatic block on the base plate.  
 Make sure that the pneumatic block engages with the centering elements ④ on the baseplate.
4. Screw the supplied fixing screws ③ into the pneumatic block.
5. Tighten the fixing screws with a torque of 1.1 Nm.
6. Place the new basic electronics onto the four holders of the rack.
7. Tighten the two fixing screws of the basic electronics.
8. Tighten the fixing screws.

9. Close the positioner as in the description depending on the device version:
  - Closing the standard and intrinsically safe version (Page 55)
  - Closing the device version with "flameproof enclosure" (Page 59)
10. For a positioner with order option -Z F01 "Fail in Place", adjust the "'49.PNEUM' Pneumatics type (Page 159)" parameter from "Std" to "FIP".
11. Switch on the supply air PZ again.
12. Initialize the positioner as described in section "Commissioning (Page 107)".


## 11.6 Return procedure

Enclose the bill of lading, return document and decontamination certificate in a clear plastic pouch and attach it firmly to the outside of the packaging.

### Required forms

- Delivery note
- Return document (<http://www.siemens.com/processinstrumentation/returngoodsnote>) with the following information:
  - Product (item description)
  - Number of returned devices/replacement parts
  - Reason for returning the item(s)
- Decontamination declaration (<http://www.siemens.com/sc/declarationofdecontamination>)  
With this declaration you warrant "that the device/replacement part has been carefully cleaned and is free of residues. The device/replacement part does not pose a hazard for humans and the environment."  
If the returned device/replacement part has come into contact with poisonous, corrosive, flammable or water-contaminating substances, you must thoroughly clean and decontaminate the device/replacement part before returning it in order to ensure that all hollow areas are free from hazardous substances. Check the item after it has been cleaned. Any devices/replacement parts returned without a decontamination declaration will be cleaned at your expense before further processing.

## 11.7 Disposal



Devices described in this manual should be recycled. They may not be disposed of in the municipal waste disposal services according to the Directive 2012/19/EC on waste electronic and electrical equipment (WEEE).

Devices can be returned to the supplier within the EC, or to a locally approved disposal service for eco-friendly recycling. Observe the specific regulations valid in your country.

Further information about devices containing batteries can be found at: Information on battery/product return (WEEE) (<https://support.industry.siemens.com/cs/document/109479891/>)



## Diagnostics and troubleshooting


### 12.1 Output of system messages in the display

#### 12.1.1 System messages during operation

Remarks about the tables:

- nn        Stands for variable numeric values
- ↳        Error symbol
- /        (slash): the texts on the left and right of the slash flash alternately

#### Messages during operation

Message	Line		Operating mode			Meaning / cause	Measure
	Up	Down	Auto- matic	Manual mode	P man- ual mode		
CPU START	X					Message after application of electrical auxiliary power.	• Wait.
HW / ERROR		X				Fault in the hardware.	• Replace electronics.
NOINI		X			X	Positioner is not initialized.	• Start initialization.
nnn.n	X		X	X		Actual position [in %] for initialized positioner. Flashing decimal point shows communication with a class 2 master.	
AUTnn		X	X			Automatic mode (nn = setpoint)	
MANnn		X		X		Manual mode (nn = setpoint)	• Switch to automatic mode with  .
oFL / 127.9	X		X	X		Display range exceeded. Possible causes: <ul style="list-style-type: none"> <li>• Friction clutch or</li> <li>• Transmission ratio selector was moved or</li> <li>• Positioner was installed on a different actuator without being re-initialized.</li> </ul>	<ul style="list-style-type: none"> <li>• Offset friction clutch so that, when the actuator moves, the actual value display stays between 0.0 and 100.0, or</li> <li>• Switch the transmission ratio selector or</li> <li>• Perform factory settings (Preset) and initialization.</li> </ul>
EXSTP		X	X			Actuator was stopped by the binary input.	

12.1 Output of system messages in the display

Message	Line		Operating mode			Meaning / cause	Measure
	Up	Down	Auto-matic	Manual mode	P manual mode		
EX UP		X	X			Actuator is moved to the upper endstop by the binary input.	
EXDWN		X	X			Actuator is moved to the lower endstop by the binary input.	
EXPSt						The partial stroke test was activated, e.g. by the binary input.	
InPSt						Cyclic partial stroke test.	
FST		X	X			Full stroke test running.	
SRT		X	X			Step response test running.	
MSRT		X	X			Multi-step response test running.	
VPT		X	X			Valve performance test running.	
LEAKR		X	X			A leakage test started by communication is running.	

12.1.2 System messages before initialization

Remarks about the tables:

- nn        Stands for variable numeric values
- ↳        Error symbol
- /        (slash): the texts on the left and right of the slash flash alternately

Messages before initialization (first commissioning)

Message	Line		Meaning / cause	Measure
	Up	Down		
CPU Start	X	X	Message after application of electrical auxiliary power	<ul style="list-style-type: none"> <li>• Maintenance</li> </ul>
Pnnn.n	X		Potentiometer voltage of a non-initialized positioner (P-manual mode) (actual position value in % of the measuring range).	<ul style="list-style-type: none"> <li>• Check whether the complete travel can be covered using the ▲ and ▼ buttons and that "P---" is never displayed.</li> <li>• Execute the initialization process.</li> </ul>
P---	X		Measuring range was exceeded, the potentiometer is in the inactive zone, the transmission ratio selector or the effective lever arm are not adjusted as per the actuator travel.	<ul style="list-style-type: none"> <li>• Switch the transmission ratio selector to 90°, especially in the case of part-turn actuators.</li> <li>• Adjust the effective lever length of linear actuators as per the measuring range.</li> </ul>
NOINI		X	Positioner is not initialized.	<ul style="list-style-type: none"> <li>• Start initialization.</li> </ul>

**See also**

Display (Page 97)

**12.1.3 System messages during initialization**







Remarks about the tables:

nn Stands for variable numeric values

⌋ Error symbol

/ (slash): the texts on the left and right of the slash flash alternately

**Messages during initialization**

Message	Line		Meaning/cause	Measure
	Up	Down		
P---	X		Measuring range was exceeded, the potentiometer is in the inactive zone, the transmission ratio selectors or the effective lever arm are not adjusted as per the actuator travel	<ul style="list-style-type: none"> <li>Switch the transmission ratio selector to 90°, especially in the case of part-turn actuators.</li> <li>Adjust the effective lever length of linear actuators as per the measuring range.</li> </ul>
RUN 1		X	Initialization was started, part 1 is active (the direction of action is determined)	<ul style="list-style-type: none"> <li>Wait.</li> </ul>
RUN 2		X	Initialization part 2 is active (actuator travel check and determination of stops)	<ul style="list-style-type: none"> <li>Wait.</li> </ul>
RUN 3		X	Initialization part 3 is active (determination and display of travel times)	<ul style="list-style-type: none"> <li>Wait.</li> </ul>
RUN 4		X	Initialization part 4 is active (determination of the minimum controller increment length)	<ul style="list-style-type: none"> <li>Wait.</li> </ul>
RUN 5		X	Initialization part 5 is active (optimization of the transient response)	<ul style="list-style-type: none"> <li>Wait until "FINSH" is displayed. Initialization was completed successfully.</li> </ul>
YEND1		X	The first position of the stop can be approached only in case of a manual initialization	<ol style="list-style-type: none"> <li>Approach first position of the stop with the button  or .</li> <li>Acknowledge using  button.</li> </ol>
YEND2		X	The second position of the stop can be approached only in case of a manual initialization	<ol style="list-style-type: none"> <li>Approach second position of the stop with the button  or .</li> <li>Acknowledge using  button.</li> </ol>

12.1 Output of system messages in the display

Message	Line		Meaning/cause	Measure
	Up	Down		
RANGE		X	The position of the stop or the measuring span is beyond the permissible measuring range only in case of a manual initialization	<ul style="list-style-type: none"> <li>Approach a different position of the stop using  or  button and acknowledge using  button.</li> <li>Move the friction clutch until "ok" is displayed, and then acknowledge with the  button.</li> <li>Terminate the initialization process using the  button, switch to the P-manual mode, and correct the actuator travel and the position displacement sensor.</li> </ul>
ok		x	The permissible measuring range of end positions is achieved only in case of a manual initialization	<ul style="list-style-type: none"> <li>Use the  button to acknowledge; the remaining steps ("RUN 1" to "FINSH") run automatically.</li> </ul>
RUN 1 / ERROR		X	Error in "RUN 1", no movement e.g. due to the lack of compressed air	<p>Possible causes:</p> <ul style="list-style-type: none"> <li>Insufficient supply of compressed air.</li> <li>Restrictor(s) blocked.</li> <li>Actuator does not move freely.</li> </ul> <p>Measures:</p> <ol style="list-style-type: none"> <li>Eliminate possible causes.</li> <li>Restart initialization.</li> </ol>
hd__U		X	Bar graph display of the zero point is outside the tolerance range	<ol style="list-style-type: none"> <li>Set between "P 4.0" and "P 9.9" ( &gt;0&lt; ) using friction clutch.</li> <li>Continue using  or  button.</li> </ol>
SEt	X		Friction clutch was moved; "P 50.0" not displayed when the lever is horizontal	<ol style="list-style-type: none"> <li>In the case of linear actuators, use the  or  button to bring the lever perpendicular to the spindle.</li> <li>Briefly acknowledge using  button (initialization is continued).</li> </ol>
MIDDL		X		
hUP >		X	"UP" tolerance range was exceeded or the inactive zone of the potentiometer was covered.	<ol style="list-style-type: none"> <li>Increase the effective lever length of the linear actuators or switch the transmission ratio selector to 90°.</li> <li>Briefly acknowledge using  button.</li> <li>Restart initialization.</li> </ol>
h90_95		X	Possible only in case of part-turn actuators: actuator travel is not in the range between 90 and 95%	<ol style="list-style-type: none"> <li>Use the  or  button to move it in the range between 90 and 95%.</li> <li>Briefly acknowledge using  button.</li> </ol>
hU-d>		X	"Up-Down" measuring span was undershot	<ol style="list-style-type: none"> <li>Decrease the effective lever length of the linear actuators or switch the transmission ratio selector to 33°.</li> <li>Briefly acknowledge using  button.</li> <li>Restart initialization.</li> </ol>

Message	Line		Meaning/cause	Measure
	Up	Down		
U nn.n	X		Display of the "Up" travel time	<ul style="list-style-type: none"> <li>Wait until initialization continues in RUN 4.</li> <li>To change the travel time, interrupt the initialization process using the ▽ button.</li> <li>Activate the leakage test using the ▲ button.</li> </ul>
D->U		X		
D nn.n	X		Display of the "Down" travel time	<ul style="list-style-type: none"> <li>Wait until initialization continues in RUN 4.</li> <li>To change the travel time, interrupt the initialization process using the ▽ button.</li> <li>Activate the leakage test using the ▲ button.</li> </ul>
U->d		X		
NOZZL		X	Actuator stops (the initialization process was interrupted using the "-" button when the actuation speed display was active)	<ol style="list-style-type: none"> <li>The travel time can be changed by adjusting the restrictor(s).</li> <li>Redetermine the positioning speed using the ▽ button.</li> <li>Continue using ▲ button.</li> </ol>
TEST	X		Leakage test active (the "+" button was pressed when the actuation speed display was active)	<ul style="list-style-type: none"> <li>Wait for one minute.</li> </ul>
LEAKG		X		
nn.n	X		Value and unit of the result after the leakage test	<ul style="list-style-type: none"> <li>Rectify the leakage if the value is too large.</li> <li>Continue using ▲ button.</li> </ul>
%/MIN		X		
nn.n	X		Initialization completed successfully with the display of actuator travel or the actuator angle	<ol style="list-style-type: none"> <li>Briefly acknowledge using ☒ button.</li> <li>Leave configuration level with a long press on the ☒ button.</li> </ol>
FINISH		X		

### See also

System messages before initialization (Page 250)

### 12.1.4 System messages when exiting the Configuration mode

Remarks about the tables:

- nn        Stands for variable numeric values
- ↳        Error symbol
- /        (slash): the texts on the left and right of the slash flash alternately

**Messages when exiting the configuration mode:**

Message	Line		Operating mode			Meaning / cause	Measure
	Up	Bot- tom	Automatic	Manual mode	P manual mode		
n.nn.nn- nn	X	X				Software version	• Maintenance
Error SLnn	X	X				Monotony interrup- tion of the free charac- teristic on the setpoint turning point n	• Correct the value

**12.1.5 System messages during operation**

Remarks about the tables:

nn        Stands for variable numeric values

↳        Error symbol

/        (slash): the texts on the left and right of the slash flash alternately

**Messages during operation:**

Message	Line		Operating mode			Meaning/cause	Measure
	Top	Bot- tom	Auto- matic	Manual	P-man- ual		
CPU START	X	X				Message after application of elec- trical auxiliary power.	• Wait.
HW / ER- ROR		X				Fault in the hardware.	• Replace electronics.
NOINI		X			X	Positioner is not initialized.	• Start initialization.
nnn.n	X		X	X		Actual position [in %] for initial- ized positioner. Flashing decimal point shows communication with a class 2 master.	
AUnn		X	X			Automatic mode (nn = setpoint)	
FS -- --		X	X			Failsafe (the vent valve is opened). Possible causes:	
						<ul style="list-style-type: none"> <li>• No communication connec- tion to master.</li> <li>• Target mode is at "MA".</li> <li>• Master sends a wrong status.</li> </ul>	<ul style="list-style-type: none"> <li>• Correct the station ad- dress.</li> <li>• Set the target mode with class-2 master to "Automatic".</li> <li>• Send the "0x80" status (good).</li> </ul>

## 12.1 Output of system messages in the display

Message	Line		Operating mode			Meaning/cause	Measure
	Top	Bot- tom	Auto- matic	Manual	P-man- ual		
FS nn		X	X			Controlled using the configured failsafe position (Cause: see above).	See above
MM nn		X	X			Positioner is in "Manual" mode.	<ul style="list-style-type: none"> <li>Set the target mode with class-2 master to "Automatic".</li> <li>Send the "0x80" status (good).</li> </ul>
MAnn				X		Manual mode (nn = setpoint)	<ul style="list-style-type: none"> <li>Switch to automatic mode using operating mode button.</li> </ul>
LO nn		X	X			Positioner is in "Local override" mode.	<ul style="list-style-type: none"> <li>Set the target mode with class-2 master to "Automatic".</li> <li>Send the "0x80" status (good).</li> </ul>
OS --	X		X	X		Positioner is in "Out of service" mode.	<ul style="list-style-type: none"> <li>Set the target mode with class-2 master to "Automatic".</li> <li>Send the "0x80" status (good).</li> </ul>
oFL / 127.9						Display range exceeded.	<ul style="list-style-type: none"> <li>Adjust friction clutch so that when the actuator moves, the actual value display stays between 0.0 and 100.0, or</li> <li>Adjust the transmission ratio selector or</li> <li>Perform factory settings (preset) and initialization</li> </ul>
						Possible causes: <ul style="list-style-type: none"> <li>Friction clutch or</li> <li>Transmission ratio selector moved or</li> <li>Positioner was installed on a different actuator without being reinitialized</li> </ul>	
EXSTP		X	X			Actuator was stopped by the binary input.	
EX UP		X	X			Actuator is moved to the upper endstop by the binary input.	
EXDWN		X	X			Actuator is moved to the lower endstop by the binary input.	
EXPSt						The partial stroke test was activated, e.g. by a binary input.	
InPst						Cyclic partial stroke test.	
FST		X	X			Full stroke test running.	
SRT		X	X			Step response test running.	

Message	Line		Operating mode			Meaning/cause	Measure
	Top	Bot- tom	Auto- matic	Manual	P-man- ual		
MSRT		X	X			Multi-step response test running.	
VPT		X	X			Valve performance test running.	
LEAKR		X	X			A leakage test started by communication is running.	

## 12.2 Diagnostics

### 12.2.1 Display of diagnostics values



#### Structure of the diagnostics display

The display in "Diagnostics" mode has a structure similar to that in "Configuration" mode:



- The upper line shows the value of the diagnostics variable.
- The lower line shows the number and the abbreviation of the displayed variable.

Some diagnostics value can be greater than 99999. In such a case, the display switches over to the exponential view. Example: The value "1234567" is shown as "1.23E6".


#### General procedure

1. Press all three buttons at the same time for at least 2 seconds. You are now in the diagnostics display.
2. Use the  button to select the next diagnostics value.
3. Press the  button for at least 2 seconds in order to exit the diagnostics display.

#### How to show the diagnostics values in reverse order

Press the  and  buttons simultaneously.


#### How to set values to zero

Specific values can be set to zero by pressing the  button for at least 5 seconds. The diagnostics values which can be reset are listed in the table in section "Overview of diagnostics values (Page 257)".



## 12.2.2 Saving the diagnostics values

The diagnostic values are written into a non-volatile memory every 15 minutes so that, in the event of a power failure, only the diagnostic values of the previous 15 minutes are lost. The values in the resettable parameters can be set to zero.

To do this, press the  button for at least 5 seconds.

The diagnostic values which can be reset can be found in the table in section Overview of diagnostics values (Page 257).

## 12.2.3 Overview of diagnostics values


### Explanatory notes on the following table

- The "Representable diagnostics values" column shows the factory settings for the diagnostics parameters in bold type.
- The "Properties" column shows the properties of the diagnostics parameters:
  - ① Diagnostics value can be read and reset.
  - ② Diagnostics value can be read but **not** reset.
  - ③ Diagnostics value can be read but **not** reset. A function can be executed.
  - ④ Diagnostics value can be read, manually reset, and manually changed.

### Overview of diagnostics values

No.	Short description	Meaning	Representable diagnostics values	Unit	Properties
1	STRKS	Number of total strokes	<b>0 ... 4.29E9</b>	-	①
2	CHDIR	Number of changes in direction	<b>0 ... 4.29E9</b>	-	①
3	hCNT	Number of fault messages	<b>0 ... 4.29E9</b>	-	①
4	A1CNT	Number of alarms 1	<b>0 ... 4.29E9</b>	-	①
5	A2CNT	Number of alarms 2	<b>0 ... 4.29E9</b>	-	①
6	HOURS	Number of operating hours	<b>0 ... 4.29E9</b>	Hours	②
7	HOURR	Resettable operating hours counter	<b>0 ... 4.29E9</b>		①
8	WAY	Determined travel	<b>0 ... 130</b>	mm or °	②
9	TUP	Travel time up	<b>0.0 / 0 ... 1000</b>	s	②
10	TDOWN	Travel time down	<b>0.0 / 0 ... 1000</b>	s	②
11	LEAK	Leakage test	<b>- / 0.0 ... 100.0</b>	%/minute	③
12	PST	Monitoring of partial stroke test	<b>OFF / ###.#, FdInI, notSt, SdtSt, fdtSt, notoL, Strt, StoP</b>	s for ###.#	③
13	PRPST	Time since last partial stroke test	<b>###, notSt, Sdst, fdtSt</b>	Days	②
14	NXPST	Time until next partial stroke test	<b>OFF / ###</b>	Days	②

## 12.2 Diagnostics

No.	Short description	Meaning	Representable diagnostics values	Unit	Properties
15	DEVI	Dynamic control valve behavior	0.0 ... 100.0	%	②
16	ONLK	Pneumatic leakage	0.0 ... 100.0	-	②
17	STIC	Stiction (slipstick)	0.0 ... 100.0	%	②
18	ZERO	Lower endstop	0.0 ... 100.0	%	②
19	OPEN	Upper endstop	0.0 ... 100.0	%	②
20	PAVG	Average value of position	OFF, IdLE, rEF, COMP 0.0 ... 100.0	%	②
21	P0	Potentiometer value of lower endstop (0%)	0.0 ... 100.0	%	③
22	P100	Potentiometer value of upper endstop (100%)	0.0 ... 100.0	%	③
23	IMPUP	Pulse length up	6 ... 160	ms	④
24	IMPDN	Pulse length down	6 ... 160	ms	④
25	PAUTP	Pulse pause	2 ... 28 ... 320	ms	④
26	DBUP	Deadband up	0.1 ... 10.0	%	②
27	DBDN	Deadband down	0.1 ... 10.0	%	②
28	SSUP	Slow step zone up	0.1 ... 10.0 ... 100.0	%	④
29	SSDN	Slow step zone down	0.1 ... 10.0 ... 100.0	%	④
30	TEMP	Current temperature	-50 ... 100 -58 ... 212	°C °F	②
31	TMIN	Minimum temperature (min/max pointer)	-50 ... 100 -58 ... 212	°C °F	②
32	TMAX	Maximum temperature (min/max pointer)	-50 ... 100 -58 ... 212	°C °F	②
33	T1	Number of operating hours in temperature range 1	0 ... 4.29E9	Hours	②
34	T2	Number of operating hours in temperature range 2	0 ... 4.29E9	Hours	②
35	T3	Number of operating hours in temperature range 3	0 ... 4.29E9	Hours	②
36	T4	Number of operating hours in temperature range 4	0 ... 4.29E9	Hours	②
37	T5	Number of operating hours in temperature range 5	0 ... 4.29E9	Hours	②
38	T6	Number of operating hours in temperature range 6	0 ... 4.29E9	Hours	②
39	T7	Number of operating hours in temperature range 7	0 ... 4.29E9	Hours	②
40	T8	Number of operating hours in temperature range 8	0 ... 4.29E9	Hours	②
41	T9	Number of operating hours in temperature range 9	0 ... 4.29E9	Hours	②
42	VENT1	Number of switching cycles of pilot valve 1	0 ... 4.29E9	-	②
43	VENT2	Number of switching cycles of pilot valve 2	0 ... 4.29E9	-	②
44	VEN1R	Number of switching cycles of pilot valve 1, resettable	0 ... 4.29E9	-	①
45	VEN2R	Number of switching cycles of pilot valve 2, resettable	0 ... 4.29E9	-	①
46	STORE	Save the current values as 'last maintenance' (press  button for 5 seconds)	-	-	③
47	PRUP	Prediction up	1 ... 40	-	④
48	PRDN	Prediction down	1 ... 40	-	④
49	WT00	Number of operating hours in the travel range WT00	0 ... 4.29E9	Hours	①

No.	Short description	Meaning	Representable diagnostics values	Unit	Properties
50	WT05	Number of operating hours in the travel range WT05	0 ... 4.29E9	Hours	①
51	WT10	Number of operating hours in the travel range WT10	0 ... 4.29E9	Hours	①
52	WT30	Number of operating hours in the travel range WT30	0 ... 4.29E9	Hours	①
53	WT50	Number of operating hours in the travel range WT50	0 ... 4.29E9	Hours	①
54	WT70	Number of operating hours in the travel range WT70	0 ... 4.29E9	Hours	①
55	WT90	Number of operating hours in the travel range WT90	0 ... 4.29E9	Hours	①
56	WT95	Number of operating hours in the travel range WT95	0 ... 4.29E9	Hours	①
57	LKPUL	Length of the leakage compensation pulse	-256 ... 0 ... 254	ms	②
58	LKPER	Period of the leakage compensation pulse	0.00 ... 600.00	s	②

## 12.2.4 Meaning of the diagnostic values

### 12.2.4.1 Diagnostic value '1.STRKS - Number of total strokes'

Display range: 0 ... 4.29E9

Purpose: In operation, the movements of the actuator are summed up and displayed in this diagnostics parameter as the number of strokes.  
Unit: 100% strokes, i.e. the path between 0% and 100% and back.

### 12.2.4.2 Diagnostic value '2.CHDIR - Number of changes in direction'

Display range: 0 ... 4.29E9

Purpose: Every change in direction of the actuator is noted in the controller and added to the number of changes in direction.

### 12.2.4.3 Diagnostic value '3.\CNT - Number of fault messages'

Display range: 0 ... 4.29E9

Purpose: Every fault is noted in the closed-loop controller with '3.\CNT' and added to the number of fault messages.

### 12.2.4.4 Diagnostic value '4.A1CNT - Number of alarms 1' / '5.A2CNT - Number of alarms 2'

Requirement: '41.AFCT' Alarm function (Page 154) parameter is activated.

Display range: 0 ... 4.29E9

Purpose: This value indicates how often the alarm has been triggered.

#### 12.2.4.5 Diagnostic value '6.HOURS - Number of operating hours'

Display range: 0 ... 4.29E9  
Purpose: The runtime meter is incremented every hour as soon as electric auxiliary power is supplied to the positioner.

#### 12.2.4.6 Diagnostic value '7.HOURR - Resettable operating hours counter'

Display range: 0 ... 4.29E9  
Purpose: The runtime meter is incremented every hour as soon as electric auxiliary power is supplied to the positioner. In contrast to Diagnostic value '6.HOURS - Number of operating hours' (Page 260), this value can be reset.  
Description: In order to minimize the control valve wear resulting from a poor control quality, it makes sense to optimize the positioner's parameters. You can recognize optimum parameter settings when the values of the Diagnostic value '44.VEN1R' / '45.VEN2R' (Page 269) are low. Low values mean that the switching frequency of the positioner pneumatics is also low. In order to carry out a comparison with various parameter settings, determine the number of switching cycles per hour. To do this, use the values of the Diagnostic value '44.VEN1R' / '45.VEN2R' (Page 269) and '7.HOURR'. These three parameters can be reset to enable simpler determination of the values.


#### 12.2.4.7 Diagnostic value '8.WAY - Determined travel'

Condition for linear actuator: The travel is set in the '3.YWAY' Range of stroke (Page 144) parameter.  
Display range: 0 ... 130  
Purpose: This value in mm or ° specifies the travel determined during the initialization.



#### 12.2.4.8 Diagnostic value '9.TUP - Travel time up' / '10.TDOWN - Travel time down'

Display range: 0 ... 1000  
Purpose: This value indicates the current UP or DOWN travel time in seconds determined during the initialization.

### 12.2.4.9 Diagnostic value '11.LEAK - Leakage test'

Condition	The positioner is initialized and in manual mode (MAN).
Display range:	<ul style="list-style-type: none"> <li>• -</li> <li>• 0.0 ... 100.0</li> </ul>
Purpose:	<p>You can use this diagnostics parameter to read the last test result or start an offline leakage test with which you can detect leakages in the actuator or in the pipe installation. Display is percent stroke per minute referred to the total stroke. A test result originates from one of the following options:</p> <ul style="list-style-type: none"> <li>• Function '11.LEAK' has already been carried out.</li> <li>• Leakage test was already carried out during initialization, see procedure of RUN 3 in section Sequence of automatic initialization (Page 111).</li> <li>• 'Offline leakage test' function was already executed by a HOST system.</li> </ul> <p>"-" in the display can have the following causes:</p> <ul style="list-style-type: none"> <li>• A leakage test has not yet been carried out.</li> <li>• Resetting to the factory settings was carried out using the '48.PRST' Preset (Page 158) &gt; ALL parameter.</li> <li>• Positioner is not initialized.</li> </ul> <p>How to start the test</p> <ol style="list-style-type: none"> <li>1. Move the actuator to the position at which you wish to start the test.</li> <li>2. In 'Diagnostics' mode, go to the '11.LEAK' diagnostic value as described in section Display of diagnostics values (Page 256).</li> <li>3. Start the function by pressing the  button for at least 5 seconds.</li> </ol>
Description:	<p>'Strt' is output in the display. The function is started after 5 seconds. 'tEst' and the current position of the actuator (actual value) are then displayed alternately for one minute.</p> <p>After one minute, the display shows the difference in the actuator position before and after the test. This means: the actuator position has changed by the displayed value in one minute.</p>

### 12.2.4.10 Diagnostic value '12.PST - Monitoring of partial stroke test'

Indication on the display:	<ul style="list-style-type: none"> <li>• OFF</li> <li>• C-ERR</li> <li>• FdIni</li> <li>• notSt</li> <li>• ###.#</li> <li>• SdtSt</li> <li>• FdtSt</li> </ul>
Purpose:	<p>This diagnostics parameter indicates the stroke time measured during the last partial stroke test.</p> <p>A partial stroke test can be initiated manually or a current partial stroke test can be interrupted by pressing the  button.</p>
Description of indications on the display:	<ul style="list-style-type: none"> <li>• OFF: The partial stroke test function is deactivated.</li> <li>• C-ERR: Configuration error. Partial stroke test cannot be started. Settings in the 'A1.STPOS start position', 'A3.STRKH stroke height' and 'A4.STRKD stroke direction' are not plausible.</li> <li>• FdIni - Failed PST Initialization: The reference stroke time measurement of the partial stroke test has failed.</li> <li>• notSt - No Test: A partial stroke test has not yet been executed.</li> <li>• ###.#: Corresponds to the measured stroke time in seconds. The last partial stroke test was successfully executed.</li> <li>• SdtSt - Stopped Test: The last partial stroke test was interrupted.</li> <li>• FdtSt - Failed Test: The last partial stroke test has failed.</li> </ul>
Status messages:	<p>The following status messages appear when you hold the  button pressed:</p> <ul style="list-style-type: none"> <li>• notoL - No Tolerance: The control valve is beyond the tolerance range to start the partial stroke test. A manual partial stroke test is not started.</li> <li>• Strt - Start: A manual partial stroke test is started five seconds after pressing the button.</li> <li>• StoP - Stop: The current partial stroke test is interrupted. 'WAIT' is output in the display.</li> </ul>
Factory setting:	OFF

**12.2.4.11 Diagnostic value '13.PRPST' - Time since last partial stroke test'**

- Indication on the display: • ###
- notSt
  - Sdtst
  - FdtSt
- Purpose: This diagnostics parameter shows the elapsed time in days since the last partial stroke test.
- Status messages: • notSt - No Test: A manual partial stroke test has not yet been executed.
- SdtSt - Stopped Test: The last partial stroke test was interrupted.
  - FdtSt - Failed Test: The last partial stroke test has failed.

**12.2.4.12 Diagnostic value '14.NXPST' - Time until next partial stroke test'**

- Requirement: • The partial stroke test is activated in 'Configuration' mode.
- The test interval is set in the 'A8.INTRV' parameter.
- Indication on the display: • OFF
- ###
- Purpose: This diagnostics parameter shows the time in days until the next partial stroke test. If one of the above-mentioned conditions is not met, 'OFF' is shown on the display.

**12.2.4.13 Diagnostics value '15.DEVI - Dynamic control valve behavior'**

- Requirement: '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is activated.
- Display range: 0.0 ... 100.0
- Purpose: This value in percent provides information about the current dynamically determined deviation from the model response.

**12.2.4.14 Diagnostic value '16.ONLK - Pneumatic leakage'**

- Requirement: Monitoring/compensation of pneumatic leakage 'C.\LEAK' (Page 170) parameter is activated.
- Display range: 0 ... 100
- Purpose: This diagnostics parameter shows the current leakage indicator.

**12.2.4.15 Diagnostic value '17.STIC - Stiction (slipstick)'**

Requirement: Monitoring of stiction (slipstick) 'd.\STIC' (Page 173) parameter is activated.

Display range: 0.0 ... 100.0

Purpose: This diagnostics parameter shows the filtered value of the slip jumps in percent resulting from the stiction.

**12.2.4.16 Diagnostic value '18.ZERO - Lower endstop'**

Requirement: '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is activated.  
' 36.YCLS' Tight closing/fast closing with manipulated variable (Page 150) Parameter is set to one of the following values: 'do', 'uP do', 'Fd', 'Fu Fd', 'uP Fd', 'Fu do'

Display range: 0.0 ... 100.0

Purpose: Indication of how many percent the lower endstop has changed compared to its value during initialization.

**12.2.4.17 Diagnostic value '19.OPEN - Upper endstop'**

Requirement: '50.XDIAG' Activation of extended diagnostics (Page 160) parameter is activated.  
' 36.YCLS' Tight closing/fast closing with manipulated variable (Page 150) parameter is set to one of the following values: 'uP', 'uP do', 'Fu', 'Fu Fd', 'uP Fd', 'Fu do'

Display range: 0.0 ... 100.0

Purpose: An indication of the current shift of the upper endstop compared to its initialization value.



**12.2.4.18 Diagnostic value '20.PAVG - Average value of position'**

Indication on the display:

- OFF
- IdLE
- rEF
- COMP

Purpose:

This value shows the last calculated comparison average. Meaning of the displays:

- OFF: The underlying function is deactivated in the configuration menu.
- IdLE : Inactive. The function has not been started yet.
- rEF: The reference average is calculated. The function was started, and the reference interval is in progress at the moment.
- COMP: The comparison average is calculated. The function was started, and the comparison interval is in progress at the moment.

**12.2.4.19 Diagnostic value '21.P0 - Potentiometer value of lower endstop (0%)' / '22.P100 - Potentiometer value of upper endstop (100%)'**

Display range:

- NO
- 0.0 ... 100.0

'NO': Changing the low or upper endstop is not possible in the current state of the control valve. Initialize the positioner again.

Condition 1 -  
read values

The positioner is initialized.

Purpose 1

**Read values**

You can use the P0 and P100 parameters to read the values for the lower endstop (0%) and the upper endstop (100%) of the position measurement as determined during the automatic initialization. The values of manually approached end positions are applicable for manual initialization.

Condition 2 -  
change values

- The positioner is initialized and in manual mode (MAN) or automatic mode (AUT).
- The current position of the actuator is within the range -10% to +10% of the lower endstop (P0).
- The current position of the actuator is within the range 90% to 110% of the upper endstop (P100).

## Purpose 2:

**Change values**




You can use these two parameters to change the lower endstop (P0) and the upper endstop (P100).

Since initialization is not usually carried out under process conditions, the values for the lower endstop (P0) and the upper endstop (P100) can change when the process is started. These changes can result from temperature changes with the associated thermal expansion of the material. If the Monitoring the lower endstop 'F.\ZERO' (Page 176) and Monitoring the upper endstop 'G.\OPEN' (Page 177) parameters are active, the thresholds set in these two parameters can be exceeded as a result of thermal expansion. An error message is output in the display.


The process-dependent thermal expansion might represent the normal state in your application. You do not wish to receive an error message as a result of this thermal expansion. Therefore reset the 'P0' and/or 'P100' parameters after the process-dependent thermal expansion has had its complete effect on the control valve. The procedure is described in the following.

## Description:

**Procedure for manual mode (MAN)**

1. Move the actuator to the desired position of the lower endstop (upper endstop) using the  and  buttons.
2. Switch to diagnostics mode.
3. Go to diagnostic value 21.P0 (22.P100).
4. Apply the setting by pressing the  button for at least 5 seconds. After 5 seconds, '0.0' (with 22.P100: '100.0') is displayed. Result: The lower endstop (upper endstop) now corresponds to the current position of the actuator.
5. Switch to manual mode (MAN). Result: Values for the upper endstop (lower endstop) have changed.

**Procedure for automatic mode (AUT)**

1. Check in the display whether the current position of the actuator is at the desired position of the lower endstop (upper endstop).
2. Switch to diagnostics mode.
3. Go to diagnostic value 21.P0 (22.P100).
4. Apply the setting by pressing the  button for at least 5 seconds. After 5 seconds, '0.0' (with 22.P100: '100.0') is displayed. Result: The lower endstop (upper endstop) now corresponds to the current position of the actuator.
5. Switch to automatic mode (AUT).

**See also**

Changing the operating mode (Page 101)

**12.2.4.20 Diagnostic value '23.IMPUP - Pulse length up' / '24.IMPDN - Pulse length down'**

Display range:	6 ... 160
Purpose:	The smallest impulse lengths that can be used to move the actuator are determined during the initialization process. They are separately determined for the 'Up' and 'Down' directions and displayed here. Display in ms. In the case of special applications you can additionally set the smallest impulse lengths in these two parameters.
Factory setting:	6

**12.2.4.21 Diagnostic value '25.PAOTP - Pulse interval'**

Display range:	2 ... 320
Purpose:	This value is not changed during an initialization process. Display in ms. For applications with high stiction (slipstick), adjusting this parameter improves the control quality. This parameter can be set for special applications.
Factory setting:	28

**12.2.4.22 Diagnostic value '26.DBUP - Deadband up' / '27.DBDN - Deadband down'**


Display range:	0.1 ... 10.0
Purpose:	In this parameter, you can read the deadbands of the controller in the 'Up' and 'Down' directions. Display in percent. The values correspond either to the manually configured value of the '31.DEBA' Deadband of controller (Page 148) parameter or to the value automatically adapted by the device if 'DEBA' was set to 'Auto'.

**12.2.4.23 Diagnostic value '28.SSUP - Slow step zone up' / '29.SSDN - Slow step zone down'**

Display range:	0.1 ... 100.0
Purpose:	The slow step zone is the zone of the closed-loop controller in which control signals are issued in a pulsed manner. Display is in percent. The impulse length is thus proportional to the control deviation. If the control deviation is beyond the slow step zone, the valves are controlled using permanent contact. This parameter can be set for special applications.
Factory setting:	10.0

**12.2.4.24 Diagnostic value '30.TEMP - Current temperature'**


Display range: °C: -50 ... 100  
 °F: -58 ... 212

Purpose: Current temperature in the positioner enclosure. The sensor is present on the basic electronics. In order to switch over the temperature display between °C and °F, press the  button.

**12.2.4.25 Diagnostic value '31.TMIN - Minimum temperature' / '32.TMAX - Maximum temperature'**

Display range: °C: -50 ... 100  
 °F: -58 ... 212

Purpose: The minimum and maximum temperatures within the enclosure are constantly determined and saved as with a min/max pointer. This value can only be reset in the factory.

In order to switch over the temperature display between °C and °F, press the  button.

**12.2.4.26 Diagnostic value '33.T1' ... '41.T9' - Number of operating hours in the temperature range 1 to 9**

Display range: 0 ... 4.29E9

Purpose: Statistics about the duration of operation in different temperature ranges is maintained in the device. An average of the measured temperature is taken every hour and the counter assigned to the corresponding temperature range is incremented. This helps in drawing conclusions about the past operating conditions of the device and the entire control valve.

The temperature ranges are classified as follows:

	T1	T2	T3	T4	T5	T6	T7	T8	T9
Temperature range [°C]	-	≥ -30	≥ -15	≥ 0	≥ 15	≥ 30	≥ 45	≥ 60	≥ 75
	≤ -30	< -15	< 0	< 15	< 30	< 45	< 60	< 75	-

Operating hours in temperature ranges T1 to T2

**12.2.4.27 Diagnostic value '42.VENT1' / '43.VENT2'**

'42.VENT1' Number of switching cycles of pilot valve 1  
 '43.VENT2' Number of switching cycles of pilot valve 2


Display range: 0 ... 4.29E9

Purpose:	Control procedures of the pilot valves in the pneumatic block of the positioner are counted and displayed in this parameter.
Description:	<p>The pneumatic block of the positioner pressurizes and depressurizes the actuator. The pneumatic block contains two pilot valves. The characteristic service life of the pneumatic block depends on the load. This amounts on average to approx. 200 million switching cycles for each of the two pilot valves with symmetrical load. The number of control procedures for the switching cycles serves to assess the switching frequency of the pneumatic block.</p> <p>Counting procedure for single-acting actuators:</p> <ul style="list-style-type: none"> <li>• Pressurize =&gt; 42.VENT1</li> <li>• Depressurize =&gt; 43.VENT2</li> </ul> <p>Counting procedure for double-acting actuators:</p> <ul style="list-style-type: none"> <li>• Pressurize (Y2) / Depressurize (Y1) =&gt; 42.VENT1</li> <li>• Depressurize (Y1) / Pressurize (Y2) =&gt; 43.VENT2</li> </ul> <p>The value is written hourly into a nonvolatile memory.</p>

#### 12.2.4.28 Diagnostic value '44.VEN1R' / '45.VEN2R'

'44.VEN1R'	Number of switching cycles of pilot valve 1, resettable
'45.VEN2R'	Number of switching cycles of pilot valve 2, resettable
Display range:	0 ... 4.29E9
Purpose:	Control procedures of the pilot valves in the pneumatic block of the positioner are counted since the last time this parameter was reset, and displayed here.
Description:	Corresponds to the description for Diagnostic value '42.VENT1' / '43.VENT2' (Page 268) referred to the diagnostics parameters 'VEN1R' and 'VEN2R' described here.

**12.2.4.29 Diagnostic value '46.STORE - Save maintenance data'**

**Purpose:** The minimum and maximum temperatures within the enclosure are constantly determined and saved as with a min/max pointer. This value can only be reset in the factory. In order to switch over the temperature display between °C and °F, press the  button for at least 5 seconds in order to initiate a save function. The values of the diagnostics parameters Diagnostic value '8.WAY - Determined travel' (Page 260) to Diagnostic value '11.LEAK - Leakage test' (Page 261) and Diagnostic value '21.PO - Potentiometer value of lower endstop (0%)' / '22.P100 - Potentiometer value of upper endstop (100%)' (Page 265) to Diagnostic value '28.SSUP - Slow step zone up' / '29.SSDN - Slow step zone down' (Page 267) are saved in the non-volatile memory as 'data of last maintenance'. This diagnostics data contains selected values whose changes can give information about mechanical wear and tear of the valve.

This function is normally operated through the PDM, menu command 'Diagnostics-> Save maintenance information'. The data of the last maintenance operation can be compared with the current data using SIMATIC PDM.

**12.2.4.30 Diagnostic value '47.PRUP - Prediction up' / '48.PRDN - Prediction down'**

**Display range:** 1 ... 40

**Purpose:** This value specifies the prediction of the controller for the up (PRUP) and down (PRDN) movements.

For more information, refer also to the section Optimization of controller data (Page 104).

**Factory setting:** 1

**12.2.4.31 Diagnostic value '49.WT00' ... '56.WT95' - Number of operating hours in the travel range WT00 to WT95**



**Display range:** 0 ... 4.29E9

**Purpose:** When the positioner is in "Automatic" mode, statistics are continuously maintained regarding the duration for which a valve or a flap is operated in a particular section of the travel range. The entire travel range is divided into 8 sections from 0 to 100 %. The positioner records the current position continuously and increments the runtime meter assigned to the corresponding travel range every hour. This helps in drawing conclusions about the past operating conditions and especially in assessing the control properties of the control loop and the entire control valve.

Travel range	WT00	WT05	WT10	WT30	WT50	WT70	WT90	WT95
Travel range section [%]	-	≥ 5	≥ 10	≥ 30	≥ 50	≥ 70	≥ 90	≥ 95
	< 5	< 10	< 30	< 50	< 70	< 90	< 95	-

Division of travel ranges

You can simultaneously set the eight operating hours counters to zero.

**TIP:** Since the travel ranges are provided at the end of the diagnostics parameters, press the  button several times along with the  button. This will help you to access the desired diagnostics parameters faster.

### 12.2.4.32 Diagnostics value '50.LKPUL - Length of the leakage compensation pulse'

Display range: -256 ... **0** ... 254

Purpose: This value in milliseconds indicates the length of a compensation pulse when Monitoring/compensation of pneumatic leakage 'C.\LEAK' (Page 170) is active. The sign indicates the control direction of the pulse.

Factory setting: 0

### 12.2.4.33 Diagnostics value '51.LKPER - Period of the leakage compensation pulse'

Display range: **0.00** ... 600.00

Purpose: This value in seconds indicates the period of the leakage compensation pulses when Monitoring/compensation of pneumatic leakage 'C.\LEAK' (Page 170) is active.

Factory setting: 0.00

## 12.3 Online diagnostics

### 12.3.1 Overview of online diagnostics

Online diagnostics means diagnostics during ongoing operation. A few important variables and parameters are continuously monitored during the operation of the positioner. In "Configuration" mode, you can configure this monitoring in such a way that the fault message output will be activated if, for instance, a limit is exceeded.

Information about what events can activate the fault message output can be found in the table in chapter "Overview of error codes (Page 272)".

12.3 Online diagnostics

This chapter contains information about the following situations in particular:

- Possible causes of the fault message.
- Events which activate the fault message output or alarm outputs.
- Setting of parameters needed for event monitoring.
- Canceling a fault message

When the fault message output is triggered in automatic or manual mode, the display shows which fault triggered the message. Both digits at bottom-left indicate the corresponding error code. If multiple triggers occur at the same time, they are displayed one after the other cyclically.

**See also**

Extended diagnostics parameters A to P (Page 163)

**12.3.2 Overview of error codes**

**Overview of error codes that activate the fault message output**

You can find where the error codes are output in the display under '50.XDIAG' Activation of extended diagnostics (Page 160).

Error code	Three-stage	Event	Parameter setting	Error message disappears when	Possible causes
h1	No	Control deviation: Actual value response has exceeded values for TIM and LIM	Always active	... the actual value response falls below the value for LIM	Compressed air failure, actuator fault, valve fault (e.g. blockade).
h2	No	Device not in "Automatic" mode	** .hFCT <sup>1)</sup> =hnA or =hnAB	... the device is changed to "Automatic" mode.	The device has been configured or is in the manual mode
h3	No	Binary input BIN1 or BIN2 active	** .h FCT <sup>1)</sup> =hnAB and binary function BIN1 or BIN2 to "On"	... the binary input is no longer activated.	The contact connected to the binary input was active (e.g. packing gland monitoring, overpressure, temperature switch).
h4	Yes	Limit for number of total strokes exceeded	L.hSTRK≠OFF	... the stroke counter is reset or the thresholds are increased	The total path covered by the actuator exceeds one of the configured thresholds.
h5	Yes	Limit for number of changes in direction exceeded	O.hDCHG≠OFF	... the counter for changes of direction is reset or the thresholds are increased.	The number of changes of direction exceeds one of the configured thresholds.
h6	Yes	Lower endstop limit exceeded	F.hZERO≠OFF ** .YCLS = do or up do	... the deviation of the endstop disappears or the device is re-initialized.	Wear and tear of the valve seat, deposits or foreign bodies in the valve seat, mechanical misalignment, friction clutch moved.



Error code	Three-stage	Event	Parameter setting	Error message disappears when	Possible causes
47	Yes	Upper endstop limit exceeded	G.4OPEN≠OFF **.YCLS <sup>1)</sup> = do or up do	... the deviation of the endstop disappears or the device is re-initialized.	Wear and tear of the valve seat, deposits or foreign bodies in the valve seat, mechanical misalignment, friction clutch moved.
48	No	Deadband limit exceeded	E.4DEBA≠OFF **.DEBA <sup>1)</sup> = Auto	... the limit is undershot again	Increased packing gland friction, mechanical gap in the position feedback.
49	Yes	Case 1: Reference stroke time for partial stroke test is exceeded.	A.4PST≠OFF	Case 1: ... a partial stroke test is successfully executed within the reference stroke time or the function is deactivated.	Case 1: Valve is stuck or rusted. Increased stiction.
		Case 2: Start position outside the start tolerance		Case 2: Move the actuator into the range of the PST start tolerance. Or increase the PST start tolerance until the actuator (PST start position) is within the PST start tolerance. Start the partial stroke test again.	Case 2: Valve is present in the safety position.
10	Yes	Deviation from expected dynamic control valve behavior	b.4DEVI≠OFF	... the position is again in a narrow corridor between the setpoint and the model, or the function is deactivated.	Actuator fault, valve fault, valve jams, increased stiction, decreased compressed air
11	Yes	Valve leakage	C.4LEAK≠OFF	... the valve leakage has been remedied or the function is deactivated.	Pneumatic leakage
12	Yes	Stiction limit (slipstick) exceeded	d.4STIC≠OFF	... Slipjumps can no longer be detected, or the function is deactivated.	Increased stiction, valve no longer moves smoothly but in jerky motion.
13	Yes	Temperature undershot	H.4TMIN≠OFF	... the low temperature thresholds are no longer undershot.	Ambient temperature too low
14	Yes	Temperature overshoot	J.4TMAX≠OFF	... the high thresholds are no longer overshoot.	Ambient temperature too high
15	Yes	Position average deviates from the reference value	P.4PAVG≠OFF	... the average position value calculated after a comparison interval is again within the thresholds for the reference value, or the function is deactivated.	In the last comparison interval, the valve trajectory was changed so severely that a deviating average value of position was calculated.
16	No	Partial stroke test is to be carried out with non-plausible parameter values	A.4PST≠OFF	the parameter values entered in A1.STPOS, A3.STRKH and A4.STRKD are plausible.	Parameters for partial stroke test are non-plausible

<sup>1)</sup> Refer to the corresponding parameter descriptions for additional information about parameters

**See also**

Overview of initialization parameters 1 to 5 (Page 134)

Overview of application parameters 6 to 55 (Page 135)

**12.3.3 XDIAG parameter**

You can use the extended diagnostics parameters to display error messages in one, two or three stages. In addition to the fault message output, alarm outputs 1 and 2 are then used. For this purpose, set the "XDIAG" parameter as described in the following table:

Settings of XDIAG	Message due to
OFF	Extended diagnostics not activated
On1	Fault message output for threshold 3 error message (maintenance alarm, single-stage)
On2	Fault message output for threshold 3 error messages and alarm output 2 for threshold 2 error messages (maintenance demanded, two-stage)
On3	Fault message output for threshold 3 error messages and alarm output 2 for threshold 2 error messages and alarm output 1 for threshold 1 error messages (maintenance required, three-stage)

Possible settings of the 'XDIAG' parameter

**12.3.4 Meaning of error codes****12.3.4.1 1 Remaining control deviation**

The deviation between the setpoint and the actual value is continuously monitored in "Automatic" mode. The fault message for a remaining control deviation is activated depending on the setting of the application parameters "4TIM" - monitoring time for setting the fault messages - and "4LIM" - response threshold for the fault message. The fault message is cancelled as soon as the control deviation drops below the response threshold. This monitoring function is always active.

**12.3.4.2 2 Device not in "Automatic" mode**

When the device is not in automatic mode, an error message is generated if the '4FCT' parameter (function of fault message output) is set correctly. A warning is then sent to the control system if the device was switched to manual or configuration mode on-site.

**12.3.4.3 3 Binary input BIN1 or BIN2 active**

If the binary input is activated, an error message is generated when the "4FCT" parameter (function of fault message output) and the "BIN1" parameter (function of binary input 1) are set correctly. For example, it can be a switch to monitor the packing glands, a temperature switch or a limit switch (e.g. for pressure).

Binary input 2 (in the optional alarm module) can be configured in a similar manner.

#### 12.3.4.4 4 Monitoring the number of total strokes

The diagnostics value "1 STRKS" is constantly compared with the thresholds that are determined from the "L1.LIMIT" to "L4.FACT3" parameters. If the thresholds are exceeded, the fault message output or the alarm outputs respond depending on the mode of the extended diagnostics. These two functions can be deactivated using the parameter setting "OFF" for "L.↳STRK".

#### 12.3.4.5 5 Monitoring the number of changes in direction

The diagnostics value "2 CHDIR" is constantly compared with the thresholds that are determined from the "O1.LIMIT" to "O4.FACT3" parameters. If the thresholds are exceeded, the fault message output or the alarm outputs respond depending on the mode of the extended diagnostics. These two functions can be deactivated using the parameter setting "OFF" for "O.↳DCHG".

#### 12.3.4.6 6 Monitoring the lower endstop and 7 Monitoring the upper endstop

If the parameter "F.↳ZERO" is set to "ON", monitoring of the lower endstop is activated. This function can be used to detect the errors in the valve seat. An overshoot limit indicates the possibility of deposits or foreign bodies in the valve seat. An undershoot limit indicates probable wear and tear of the valve seat or flow restrictor. Even a mechanical misalignment of the position feedback can trigger this fault message.

Monitoring is always carried out whenever the valve is in the "tight closing/fast closing Down" position. The current position is compared with the position that was determined as the lower endstop at the time of initialization. Requirement: ' 36.YCLS' Tight closing/fast closing with manipulated variable (Page 150) Parameter is set to one of the following values: 'do', 'uP do', 'Fd', 'Fu Fd'.

Example: A value of 3% is set. The position is normally adopted for "tight closing/fast closing Down". A fault is reported if a value > 3% or < -3% is determined instead.

The fault message remains activated until either a subsequent monitoring remains within the tolerance or a re-initialization process is executed. Even the deactivation of monitoring ("F.↳ZERO"=OFF) may trigger an error message.

This monitoring function does not deliver any utilizable results if the endstops were not determined automatically at the time of initialization, but the limits were set manually (manual initialization, "5.INITM").

Similar diagnostics is carried out for the upper endstop. The "G.↳OPEN" parameter is used to set the limit for this. Requirement: ' 36.YCLS' Tight closing/fast closing with manipulated variable (Page 150) Parameter is set to one of the following values: 'uP', 'uP do', 'Fu', 'Fu Fd', 'uP Fd', 'Fu do'.

#### 12.3.4.7 8 Monitoring deadband

If the deadband increases disproportionately when adjusting it automatically ("DEBA"=Auto parameter), it indicates an error in the system (e.g. severely increased packing gland friction, play in the position displacement sensor, leakage). A limit can therefore be entered for this value ("E1.LEVL3", threshold for deadband monitoring). An error message output is activated when this value is exceeded.

**12.3.4.8 9 Partial stroke test**

On the one hand, this fault message appears when a manual or cyclic partial stroke test is initiated and the test cannot be started since the valve is not within the starting tolerance. On the other hand, the fault message appears when one of the three thresholds of the partial stroke test that are determined from the 'A9.PSTIN' reference stroke time multiplied by factors 'AA.FACT1', 'Ab.FACT2' and 'AC.FACT3' is violated. The severity of the fault message is shown by the number of bars on the display. The severity of the fault message is simultaneously displayed using the fault message output or alarm outputs depending on the mode of the advanced diagnostics.

**12.3.4.9 10 Monitoring of dynamic control valve behavior**

The monitoring of the operational behavior responds when the actual valve position shifts from a narrow corridor between the setpoint and the expected position course. In this case, the deviation between the expected and actual position course is filtered, displayed and compared with the configured thresholds that are determined from the "b2.LIMIT" limit multiplied by the factors "b3.FACT1" to "b5.FACT3".

**12.3.4.10 11 Monitoring/compensation of pneumatic leakage**

This fault message appears if a leakage is present. For additional information, see Monitoring/compensation of pneumatic leakage 'C.\LEAK' (Page 170).

**12.3.4.11 12 Monitoring of stiction (slipstick)**

If the stiction of the control valve increases during operation or if an increasing number of Slipjumps is detected, "d1.LIMIT" could be exceeded and result in this fault message.

**12.3.4.12 13 Monitoring the lower limit temperature**

This fault message appears when the lower limit temperature thresholds are undershot.

**12.3.4.13 14 Monitoring the upper limit temperature**

This fault message appears when the upper limit temperature thresholds are overshoot.

**12.3.4.14 15 Monitoring the position average value**

This fault message appears when a position value calculated after the expiry of a comparison interval deviates from the reference value by more than the configured thresholds.

**12.3.4.15 16 Monitoring the plausibility of values for the partial stroke test**

This error message is triggered if, when starting a partial stroke test, the plausibility check of the "A1.STPOS", "A3.STRKH" and "A4.STRKD" parameters was not successful.

## 12.4 Fault correction

### 12.4.1 Fault identification

#### Diagnostics guide

Fault	Corrective measures, see table				
<b>In which mode does a fault occur?</b>					
• Initialization	1				
• Manual and automatic modes	2	3	4	5	6
<b>In which environment and under which boundary conditions does a fault occur?</b>					
• Wet environment (e.g. strong rain or constant condensation)	2				
• Vibrating (oscillating) control valves	2	5			
• Impact or shock loads (e.g. vapor shocks or breakaway valves)	5				
• Moist (wet) compressed air	2				
• Dirty compressed air (contaminated with solid particles)	2	3			
<b>When does a fault occur?</b>					
• Regularly (reproducible)	1	2	3	4	
• Sporadically (not reproducible)	5				
• Mostly after a specific operation time	2	3	5		

### 12.4.2 Remedial measures table 1

Fault profile (symptoms)	Possible cause(s)	Corrective measures
<ul style="list-style-type: none"> <li>Positioner remains in "RUN 1".</li> </ul>	<ul style="list-style-type: none"> <li>Initialization started from the end position and</li> <li>The response time of a maximum of 1 minute was not observed.</li> <li>Supply air PZ not connected or pressure of supply air PZ too low.</li> <li>Compressed air line blocked, e.g. solenoid valve</li> </ul>	<ul style="list-style-type: none"> <li>A waiting time of up to 1 minute is essential.</li> <li>Do not start initialization from the end position.</li> <li>Ensure supply air PZ.</li> <li>Unlock blocked lines.</li> </ul>
<ul style="list-style-type: none"> <li>Positioner remains in "RUN 2".</li> </ul>	<ul style="list-style-type: none"> <li>Transmission ratio selector and parameter 2</li> <li>"YAGL" and the real stroke do not match.</li> <li>Incorrectly set stroke on the lever.</li> <li>Piezo valve does not activate.</li> </ul>	<ul style="list-style-type: none"> <li>Check settings: see leaflet: Fig. "Device view ⑦" as well as parameters 2 and 3</li> <li>Check the stroke setting on the lever. See Table 2.</li> </ul>

12.4 Fault correction

Fault profile (symptoms)	Possible cause(s)	Corrective measures
<ul style="list-style-type: none"> <li>Positioner remains in "RUN 3".</li> </ul>	<ul style="list-style-type: none"> <li>Actuator travel time is too high.</li> </ul>	<ul style="list-style-type: none"> <li>Open the restrictor completely and/or set the pressure PZ (1) to the highest permissible value.</li> <li>Use a booster if required.</li> </ul>
<ul style="list-style-type: none"> <li>Positioner remains "RUN 5", does not go up to "FINISH" (waiting time &gt; 5 min).</li> </ul>	<ul style="list-style-type: none"> <li>"Gap" (play) in the positioner - actuator - control valve system</li> </ul>	<ul style="list-style-type: none"> <li>Part-turn actuator: check for the firmness of the grub screw of the coupling wheel</li> <li>Linear actuator: check for the firmness of the lever on the positioning shaft.</li> <li>Correct any other play between the actuator and the control valve.</li> </ul>
	<ul style="list-style-type: none"> <li>Diagnostic value "9.TUP" or "10.TDOWN" &lt; 1.5 s</li> </ul>	<ul style="list-style-type: none"> <li>Set the traversing velocity to &gt; 1.5 s using the internal restrictor.</li> </ul>

Fault table 1

12.4.3 Remedial measures table 2




Fault profile (symptoms)	Possible cause(s)	Corrective measures
<ul style="list-style-type: none"> <li>"CPU test" blinks on the display approximately every 2 seconds.</li> <li>Piezo valve does not activate.</li> </ul>	<ul style="list-style-type: none"> <li>Water in the pneumatic block (due to wet compressed air)</li> </ul>	<ul style="list-style-type: none"> <li>At an early stage, this fault can be rectified with a subsequent operating using dry air, if required, in a temperature cabinet at 50°C to 70°C.</li> <li>Otherwise: Repair</li> </ul>
	<ul style="list-style-type: none"> <li>In the manual and automatic modes, the actuator cannot be moved or can be moved only in one direction.</li> </ul>	
<ul style="list-style-type: none"> <li>Piezo valve does not activate (a gentle click sound is not audible when the "+" or "-" buttons are pressed in the manual mode.)</li> </ul>	<ul style="list-style-type: none"> <li>The screw between the shrouding cover and the pneumatic block has not been tightened firmly or the cover got stuck.</li> </ul>	<ul style="list-style-type: none"> <li>Tighten the screw firmly; if required, rectify the deadlock.</li> </ul>
	<ul style="list-style-type: none"> <li>Dirt (swarf, particles) in the pneumatic block</li> </ul>	<ul style="list-style-type: none"> <li>Repair or a new device; clean and/or replace the built-in fine screens.</li> </ul>
	<ul style="list-style-type: none"> <li>Deposits on the contacts between the electronic printed circuit board and the pneumatic block can develop due to abrasion owing to continuous loads resulting from strong vibrations.</li> </ul>	<ul style="list-style-type: none"> <li>Clean all contact surfaces with spirit; if required, bend the pneumatic block contact springs.</li> </ul>

Fault table 2

See also

Repair/Upgrading (Page 244)

### 12.4.4 Corrective measures Table 3

Fault profile (symptoms)	Possible cause	Corrective measures
<ul style="list-style-type: none"> <li>Actuator does not move.</li> </ul>	<ul style="list-style-type: none"> <li>Compressed air &lt; 1.4 bar</li> </ul>	<ul style="list-style-type: none"> <li>Set pressure of supply air PZ to &gt; 1.4 bar.</li> </ul>
<ul style="list-style-type: none"> <li>Piezo valve does not switch (however, a gentle clicking sound can be heard when the  or  button is pressed in "Manual" mode.)</li> </ul>	<ul style="list-style-type: none"> <li>Restrictor valve turned off (screw at the right endstop)</li> </ul>	<ul style="list-style-type: none"> <li>Open the restrictor screw by turning it anticlockwise, see leaflet, Fig. "Device view .</li> </ul>
	<ul style="list-style-type: none"> <li>Dirt in the pneumatic block</li> </ul>	<ul style="list-style-type: none"> <li>Repair or a new device; clean and/or replace the built-in fine screens.</li> </ul>
<ul style="list-style-type: none"> <li>A piezo valve is switched constantly in stationary automatic mode (constant setpoint) and in "Manual" mode.</li> </ul>	<ul style="list-style-type: none"> <li>Pneumatic leakage in the positioner-actuator system; start the leakage test in "RUN 3" (initialization).</li> </ul>	<ul style="list-style-type: none"> <li>Rectify leakage in the actuator and/or feed line.</li> <li>In case of an intact actuator and tight feed line: Repair or new device</li> </ul>
	<ul style="list-style-type: none"> <li>Dirt in the pneumatic block</li> </ul>	<ul style="list-style-type: none"> <li>See above</li> </ul>

Fault table 3

### See also

Repair/Upgrading (Page 244)

### 12.4.5 Corrective measures Table 4

Fault profile (symptoms)	Possible cause(s)	Corrective measures
<ul style="list-style-type: none"> <li>In stationary automatic mode (constant setpoint) and in "Manual" mode, both piezo valves continually switch alternately, and the actuator oscillates around an average value.</li> </ul>	<ul style="list-style-type: none"> <li>Stiction of the packing gland from the control valve or actuator too large</li> </ul>	<ul style="list-style-type: none"> <li>Reduce stiction or increase deadband of positioner (parameter "dE-bA") until the oscillation stops.</li> </ul>
	<ul style="list-style-type: none"> <li>Looseness (play) in the positioner/actuator/control valve system</li> </ul>	<ul style="list-style-type: none"> <li>Part-turn actuator: Check for firm seating of set screw on coupling wheel.</li> <li>Linear actuator: Check for firm seating of lever on positioner shaft.</li> <li>Correct any other play between the actuator and the control valve.</li> </ul>
	<ul style="list-style-type: none"> <li>Actuator too fast</li> </ul>	<ul style="list-style-type: none"> <li>Increase travel times using throttle screws.</li> <li>If a quick travel time is needed, increase the deadband (parameter "dE-bA") until the oscillation stops.</li> </ul>
<ul style="list-style-type: none"> <li>Positioner doesn't move control valve to the stop (at 20 mA).</li> </ul>	<ul style="list-style-type: none"> <li>Supply pressure too low. Load on the feeding controller or system output is too low.</li> </ul>	<ul style="list-style-type: none"> <li>Increase supply pressure, insert ballast converter</li> <li>Select 3/4-wire mode</li> </ul>

Error table 4

**See also**

Cleaning of the screens (Page 242)

**12.4.6 Remedial measures table 5**

Fault profile (symptoms)	Possible cause(s)	Corrective measures
Zero point displaces sporadically (> 3%).	Impact or shock loads result in accelerations so high that the friction clutch moves, e.g. due to "vapor shocks" in vapor lines.	<ul style="list-style-type: none"> <li>• Rectify the causes for shock loads.</li> <li>• Re-initialize the position controller.</li> </ul>
The device function has completely failed: No representation on the display either.	Electrical auxiliary power supply is not adequate.	<ul style="list-style-type: none"> <li>• Check the electrical auxiliary power supply.</li> </ul>
	In case of very high continuous loads due to vibrations (oscillations): <ul style="list-style-type: none"> <li>• Screws of the electrical connecting terminals may be loosened.</li> <li>• Electrical connecting terminals and/or electronic components may be knocked out.</li> </ul>	<ul style="list-style-type: none"> <li>• Tighten the screws firmly and secure using sealing wax.</li> <li>• Repair</li> <li>• For prevention: Install the positioner on the damping pads.</li> </ul>

Fault table 5

**See also**

Repair/Upgrading (Page 244)



## Technical data

### 13.1 Rated conditions

Rated conditions	
Ambient conditions	For use indoors and outdoors.
Ambient temperature	In hazardous areas, observe the maximum permissible ambient temperature corresponding to the temperature class.
<ul style="list-style-type: none"> <li>Permissible ambient temperature for operation <sup>2)3)</sup></li> </ul>	-30 ... +80 °C (-22 ... +176 °F)
<ul style="list-style-type: none"> <li>Height</li> </ul>	2000 m above sea level. At altitudes greater than 2000 m above sea level, use a suitable power supply.
<ul style="list-style-type: none"> <li>Relative humidity</li> </ul>	0 ... 100%
Degree of pollution	2
Overvoltage category	II
Degree of protection <sup>1)</sup>	IP66 to IEC/EN 60529 / NEMA 4X
Mounting position	Any; pneumatic connections and exhaust air outlet not facing up in wet environment, Freezing of the exhaust air outlets (Page 41)
Vibration resistance	
<ul style="list-style-type: none"> <li>Harmonic oscillations (sine) according to EN 60068-2-6/10.2008</li> </ul>	3.5 mm (0.14"), 2 ... 27 Hz, 3 cycles/axle 98.1 m/s <sup>2</sup> (321.84 ft/s <sup>2</sup> ), 27 ... 300 Hz, 3 cycles/axle
<ul style="list-style-type: none"> <li>Bumping (half-sine) according to EN 60068-2-27/02.2010</li> </ul>	150 m/s <sup>2</sup> (492 ft/s <sup>2</sup> ), 6 ms, 1000 shocks/axle
<ul style="list-style-type: none"> <li>Noise (digitally controlled) according to EN 60068-2-64/04.2009</li> </ul>	10 ... 200 Hz; 1 (m/s <sup>2</sup> ) <sup>2</sup> /Hz (3.28 (ft/s <sup>2</sup> ) <sup>2</sup> /Hz) 200 ... 500 Hz; 0.3 (m/s <sup>2</sup> ) <sup>2</sup> /Hz (0.98 (ft/s <sup>2</sup> ) <sup>2</sup> /Hz) 4 hours/axle
<ul style="list-style-type: none"> <li>Recommended range of continuous operation of the entire control valve</li> </ul>	≤ 30 m/s <sup>2</sup> (98.4 ft/s <sup>2</sup> ) without resonance peak
Climate class	
<ul style="list-style-type: none"> <li>Storage</li> </ul>	1K5, but -40 ... +80°C (1K5, but -40 ... +176°F)
<ul style="list-style-type: none"> <li>Transport</li> </ul>	2K4, but -40 ... +80°C (2K4, but -40 ... +176°F)

<sup>1)</sup> Max. impact energy 1 Joule for enclosure with inspection window 6DR5..0 and 6DR5..1 or max. 2 Joule for 6DR5..3

<sup>2)</sup> At ≤ -10 °C (≤ 14 °F) the display refresh rate of the indicator is limited. When using position feedback module, only T4 is permissible.

<sup>3)</sup> The following applies to order suffix (order code) **-Z M40**: -40 ... +80 °C (-40 ... +176°F)

## 13.2 Pneumatic data

Pneumatic data	
Auxiliary power (air supply)	Compressed air, carbon dioxide (CO <sub>2</sub> ), nitrogen (N), noble gases or cleaned natural gas
<ul style="list-style-type: none"> <li>Pressure <sup>1)</sup></li> </ul>	1.4 ... 7 bar (20.3 ... 101.5 psi)
Air quality to ISO 8573-1	
<ul style="list-style-type: none"> <li>Solid particulate size and density</li> </ul>	Class 3
<ul style="list-style-type: none"> <li>Pressure dew point</li> </ul>	Class 3 (min. 20 K (36 °F) below ambient temperature)
<ul style="list-style-type: none"> <li>Oil content</li> </ul>	Class 3
Unrestricted flow (DIN 1945)	
<ul style="list-style-type: none"> <li>Inlet air valve (ventilate actuator) <sup>2)</sup></li> </ul>	
2 bar; 0.1 KV (29 psi; 0.116 CV)	4.1 Nm <sup>3</sup> /h (18.1 USgpm)
4 bar; 0.1 KV (58 psi; 0.116 CV)	7.1 Nm <sup>3</sup> /h (31.3 USgpm)
6 bar; 0.1 KV (87 psi; 0.116 CV)	9.8 Nm <sup>3</sup> /h (43.1 USgpm)
<ul style="list-style-type: none"> <li>Exhaust valve (deerate actuator for all versions except fail in place) <sup>2)</sup></li> </ul>	
2 bar; 0.2 KV (29 psi; 0.232 CV)	8.2 Nm <sup>3</sup> /h (36.1 USgpm)
4 bar; 0.2 KV (58 psi; 0.232 CV)	13.7 Nm <sup>3</sup> /h (60.3 USgpm)
6 bar; 0.2 KV (87 psi; 0.232 CV)	19.2 Nm <sup>3</sup> /h (84.5 USgpm)
<ul style="list-style-type: none"> <li>Exhaust valve (deerate actuator for fail in place version)</li> </ul>	
2 bar; 0.1 KV (29 psi; 0.116 CV)	4.3 Nm <sup>3</sup> /h (19.0 USgpm)
4 bar; 0.1 KV (58 psi; 0.116 CV)	7.3 Nm <sup>3</sup> /h (32.2 USgpm)
6 bar; 0.1 KV (87 psi; 0.116 CV)	9.8 Nm <sup>3</sup> /h (43.3 USgpm)
Valve leakage	< 6·10 <sup>-4</sup> Nm <sup>3</sup> /h (0.0026 USgpm)
Throttle ratio	Adjustable up to ∞: 1
Auxiliary power consumption in the controlled state	< 3.6·10 <sup>-2</sup> Nm <sup>3</sup> /h (0.158 USgpm)
Sound pressure level	L <sub>Aeq</sub> < 75 dB L <sub>Amax</sub> < 80 dB
Sound pressure with installed booster <sup>3)</sup>	L <sub>Aeq</sub> < 95.2 dB L <sub>Amax</sub> < 98.5 dB

<sup>1)</sup> The following applies to fail in place double acting: 3 ... 7 bar (43.5 ... 101.5 psi)

<sup>2)</sup> When using device versions Ex d (6DR5..5-... and 6DR5..6-...), values are reduced by approximately 20%.

<sup>3)</sup> Read the warning notice "Increased sound pressure level".

### See also

Lever for position detection (Page 107)

## 13.3 Construction

Construction	
How does it work?	
• Range of stroke (linear actuator)	3 ... 130 mm (0.12 ... 5.12") (angle of rotation of the positioner shaft 16 ... 90°)
• Angle of rotation (part-turn actuator)	30 to 100°
Mounting method	
• On the linear actuator	Using mounting kit 6DR4004-8V and, where necessary, an additional lever arm 6DR4004-8L on actuators according to IEC 60534-6-1 (NAMUR) with a fin, columns, or a plane surface.
• On the part-turn actuator	Using mounting kit 6DR4004-8D or TGX:16300-1556 on actuators with mounting plane according to VDI/VDE 3845 and IEC 60534-6-2: The required mount must be provided on the actuator-side.
Weight, positioner without option modules or accessories	
• 6DR5..0 Glass-fiber reinforced polycarbonate enclosure	Approx. 0.9 kg (1.98 lb)
• 6DR5.11 aluminum enclosure, only single-acting	Approx. 1.3 kg (2.86 lb)
• 6DR5..2 stainless steel enclosure	Approx. 3.9 kg (8.6 lb)
• 6DR5..3 aluminum enclosure	Approx. 1.6 kg (3.53 lb)
• 6DR5..5 aluminum enclosure, flameproof, rugged	Approx. 5.2 kg (11.46 lb)
• 6DR5..6 stainless steel enclosure, flameproof, rugged	Approx. 8.4 kg (18.5 lb)
Material	
• Enclosure	
6DR5..0 polycarbonate	Glass-fiber reinforced polycarbonate (PC)
6DR5.11 aluminum, only single-acting	GD AlSi12
6DR5..2 stainless steel	Austenitic stainless steel 316Cb, mat. No. 1.4581
6DR5..3 aluminum	GD AlSi12
6DR5..5 aluminum, flameproof, rugged	GK AlSi12
6DR5..6 stainless steel enclosure, flameproof, rugged	Austenitic stainless steel 316L, mat. No. 1.4409
• Pressure gauge block	Aluminum AlMgSi, anodized or stainless steel 316
Versions	
• In the polycarbonate enclosure 6DR5..0	Single-acting and double-acting
• In aluminum enclosure 6DR5.11	Single-acting
• In aluminum enclosures 6DR5..3 and 6DR5..5	Single-acting and double-acting
• In stainless steel enclosures 6DR5..2 and 6DR5..6	Single-acting and double-acting
Torques	
• Part-turn actuator fixing screws DIN 933 M6x12-A2	5 Nm (3.7 ft lb)
• Linear actuator fixing screws DIN 933 M8x16-A2	12 Nm (8.9 ft lb)
• Gland pneumatic G¼	15 Nm (11.1 ft lb)
• Pneumatic gland 1/4-18 NPT	
Without sealant	12 Nm (8.9 ft lb)

13.4 Controller

<b>Construction</b>	
With sealant	6 Nm (4.4 ft lb)
• Cable glands	
Screw-in torque for plastic gland in all enclosures	4 Nm (3 ft lb)
Screw-in torque for cable gland made of metal/stainless steel in polycarbonate enclosure	6 Nm (4.4 ft lb)
Screw-in torque for metal/stainless steel glands in aluminum/stainless steel enclosure	6 Nm (4.4 ft lb)
Screw-in torque for NPT adapter made of metal/stainless steel in polycarbonate enclosure	8 Nm (5.9 ft lb)
Screw-in torque for NPT adapter made of metal/stainless steel in aluminum/stainless steel enclosure	15 Nm (11.1 ft lb)
Screw-in torque for NPT gland in the NPT adapter NOTE: To avoid damage to the device, the NPT adapter must be held in place while the NPT gland is screwed into the NPT adapter.	68 Nm (50 ft lb)
Tightening torque for union nut made of plastic	2.5 Nm (1.8 ft lb)
Tightening torque for union nut made of metal/stainless steel	4 Nm (3 ft lb)
• Pressure gauge block fixing screws	6 Nm (4.4 ft lb)
<b>Manometer</b>	
• Degree of protection	
Manometer made of plastic	IP31
Manometer, steel	IP44
Manometer made of stainless steel 316	IP54
• Vibration resistance	In accordance with DIN EN 837-1
<b>Connections, electrical</b>	
• Screw terminals	2.5 mm <sup>2</sup> AWG30-14
• Cable gland	
Without Ex protection as well as with Ex i	M20 x 1.5 or 1/2-14 NPT
With explosion protection Ex d	Ex d-certified M20 x 1.5; 1/2-14 NPT or M25 x 1.5
<b>Connections, pneumatic</b>	Female thread G <sup>1</sup> / <sub>4</sub> or <sup>1</sup> / <sub>4</sub> -18 NPT

## 13.4 Controller

<b>Controller</b>	
<b>Control unit</b>	
• Five-point controller	Adaptive
• Dead zone	
dEbA = auto	Adaptive
dEbA = 0.1 ... 10 %	Can be set as fixed value
<b>Analog-to-digital converter</b>	

Controller	
• Scanning time	10 ms
• Resolution	≤ 0,05 %
• Transmission error	≤ 0,2 %
• Temperature influence	≤ 0.1 %/10 K (≤ 0.1 %/18 °F)

## 13.5 Explosion protection







### 13.5.1 Breakdown of the article numbers

Each device has a nameplate. This nameplate shows a specific article number for the device. Lower-case letters are used and explained in the tables below for the variable digits in the article number. Each variable that is used stands for a different order version. You will find the order data in the FI 01 catalog on the Internet.

Table 13-1 Article number

1	2	3	4	5	6	7	-	8	9	10	11	12	-	13	14	15	16	-	
6	D	R	5	a	y	b	-	0	c	d	e	f	-	g	*	*	h	-	Z j j j











Table 13-2 Enclosure and the relevant variables

Enclosure polycarbonate 6DR5 (b = 0) 	Enclosure aluminum single-acting 6DR5 (b = 1) 	Enclosure stainless steel 6DR5 (b = 2) 	Enclosure aluminum single/double-acting 6DR5 (b = 3) 				
Enclosure aluminum flameproof 6DR5 (b = 5) 		Enclosure stainless steel flameproof 6DR5 (b = 6) 					
6DR5ayb-		0cdef-		g..h-		Z jjj	

13.5 Explosion protection

a (version) = 0, 2, 5, 6	c (Ex protection) = E, D, F, G, K	g = 0, 2, 6, 7, 8	jjj (-Z order code) = = A20, A40, C20, D53, D54, D55, D56, D57, F01, K**, L1A, M40,R**, S**, Y** * = any character
y (actuator) = 1, 2	d (thread) = G, N, M, P, R, S	h (manometer block) = 0, 1, 2, 3, 4, 9	
b (enclosure) = 0, 1, 2, 3	e (limit monitor) = 0, 1, 2, 3, 9		
	f (option module) = 0, 1, 2, 3		

### 13.5.2 Protection against explosion device and option modules

Type of protection 6DR5ayb-*cdef-g*Ah-Zjjj	Ex marking ATEX/IECEX	Ex marking FM-CSA
Intrinsic safety		
<ul style="list-style-type: none"> <li>For c = E and b = 0</li> </ul>	 II 2 G Ex ia IIC T6/T4 Gb	CI I Zn 1 AEx ib IIC Gb
<ul style="list-style-type: none"> <li>C73451-A430-D78</li> <li>External position detection system in the polycarbonate enclosure with potentiometer</li> </ul>	 II 3 G Ex ic IIC T6/T4 Gc	CI I Zn 1 Ex ib IIC Gb IS CI I Div 1 Gp A-D
Flameproof enclosure and dust protection by enclosure		
<ul style="list-style-type: none"> <li>For c = E and b = 5, 6</li> </ul>	 II 2 G Ex db IIC T6/T4 Gb  II 2 D Ex tb IIIC T100°C Db	<b>FM</b> CI I Zn 1 AEx db IIC Gb XP CI I Div 1 Gp A-D <b>CSA</b> CI I Zn 1 Ex db IIC Gb XP CI I Div 1 Gp C-D <b>FM + CSA</b> Zn 21 AEx tb IIIC T100°C Db Zn 21 Ex tb IIIC T100°C Db DIP CI II, III Div 1 Gp E-G
Intrinsic safety		
<ul style="list-style-type: none"> <li>For c = E and b = 1, 2, 3</li> </ul>	 II 2 G Ex ia IIC T6/T4 Gb  II 3 G Ex ic IIC T6/T4 Gc  II 2 D Ex ia IIIC T130°C Db	CI I Zn 1 AEx ib IIC Gb CI I Zn 1 Ex ib IIC Gb Zn 21 AEx ib IIIC, T130°C Db Zn 21 Ex ib IIIC, T130°C Db IS CI I, II, III Div 1 Gp A-G
Increased safety (non incendive NI)		
<ul style="list-style-type: none"> <li>For c = G and b = 1, 2, 3, 5, 6</li> </ul>	 II 3 G Ex ec IIC T6/T4 Gc	CI I Zn 2 AEx nA IIC Gc CI I Zn 2 Ex nA IIC Gc NI CI I Div 2 Gp A-D
Increased safety (non incendive NI) and dust protection by enclosure		
<ul style="list-style-type: none"> <li>For c = D and b = 1, 2, 3</li> </ul>	 II 2 D Ex tb IIIC T100°C Db  II 3 G Ex ec IIC T6/T4 Gc	<b>DIP:</b> Zn 21 AEx tb IIIC T100°C Db Zn 21 Ex tb IIIC T100°C Db DIP CI II, III Div 1 Gp E-G <b>NI:</b> CI I Zn 2 AEx nA IIC Gc CI I Zn 2 Ex nA IIC Gc NI CI I Div 2 Gp A-D
Intrinsic safety, increased safety (non incendive NI) and dust protection by enclosure		

13.5 Explosion protection

Type of protection 6DR5ayb-*cdef-g*Ah-Zjjj	Ex marking ATEX/IECEX	Ex marking FM-CSA
<ul style="list-style-type: none"> <li>For c = K and b = 1, 2, 3, 5, 6</li> <li>6DR4004-1ES External Position Transmitter (Potentiometer)</li> <li>6DR4004-2ES External Position Transmitter (NCS)</li> </ul>	<ul style="list-style-type: none"> <li> II 2 G Ex ia IIC T6/T4 Gb</li> <li> II 3 G Ex ic IIC T6/T4 Gc</li> <li> II 2 D Ex ia IIIC T130°C Db</li> <li> II 2 D Ex tb IIIC T100°C Db</li> <li> II 3 G Ex ec IIC T6/T4 Gc</li> </ul>	<p><b>IS:</b>                      Cl I Zn 1 AEx ib IIC Gb                      Cl I Zn 1 Ex ib IIC Gb                      Zn 21 AEx ib IIIC, T130°C Db                      Zn 21 Ex ib IIIC, T130°C Db                      IS Cl I, II, III Div 1 Gp A-G</p> <p><b>NI:</b>                      Cl I Zn 2 AEx nA IIC Gc                      Cl I Zn 2 Ex nA IIC Gc                      NI Cl I Div 2 Gp A-D</p> <p><b>DIP:</b>                      Zn 21 AEx tb IIIC T100°C Db                      Zn 21 Ex tb IIIC T100°C Db                      DIP Cl II, III Div 1 Gp E-G</p>
Intrinsic safety and increased safety (non-incendive NI)		
<ul style="list-style-type: none"> <li>For c = F and b = 1, 2, 3, 5, 6</li> <li>6DR4004-6N**-0-*** Non-Contacting Sensor (NCS)</li> </ul>	<ul style="list-style-type: none"> <li> II 2 G Ex ia IIC T6/T4 Gb</li> <li> II 3 G Ex ic IIC T6/T4 Gc</li> <li> II 2 D Ex ia IIIC T130°C Db</li> <li> II 3 G Ex ec IIC T6/T4 Gc</li> </ul>	<p><b>IS:</b>                      Cl I Zn 1 AEx ib IIC Gb                      Cl I Zn 1 Ex ib IIC Gb                      Zn 21 AEx ib IIIC T130°C Db                      Zn 21 Ex ib IIIC T130°C Db                      IS Cl I, II, III Div 1 Gp A-G</p> <p><b>NI:</b>                      Cl I Zn 2 AEx nA IIC Gc                      Cl I Zn 2 Ex nA IIC Gc                      NI Cl I Div 2 Gp A-D</p>

13.5.3 Maximal permissible ambient temperature ranges

Positioner, modules and position detection systems	Temperature class T4	Temperature class T6
Positioner		
<ul style="list-style-type: none"> <li>6DR5ayb-0cdef-g*Ah-Z jjj</li> </ul>	-30 °C ≤Ta ≤ +80 °C	-30 °C ≤Ta ≤ +50 °C
<ul style="list-style-type: none"> <li>6DR5ayb-0cdef-g*Ah-Z <b>M40</b></li> </ul>	-40 °C ≤Ta ≤ +80 °C	-40 °C ≤Ta ≤ +50 °C
<ul style="list-style-type: none"> <li>6DR5ayb-0cdef-g*Ah-Z jjj for a = 0, 2 and f = 0, 2</li> </ul>	-30 °C ≤Ta ≤ +80 °C	-30 °C ≤Ta ≤ +60 °C
<ul style="list-style-type: none"> <li>6DR5ayb-0cdef-g*Ah-Z <b>M40</b> for a = 0, 2 and f = 0, 2</li> </ul>	-40 °C ≤Ta ≤ +80 °C	-40 °C ≤Ta ≤ +60 °C
Position feedback module / Analog Output Module (AOM)		



Positioner, modules and position detection systems	Temperature class T4	Temperature class T6
<ul style="list-style-type: none"> <li>Already fitted: 6DR5ayb-0cdef-g.Ah-Z ... for f = 1, 3</li> <li>Can be retrofitted 6DR4004-6J</li> </ul>	-30 °C ≤ Ta ≤ +80 °C	-
<ul style="list-style-type: none"> <li>Already fitted and can be retrofitted: 6DR5ayb-0cdef-g*Ah-Z <b>M40</b> for f = 1, 3</li> </ul>	-40 °C ≤ Ta ≤ +80 °C	-
Position detection systems		
<ul style="list-style-type: none"> <li>Non-Contacting Sensor (NCS) 6DR4004-6N**-0-***</li> </ul>	-40 °C ≤ Ta ≤ +90 °C	-40 °C ≤ Ta ≤ +70 °C
<ul style="list-style-type: none"> <li>External position detection system in the polycarbonate enclosure with potentiometer C73451-A430-D78</li> </ul>	-40 °C ≤ Ta ≤ +90 °C	-40 °C ≤ Ta ≤ +60 °C
<ul style="list-style-type: none"> <li>External Position Transmitter (Potentiometer) 6DR4004-1ES</li> </ul>	-40 °C ≤ Ta ≤ +90 °C	-40 °C ≤ Ta ≤ +60 °C
<ul style="list-style-type: none"> <li>External Position Transmitter (NCS) 6DR4004-2ES</li> </ul>	-40 °C ≤ Ta ≤ +90 °C	-40 °C ≤ Ta ≤ +50 °C

## 13.6 Certificates, approvals, explosion protection

Certificates and approvals	
Classification according to pressure equipment directive (PED 2014/68/EU)	For fluid group 1 gases; fulfills requirements according to article 4, paragraph 3 (good engineering practice SEP)
CE conformity	The applicable directives and applied standards with their revision levels can be found in the EU declaration of conformity on the Internet.
UL conformity	You can find the appropriate "Standard(s) for Safety", including the relevant versions, in the UL-CERTIFICATE OF COMPLIANCE on the Internet.

## 13.7 Electrical specifications

	Basic device without explosion protection	Basic device with explosion protection Ex d	Basic device with explosion protection Ex "ia"	Basic device with explosion protection Ex "ic", "ec", "t"
Auxiliary power supply bus circuit			Bus-powered	
Bus voltage	9 ... 32 V	9 ... 32 V	9 ... 24 V	9 ... 32 V
For connecting to circuits with the following peak values				

13.7 Electrical specifications

	Basic device with- out explosion pro- tection	Basic device with explosion protec- tion Ex d	Basic device with explosion protec- tion Ex "ia"	Basic device with explosion protec- tion Ex "ic", "ec", "t"
• Bus connector with FISCO supply unit	-	-	U <sub>i</sub> = 17.5 V I <sub>i</sub> = 380 mA P <sub>i</sub> = 5.32 W	"ic": U <sub>i</sub> = 17.5 V I <sub>i</sub> = 570 mA "ec"/"t": U <sub>n</sub> ≤ 32 V
• Bus connector with barrier			U <sub>i</sub> = 24 V I <sub>i</sub> = 250 mA P <sub>i</sub> = 1.2 W	"ic": U <sub>i</sub> = 32 V "ec"/"t": U <sub>n</sub> ≤ 32 V
Effective inner capacitance C <sub>i</sub>	-	-	Negligible	Negligible
Effective inner inductance L <sub>i</sub>	-	-	8 μH	"ic": 8 μH
Current consumption	11.5 mA ± 10 %			
Additional fault current	0 mA			
<b>Safety shutdown can be activated using "Jumper" (terminals 81 and 82)</b>	Electrically isolated from bus circuit and binary input			
• Input resistance	> 20 kΩ			
• Signal status "0" (shutdown active)	0 ... 4.5 V or unused			
• Signal status "1" (shutdown inactive)	13 ... 30 V			
• For connecting to power source with the following peak values	-	-	U <sub>i</sub> = 30 V I <sub>i</sub> = 100 mA P <sub>i</sub> = 1 W	"ec": U <sub>n</sub> ≤ 30 V I <sub>n</sub> ≤ 100 mA "ic": U <sub>i</sub> = 30 V I <sub>i</sub> = 100 mA
• Effective internal capacitance and inductance	-	-	Negligible	Negligible
<b>Binary input BE1 (terminals 9 and 10) electrically connected to the bus circuit</b>	Jumpered or connection to switch contact. Suitable only for floating contact; max. contact load < 5 μA with 3 V			
<b>Galvanic isolation</b>				
• For basic device without Ex protection and for basic device with Ex d	Galvanic isolation between the basic device and the input for safety shutdown and the outputs of option modules.			
• For basic device Ex "ia"	The basic device, the input for safety shutdown, and the outputs of option modules are individual intrinsically safe circuits.			

	Basic device without explosion protection	Basic device with explosion protection Ex d	Basic device with explosion protection Ex "ia"	Basic device with explosion protection Ex "ic", "ec", "t"
• For basic device Ex "ic", "ec", "t"	Galvanic isolation between the basic device and the input for safety shutdown and the outputs of option modules.			
Test voltage	DC 840 V, 1 s			

## 13.8 Communication


### Communication PROFIBUS PA

Communication	Layer 1 + 2 according to PROFIBUS PA, transmission technique according to IEC 1158-2; Slave function layer 7 (protocol layer) according to PROFIBUS DP, Standard EN 50170 with extended PROFIBUS functionality (all data acyclic, manipulated variable, feedbacks and states are also cyclic)
C2 connections	Four connections to master class 2 are supported, automatic connection setup 60 s after break in communication
Device profile	PROFIBUS PA profile B, version 3.02, more than 150 objects
Response time to master message	Typically 10 ms
Device address	126 (when delivered)
PC parameter assignment software	SIMATIC PDM; supports all device objects. The software is not included in the scope of delivery.

## 13.9 Technical data for natural gas as actuator medium

### Introduction

Note when using an actuator with natural gas that this can escape at the exhaust air outlets.



① Base plate

② Exhaust air outlet enclosure ventilation

③ Exhaust air outlet sound absorber

④ Exhaust air outlet near the pneumatic connections

### Note

The following applies for exhaust air outlet with sound absorber ③:

The positioner is supplied as standard with a sound absorber. To provide an outlet for the exhaust air, replace the sound absorber by a G $\frac{1}{4}$  pipe coupling.

The following applies for enclosure ventilation ② and control air outlet ④:

1. With the "flameproof enclosure" device version in an aluminum enclosure with order suffix -Z K50 "Operation with natural gas", you can completely collect and discharge the escaping natural gas.
2. In all other device versions, the escaping natural gas is released into the environment.

### Maximum values for escaping natural gas

- The quantity of escaping natural gas is negligible during regulated operation.
- If a control error occurs, a maximum of 30 NI/min of natural gas will escape at the enclosure vent ② and a maximum of 89 NI/min at the control air outlet ④.

### See also

Lever for position detection (Page 107)

## 13.10 Option modules

### 13.10.1 Alarm module

	Without explosion protection or suitable for use in the SIPART PS2 Ex d	With Ex protection Ex "ia"	With explosion protection Ex "ic", "ec", "t"
<b>Alarm module</b>	6DR4004-8A	6DR4004-6A	6DR4004-6A
3 binary output circuits			
<ul style="list-style-type: none"> <li>Alarm output A1: Terminals 41 and 42</li> <li>Alarm output A2: Terminals 51 and 52</li> <li>Fault message output: Terminals 31 and 32</li> </ul>			
• Auxiliary voltage $U_{Aux}$	$\leq 35$ V and the current consumption is to be limited to $< 25$ mA	-	-
• Signal status			
High (not addressed)	Conductive, $R = 1$ k $\Omega$ , $+3/-1$ % *)	$\geq 2.1$ mA	$\geq 2.1$ mA
Low *) (addressed)	Deactivated, $I_R < 60$ $\mu$ A	$\leq 1.2$ mA	$\leq 1.2$ mA
*) The status is also Low if the basic device is faulty or without a auxiliary power.	*) When using in the flame-proof housing, the current consumption must be restricted to 10 mA per output.	Switching threshold for supply according to EN 60947-5-6: $U_{Aux} = 8.2$ V, $R_i = 1$ k $\Omega$	Switching threshold for supply according to EN 60947-5-6: $U_{Aux} = 8.2$ V, $R_i = 1$ k $\Omega$
• For connecting to circuits with the following peak values	-	$U_i = 15$ V DC $I_i = 25$ mA $P_i = 64$ mW	"ic": $U_i = 15$ V DC $I_i = 25$ mA "ec"/"t": $U_n \leq 15$ V DC
Effective internal capacitance	-	$C_i = 5.2$ nF	$C_i = 5.2$ nF
Effective internal inductance	-	$L_i =$ negligibly small	$L_i =$ negligibly small
1 binary input circuit			
<ul style="list-style-type: none"> <li>Binary input BI2: Terminals 11 and 12, terminals 21 and 22 (jumper)</li> <li>Galvanically connected with the basic device</li> </ul>			
Signal status 0	Floating contact, open		
Signal status 1	Floating contact, closed		
Contact load	3 V, 5 $\mu$ A		
• Electrically isolated from the basic device			
Signal status 0	$\leq 4.5$ V or open		
Signal status 1	$\geq 13$ V		
Internal resistance	$\geq 25$ k $\Omega$		

13.10 Option modules

	Without explosion protection or suitable for use in the SIPART PS2 Ex d	With Ex protection Ex "ia"	With explosion protection Ex "ic", "ec", "t"
• Static destruction limit	± 35 V	-	-
• Connecting to circuits with the following peak values	-	$U_i = \text{DC } 25.2 \text{ V}$	"ic": $U_i = \text{DC } 25.2 \text{ V}$ "ec"/"t": $U_n \leq \text{DC } 25.5 \text{ V}$
Effective internal capacitance	-	$C_i = \text{negligibly small}$	$C_i = \text{negligibly small}$
Effective internal inductance	-	$L_i = \text{negligibly small}$	$L_i = \text{negligibly small}$
Galvanic isolation	The three outputs, the BI2 input and the basic device are galvanically isolated from each other.		
Test voltage	DC 840 V, 1 s		

13.10.2 Position feedback module

	Without explosion protection or suitable for use in the SIPART PS2 Ex d	With Ex protection Ex ia (use only in temperature class T4)	With explosion protection Ex "ic", "ec", "t"
<b>Position feedback module</b>	6DR4004-8J	6DR4004-6J	6DR4004-6J
Direct current output for position feedback	1 current output, terminals 61 and 62		
	2-wire connection		
Rated signal range	4 ... 20 mA, short-circuit proof		
Dynamic range	3.6 ... 20.5 mA		
Auxiliary voltage $U_{Aux}$	+12 ... +35 V	+12 ... +30 V	+12 ... +30 V
External load $R_B$ [kΩ]	$\leq (U_{Aux} [\text{V}] - 12 \text{ V})/I$ [mA]		
Transmission error	$\leq 0.3\%$		
Temperature influence	$\leq 0.1\%/10 \text{ K}$ ( $\leq 0.1\%/18 \text{ }^\circ\text{F}$ )		
Resolution	$\leq 0.1\%$		
Residual ripple	$\leq 1 \%$		
For connecting to circuits with the following peak values		$U_i = \text{DC } 30 \text{ V}$ $I_i = 100 \text{ mA}$ $P_i = 1 \text{ W}$	"ic": $U_i = \text{DC } 30 \text{ V}$ $I_i = 100 \text{ mA}$ "ec"/"t": $U_n \leq \text{DC } 30 \text{ V}$ $I_n \leq 100 \text{ mA}$ $P_n \leq 1 \text{ W}$
Effective internal capacitance	-	$C_i = 11 \text{ nF}$	$C_i = 11 \text{ nF}$
Effective internal inductance	-	$L_i = \text{negligibly small}$	$L_i = \text{negligibly small}$
Galvanic isolation	Safe galvanic isolation from alarm option and basic device		
Test voltage	DC 840 V, 1 s		

### 13.10.3 SIA module

	Without Ex protection	With Ex protection Ex "ia"	With explosion protection Ex "ic", "ec", "t"
<b>SIA module</b>	6DR4004-8G	6DR4004-6G	6DR4004-6G
Limit encoder with slotted initiators and fault message output			
2 slotted initiators			
<ul style="list-style-type: none"> <li>Binary output (limit transmitter) A1: Terminals 41 and 42</li> <li>Binary output (limit transmitter) A2: Terminals 51 and 52</li> </ul>			
• Connection	2 wire technology in accordance with EN 60947-5-6 (NAMUR), for switching amplifiers connected on load side		
• Signal state High (not triggered)		> 2.1 mA	
• Signal state Low (triggered)		< 1.2 mA	
• 2 slotted initiators		Type SJ2-SN	
• Function		NC contact (NC, normally closed)	
• Connecting to circuits with the following peak values	Rated voltage 8 V, power consumption: $\geq 3$ mA (limit not activated), $\leq 1$ mA (limit activated)	$U_i = DC 15$ V $I_i = 25$ mA $P_i = 64$ mW	"ic": $U_i = DC 15$ V $I_i = 25$ mA "ec": $U_n \leq DC 15$ V $P_n \leq 64$ mW
Effective internal capacitance	-	$C_i = 161$ nF	$C_i = 161$ nF
Effective internal inductance	-	$L_i = 120$ $\mu$ H	$L_i = 120$ $\mu$ H
1 fault message output			
<ul style="list-style-type: none"> <li>Binary output: Terminals 31 and 32</li> </ul>			
• Connection	At switching amplifier in accordance with EN 60947-5-6: (NAMUR), $U_{Aux} = 8.2$ V, $R_i = 1$ k $\Omega$ ).		
• Signal state High (not triggered)	$R = 1.1$ k $\Omega$	> 2.1 mA	> 2.1 mA
• Signal state Low (triggered)	$R = 10$ k $\Omega$	< 1.2 mA	< 1.2 mA
• Auxiliary power $U_{Aux}$	$U_{Aux} \leq DC 35$ V $I \leq 20$ mA	-	-
• Connecting to circuits with the following peak values	-	$U_i = DC 15$ V $I_i = 25$ mA $P_i = 64$ mW	"ic": $U_i = DC 15$ V $I_i = 25$ mA "ec": $U_n \leq DC 15$ V $P_n \leq 64$ mW
Effective internal capacitance	-	$C_i = 5.2$ nF	$C_i = 5.2$ nF
Effective internal inductance	-	$L_i =$ negligibly small	$L_i =$ negligibly small
Galvanic isolation	The 3 outputs are galvanically isolated from the basic device.		
Test voltage	DC 840 V, 1 s		

### 13.10.4 Mechanical limit switch module

	Without Ex protection	With Ex protection Ex ia	With Ex protection Ex "ic", "t"
<b>Mechanical limit switch module</b>	6DR4004-8K	6DR4004-6K	6DR4004-6K
Limit encoder with mechanical switching contacts			
2 limit contacts			
<ul style="list-style-type: none"> <li>Binary output 1: Terminals 41 and 42</li> <li>Binary output 2: Terminals 51 and 52</li> </ul>			
• Max. switching current AC/DC	4 A	-	-
• For connecting to circuits with the following peak values	-	$U_i = 30\text{ V}$ $I_i = 100\text{ mA}$ $P_i = 750\text{ mW}$	"ic": $U_i = 30\text{ V}$ $I_i = 100\text{ mA}$ "t": $U_n = 30\text{ V}$ $I_n = 100\text{ mA}$
Effective internal capacitance	-	$C_i =$ negligibly small	$C_i =$ negligibly small
Effective internal inductance	-	$L_i =$ negligibly small	$L_i =$ negligibly small
• Max. switching voltage AC/DC	250 V/24 V	DC 30 V	DC 30 V
1 fault message output			
<ul style="list-style-type: none"> <li>Binary output: Terminals 31 and 32</li> </ul>			
• Connection	On switching amplifier according to EN 60947-5-6: (NAMUR), $U_{Aux} = 8.2\text{ V}$ , $R_i = 1\text{ k}\Omega$ .		
• Signal state High (not triggered)	$R = 1.1\text{ k}\Omega$	$> 2.1\text{ mA}$	$> 2.1\text{ mA}$
• Signal state Low (triggered)	$R = 10\text{ k}\Omega$	$< 1.2\text{ mA}$	$< 1.2\text{ mA}$
• Auxiliary power	$U_{Aux} \leq \text{DC } 35\text{ V}$ $I \leq 20\text{ mA}$	-	-
• Connecting to circuits with the following peak values	-	$U_i = 15\text{ V}$ $I_i = 25\text{ mA}$ $P_i = 64\text{ mW}$	"ic" : $U_i = 15\text{ V}$ $I_i = 25\text{ mA}$ "t": $U_n = 15\text{ V}$ $I_n = 25\text{ mA}$
Effective internal capacitance	-	$C_i = 5.2\text{ nF}$	$C_i = 5.2\text{ nF}$
Effective internal inductance	-	$L_i =$ negligibly small	$L_i =$ negligibly small
Galvanic isolation	The 3 outputs are galvanically isolated from the basic device		
Test voltage	DC 3150 V, 2 s		
Rated condition height	Max. 2 000 m mean sea level Use a suitable power supply at an altitude of more than 2 000 m above sea level.	-	-



### 13.10.5 EMC filter module

	Without Ex protection	With Ex protection Ex "ia", "ic"	With explosion protection Ex "ec", "t"
<p>The EMC filter module type 6DR4004-6F is required to connect electro-sensitive, external position detection, e.g. NCS module type 6DR4004-6N*/-8N* or an external position detection system with potentiometer type C73451-A430-D78 or 6DR4004-1ES.</p> <p>For devices without explosion protection, other types of potentiometers with a resistance of 10 kilohms can be connected.</p>			
Maximum values when powered by the base unit with PA (6DR55) or FF communication (6DR56)	$U_{max} = 5\text{ V}$	$U_o = 5\text{ V}$ $I_o = 75\text{ mA static}$ $I_o = 160\text{ mA transient}$ $P_o = 120\text{ mW}$ $C_o = 1\text{ }\mu\text{F}$ $L_o = 1\text{ mH}$	$U_{max} = 5\text{ V}$
Peak values when supplied by other basic devices (6DR50/1/2/3/9)	$U_{max} = 5\text{ V}$	$U_o = 5\text{ V}$ $I_o = 100\text{ mA}$ $P_o = 33\text{ mW}$ $C_o = 1\text{ }\mu\text{F}$ $L_o = 1\text{ mH}$	$U_{max} = 5\text{ V}$
Supply and signal power circuits	Galvanically connected with the basic device		

### 13.10.6 Internal NCS modules 6DR4004-5L and 6DR4004-5LE

Additional modules	Without Ex protection	With Ex protection Ex "ia"	With explosion protection Ex "ic", "ec", "t"
<b>Internal NCS module</b>	6DR4004-5L	6DR4004-5LE	6DR4004-5LE
Linearity (after corrections made by positioner)	$\pm 1\%$	$\pm 1\%$	$\pm 1\%$
Hysteresis	$\pm 0.2\%$	$\pm 0.2\%$	$\pm 0.2\%$

### 13.10.7 Other technical specifications

Technical specifications for additional option modules and accessories is available at:

- Technical specifications NCS (Page 325)
- Technical specifications of the external position detection system (Page 330)
- Sealing plug / thread adapter (Page 335)
- Positioner with remote control electronics (Page 355)



## Dimension drawing

### 14.1 Positioner in non-flameproof enclosure




Figure 14-1 Dimension drawing, dimensions in mm (inch)

	6DR5..0		6DR5..1	6DR5..2	6DR5..3	
	G $\frac{1}{4}$	1/4-18 NPT			G $\frac{1}{4}$	1/4-18 NPT
A	184.5 [7.26]	186.5 [7.34]	185 [7.28]	186.5 [7.34]	186.5 [7.34]	188.5 [7.42]
B	-	-	-	-	15 [0.59]	
C	95 [3.74]		84 [3.31]	99 [3.90]	98.6 [3.88]	
D	47.5 [1.87]		49.5 [1.95]	49.5 [1.95]	49.3 [1.94]	
E	88.5 [3.48]		88.8 [3.50]	88.5 [3.48]	88.8 [3.50]	
F*)	29.5 [1.16]		-	29.5 [1.16]	29.5 [1.16]	
G	39 [1.54]		44 [1.73]	39 [1.54]	39 [1.54]	
H	14.5 [0.57]		16 [0.63]	16 [0.63]	14.5 [0.57]	
J	96.6 [3.80]		96.6 [3.80]	98.5 [3.88]	103 [4.06]	
K	18.5 [0.73]		22 [0.87]	18.5 [0.73]	18.5 [0.73]	
L	18.5 [0.73]		7 [0.23]	18.5 [0.73]	18.5 [0.73]	

14.2 Terminal strip for positioner with polycarbonate enclosure


	6DR5..0		6DR5..1	6DR5..2	6DR5..3	
	G $\frac{1}{4}$	1/4-18 NPT			G $\frac{1}{4}$	1/4-18 NPT
M	-	-	26.5 [1.04]	41.5 [1.53]	40 [1.57]	
N	-	-	7.5	7.5	7.5	
O	14.5 [0.57]		14.5 [0.57]	14.5 [0.57]	15.5 [0.61]	
P	> 150 (5.91) Adhere to this minimum clearance P for service and maintenance above the cover.					

Dimensions in mm [inch]

\*) Dimensions only apply to double-acting actuators.


- 6DR5..0 Polycarbonate enclosure; dimensions with pneumatic connection G $\frac{1}{4}$  or 1/4-18 NPT
- 6DR5..1 Aluminum enclosure, single-acting
- 6DR5..2 Stainless steel enclosure, without inspection window
- 6DR5..3 Aluminum enclosure, single/double-acting; dimensions with pneumatic connection G $\frac{1}{4}$  or 1/4-18 NPT

## 14.2 Terminal strip for positioner with polycarbonate enclosure



① Thread depth  
Figure 14-2 Terminal strip, dimensions in mm (inch)

## 14.3 Positioner in flameproof enclosure



- ① All air connections G $\frac{1}{4}$  or  $\frac{1}{4}$ -18 NPT  
 ② Air connection Y2, only with double-acting version

Figure 14-3 Dimensions of positioner in flameproof enclosure

	6DR5..5	6DR5..6
A	5 [0.2]	-
B	60 (2.36)	-
C	25.7 (1.01)	21.7 (0.85)
D	33.5 (1.32)	25 [0.99]
E	33.5 (1.32)	-
F	158.5 [6.24]	160 [6.3]
G	235.3 [9.26]	227.6 [8.96]

Dimensions in mm [inch]

6DR5..5 Aluminum enclosure, flameproof; dimensions with pneumatic connection G $\frac{1}{4}$  or  $\frac{1}{4}$ -18 NPT

6DR5..6 Stainless steel enclosure, flameproof



## Spare parts/accessories/scope of delivery

### 15.1 Overview



#### WARNING

##### Assembling the components

When assembling components, ensure that only those positioners and option modules are combined with each other that are approved for the corresponding operating range.

These conditions particularly apply to safe operation of the positioner in hazardous areas. Observe the applicable certificates and approvals or the "Technical data (Page 281)".

#### Basic version

The positioner can be delivered for:

- Double-acting actuators
- Single-acting actuators

The positioner and its option modules are delivered as separate units and with different versions for the operation in:

- Hazardous environments and atmospheres
- Non-hazardous environments and atmospheres

#### Enclosure

The electronic unit with display, the position feedback, and the pneumatic block are integrated in the enclosure.

The enclosure is available in the following versions:

- Polycarbonate enclosure for single-acting and double-acting actuators
- Aluminum enclosure for single-acting or double-acting actuators
- Stainless steel enclosure for single and double-acting actuators
- Flameproof enclosure for single and double-acting actuators

#### Options

The positioner can be equipped with different option modules. The following modules are normally available:

- Position feedback module: two-wire current output 4 to 20 mA for position feedback
- Alarm module: 3 binary outputs and 1 binary input

15.2 Spare parts

- SIA module: one binary output for fault messages, two binary outputs for limit monitors
- Mechanical limit switch module with two switches and one alarm output
- Internal NCS module 6DR4004-5L/-5LE

The SIA module and the mechanical limit switch module cannot be used in device versions with flameproof enclosure. For more limitations, please refer to section "Technical data (Page 281)".

Accessories

- Pressure gauge block: 2 or 3 pressure gauges for single and double-acting positioners
- Mounting flange (NAMUR) for safety pneumatic block
- Mounting kits for linear and part-turn actuators





For separate mounting of positioner and position sensor


- External position detection system
- NCS sensor for contactless position detection

**Note**

The version is identified using a special nameplate.

15.2 Spare parts










	Description	Article number	For version
<b>Basic electronics</b>			
	PROFIBUS PA, not Ex	A5E00141523	6DR55...-N
	PROFIBUS PA, Ex	A5E00141550	6DR55...-D/E/F/G/K
	Interface module for positioner without basic electronics	A5E00151572	6DR5910-*
	Interface module for 19-inch slide-in module 4 ... 20 mA	A5E00151571	A5E00151560

	Description	Article number	For version
<b>Pneumatic block</b>			
	Single-acting, with seal and screws	C73451-A430-D80	6DR5.1.*





	Description	Article number	For version
	Double-acting, with seal and screws	C73451-A430-D81	6DR5.2.*
	Fail in place, with seal and screws	A5E34409029	6DR5* -Z F01
	Single-acting for temperature range extension -40 °C ... 80 °C, with seal and screws	A5E35377156	6DR5.1.* -Z M40
	Double-acting for temperature range extension -40 °C ... 80 °C, with seal and screws	A5E35377157	6DR5.2.* -Z M40
	Optimized for small actuators with seal and screws	A5E43291389	6DR5.1.* -Z K10
<b>Enclosure cover without Ex d</b>			
	Made from polycarbonate, with inspection window, single and double-acting, with cover seal and screws	C73451-A430-D82	6DR5..0-.N/E C73451-A430-D78
	Made from aluminum, with inspection window, single-acting, with cover seal and screws	C73451-A430-D83	6DR5.11-.N/E/F/G
	Made from aluminum, without inspection window, single-acting, with cover seal and screws	A5E00065819	6DR5.11-.D/K*
	Made from aluminum, with inspection window, single and double-acting, with cover seal and screws	A5E39637097	6DR5..3-*
	Made from aluminum, without inspection window, single and double-acting, with cover seal and screws	A5E39636806	6DR5..3-* -Z M40 6DR4004-1/2/3/4ES
<b>Magnet clamp, manometer, sound absorber</b>			

## 15.2 Spare parts

	Description	Article number	For version
	Magnet clamp for linear actuators	A5E00078031	6DR4004-...2*
	Magnet clamp made from anodized aluminum for rotary actuators	A5E00524070	6DR4004-...1/4*
	Manometer steel, process connection G1/8 (3 units)	A5E32527731	6DR5...-.....-...9 -R1A/-R2A 6DR4004-1P/-2P
	Manometer stainless steel, process connection G1/8 (3 units)	A5E32527735	6DR5...-.....-...9 -R1C/-R2C 6DR4004-1QP/-2Q
	Stainless steel sound absorber (3 units)	A5E32527711	6DR5..0/1/2/3/6-*
<b>Spare parts for flameproof enclosure Ex d</b>			
	Pneumatic connection board 1/4-18 NPT with seals and screws	A5E37056680	6DR5..6-..N/M/S*
	Pneumatic connection board G1/4 with seals and screws	A5E37056681	6DR5..6-..G/P/R/Q*
	Sealing plugs M25 and thread adapter M25 on M20 with seals	A5E37056682	6DR5..5/6-..G/M/Q*
	Sealing plugs M25 and thread adapter M25 on 1/2-14 NPT with seals	A5E37056685	6DR5..5/6-..N/P/Q*
	Enclosure cover with seal	A5E37056687	6DR5..6*
	Sealing set with seals for cover, button cover, pneumatic connection board, valve for enclosure ventilation and shaft sealing ring	A5E37056923	6DR5..6*

## 15.3 Scope of delivery of mechanical limit switch module

	Description	Article number	For version
<b>Small part set</b>			
	With cover seal, pneumatic terminal strips with <b>G thread</b> , air filter, O rings for pneumatic connections, screws, sound absorber, metal cable gland	A5E33519995	6DR5..0/3
	With cover seal, pneumatic terminal strips with <b>NPT thread</b> , air filter, O-rings for pneumatic connections, screws, sound absorber, metal cable gland and metal <b>NPT adapter</b>	A5E33519994	6DR5..0/3

**Note**

See Catalog FI 01 "Field devices for process automation" for additives and possible modules.

## 15.3 Scope of delivery of mechanical limit switch module


If the mechanical limit switch module was ordered for later installation, then the following components are included in the scope of delivery:

- One mechanical limit switch module with accessories
- DVD with product documentation
- One housing cover with enlarged aperture
- One insulating cover
- Two cable ties
- One set of signs; how these are to be attached depends on the version.

## 15.4 Scope of delivery EMC filter module

### Cable glands and adapters

The EMC filter module is supplied with various cable glands and adapters. The following figure shows the different variants.



Connections ① to ③ for power supply



- ① Adapter M20 to 1/2-14 NPT for 6DR5..0/1/2/3-0.N/P
- ② M12 connector for device version with PROFIBUS or FOUNDATION fieldbus communication for 6DR55/6..-0.R/S
- ③ Cable gland for connection thread M20x1.5 for 6DR5..0/1/2/3-0.G/M

Connections ④ to ⑥ for optional modules

- ④ Cable gland for connection thread M20x1.5 with seal insert for 6DR55/6..0-0.G/M/R/S
- ⑤ Blanking plug for device version without optional modules 6DR5...-0..00
- ⑥ Adapter M20 to 1/2-14 NPT for 6DR5..0/1/2/3-0.N/P

Figure 15-1 Positioner with the different cable glands and adapter

### Scope of delivery EMC filter module

	Description
	EMC filter module C73451-A430-L8
	Sealing ring for ⑥
	Cable tie
⑥	Adapter M20 to 1/2-14 NPT
④	Cable gland for connection thread, gray
④	Cable gland for connection thread, blue
	Sealing set for ④
	Sealing set plug for ④
	Screw for plastic
	Oval head screw M3x6

## 15.5 Accessories

For accessories, refer to Catalog FI 01 "Field devices for process automation", for example:

- Option modules
- NCS sensor for non-contacting position detection
- Mounting kits
- Operating software

## 15.6 Order data

In order to ensure that the ordering data you are using is not outdated, the latest ordering data is always available on the Internet:

Process instrumentation catalog (<http://www.siemens.com/processinstrumentation/catalogs>)



# Appendix

## A.1 Certificates

The certificates can be found on the DVD supplied and on the Internet at: Certificates (<http://www.siemens.com/processinstrumentation/certificates>)

## A.2 Technical support

### Technical Support

If this documentation does not provide complete answers to any technical questions you may have, contact Technical Support at:

- Support request (<http://www.siemens.com/automation/support-request>)
- More information about our Technical Support is available at Technical support (<http://www.siemens.com/automation/csi/service>)

### Internet Service & Support

In addition to our documentation, Siemens provides a comprehensive support solution at:

- Service&Support (<http://www.siemens.com/automation/service&support>) where you will find support news, support documents including EDDs and software, and also support from experts.

### Additional Support

If you have additional questions about the device, please contact your local Siemens representative.

Find your local contact partner at:

- Partner (<http://www.automation.siemens.com/partner>)

Documentation for various products and systems is available at:

- Instructions and manuals (<http://www.siemens.com/processinstrumentation/documentation>)

### See also

E-mail (<mailto:support.automation@siemens.com>)

SIPART PS2 product information (<http://www.siemens.com/sipartps2>)

Process instrumentation catalog (<http://www.siemens.com/processinstrumentation/catalogs>)





# External position detection

## B.1 Introduction to external position detection



### WARNING

#### External position detection system

Versions with flameproof enclosures may not be operated with an external position detection system with the same type of protection.

In some cases it makes sense to mount the position detection and the controller unit separately. A separate mounting the case, for example, with continuous and strong vibrations, high or too low ambient temperatures and nuclear radiation. A universal component is available for this purpose. It is suitable for part-turn and linear actuators. You will require the following:

#### One of the following external position detection systems

- Article number C73451-A430-D78 made of polycarbonate or with article number 6DR4004-1ES made of aluminum consisting of:
  - Positioner enclosure
  - Integrated friction clutch
  - Integrated potentiometer
  - Various blanking plugs and seals
- An external position detection system with article number 6DR4004-2ES, 3ES or 4ES comprising:
  - Positioner enclosure
  - Internal NCS module
  - Various blanking plugs and seals
  - Integrated SIA module (6DR4004-3ES) or GWK module (6DR4004-4ES)
- NCS sensor for non-contacting position detection 6DR4004-6N.../8N.
- Potentiometers with 3 k $\Omega$ , 5 k $\Omega$  or 10 k $\Omega$
- Position sensor with a signal range from 0 to 20 mA
- Position sensor with a signal range from 0 to 10 V

#### And a positioner

- Positioner in combination with EMC filter module 6DR5..0/1/2/3-0...2/3 or retrofitted as accessory 6DR4004-6F/-8F.
  - An EMC filter module as an accessory is provided in a set along with cable clamps and M20 cable glands.



## B.2.2 Mounting the NCS

### Function

The positioner facilitates the separate installation of the position detection system. The stroke or rotary angle is measured directly at the actuator by means of a non contacting sensor. It is therefore possible to install the controller unit at some distance away, e.g. on a mounting pipe or similar. The positioner is connected to the position detection system by means of an electrical cable.


Such a separate installation is useful whenever the ambient conditions at the valve exceed the specified positioner values.

The NCS consists of a molded sensor for fixed installation and a magnet. The magnet is mounted to the spindle on linear actuators, or to the stub shaft on part-turn actuators. The sensor housing is mounted onto the console on part-turn actuators and to the bracket on linear actuators. The bracket can be a NAMUR type, or any other mounting bracket.

Auxiliary power is supplied to the NCS via the EMC filter module 6DR4004-6F and EMC-compatibility is ensured at the same time.

EMC filter module ordering options:

- Installed in the positioner; see Catalog FI 01
- For retrofitting in the positioner; item number 6DR4004-6F. For information on retrofitting the EMC filter module, refer to the positioner operating instructions, chapter "Installation/ Mounting".



- ① Pneumatic line
- ② Pneumatic line for double-action actuators
- ③ Position detection system (10 k $\Omega$  potentiometer or NCS)
- ④ Electrical cable
- ⑤ Retrofittable EMC filter module (in the positioner)
- ⑥ Positioner

Figure B-3 Separate installation of the NCS and positioner

**B.2.2.1 Mounting on part-turn actuator**

**Requirements**

1. An EMC filter module in the positioner.
2. A non contacting sensor for part-turn actuators 6DR4004-.N.10 or 6DR4004-.N.40.
3. A part-turn actuator with interface to VDI/VDE 3845 and mounting console to VDI/VDE 3845, or a part-turn actuator with manufacturer-specific interface.


**NOTICE**

**Incorrect mounting**

A clearance of 3 mm must be maintained between the magnet and the mounting console in order to ensure correct measurement of the actuator position. The values transferred may be incorrect if this clearance is not given.

- Maintain a clearance of 3 mm between the top edge of the magnet ④ and the top edge of the mounting console ⑩.

**Description**



- |                                    |                                    |
|------------------------------------|------------------------------------|
| ① Tensioning ring                  | ⑧ Washer                           |
| ② Hex socket head screw size M3x12 | ⑨ Clamping table                   |
| ③ Spring element                   | ⑩ Mounting console                 |
| ④ Magnet                           | ⑪ Hexagon nut                      |
| ⑤ Hooks                            | ⑫ Hex socket head screw size M6x25 |
| ⑥ Plastic washer                   | ⑬ Non Contacting Sensor (NCS)      |
| ⑦ Hex socket head screw size M6x12 |                                    |

Figure B-4 Mounting on part-turn actuator with magnet holder made of glass fiber reinforced polyester (left figure) or anodized aluminum (right figure)

### Procedure for the part-turn actuator to VDI/VDE 3845

1. Slide the clamping table ⑨ onto the stub shaft of the part-turn actuator.
2. Mount the clamping table ⑨ to the stub shaft using a hex socket head screw ⑦ and washer ⑧.
3. Depending on the material of the magnet holder, proceed as follows:

Magnet holder made of glass fiber reinforced polyester	Magnet holder made of anodized aluminum
<ol style="list-style-type: none"> <li>1. Insert the plastic washer ⑥ into the magnet ④.</li> <li>2. Fix the magnet ④ onto the clamping table ⑨. The magnet ④ can now be rotated easily on the clamping table ⑨.</li> <li>3. Slide the tensioning ring ① over the magnet ④. Make sure that the spring elements ③ and the hook ⑤ on the magnet ④ are lined up above one another and that they engage. You will now have more resistance when turning the tensioning ring ① and magnet ④.</li> </ol>	<ol style="list-style-type: none"> <li>1. Place the magnet ④ onto the clamping table ⑨.</li> <li>2. Secure the magnet ④ to the clamping table ⑨ by connecting the two parts of the tensioning ring ① to the two hex socket head screws ②. The magnet ④ can now be rotated easily on the clamping table ⑨.</li> <li>3. Then tighten the two hex socket head screws ②. The magnet ④ can then no longer be rotated on the clamping table ⑨.</li> </ol>

4. Screw the NCS ⑬ onto the mounting console ⑩ using the hexagon socket-head screw ⑫, hex nut ⑪ and the washer ⑧.
5. Once the NCS ⑬ is mounted, the clearance of 3 mm between the top edge of the magnet ④ and the top edge of the mounting console ⑩ is set automatically.

### Procedure for part-turn actuators with manufacturer-specific interface

1. Steps 1 to 4 as above.
2. Set a clearance of 3 mm between the top edge of the magnet ④ and the top edge of the mounting console ⑩. Extend the stub shaft accordingly, or insert washers underneath the NCS housing ⑬.

### Reference

For information on the scope of delivery, refer to chapter "NCS sensor scope of delivery (Page 327)".


### B.2.2.2 Mounting on linear actuator up to 14 mm (0.55 inch)

#### Requirement

1. An EMC filter module in the positioner.
2. An NCS for linear actuators up to 14 mm (0.55 inch) 6DR4004-.N.20.
3. A linear actuator with interface to NAMUR. This installation must be carried out individually. Only a NAMUR mounting bracket can be used as mounting base. The following figure shows the assembly with NAMUR mounting bracket. Or:  
A linear actuator without interface to NAMUR and individual mounting solution.

You can find the dimensions of the NCS as well as the NCS magnet under Dimensional drawing of non-contacting sensor (Page 327).

## Description



Dimensions in mm

- |   |                                                                                                             |   |                                                                                              |
|---|-------------------------------------------------------------------------------------------------------------|---|----------------------------------------------------------------------------------------------|
| A | Mounting on a yoke with fin                                                                                 | ③ | Non Contacting Sensor (NCS)                                                                  |
| B | Mounting on a yoke with plane surface                                                                       | ④ | Hex socket head screw M6x25                                                                  |
| C | Mounting on a yoke with columns                                                                             | ⑤ | Magnet                                                                                       |
| ① | NAMUR mounting bracket IEC 60534 - not included in the scope of delivery                                    | ⑥ | Hex socket head screw M6x12                                                                  |
| ② | Assembly panel for Non Contacting Sensor (NCS) - individual solution; not included in the scope of delivery | ⑦ | Mounting bracket for the magnet - individual solution; not included in the scope of delivery |

Figure B-5 Example of the assembly on a linear actuator with a stroke up to 14 mm (0.55 inch)

## Procedure

1. Produce the mounting panel ② and mounting bracket ⑦ individually.
2. Align the sensor to the center of the stroke. Observe the dimensions specified in the figure.

## Reference

For information on the scope of delivery, refer to section "NCS sensor scope of delivery (Page 327)".

**See also**


Scope of delivery of NCS for linear actuators up to 14 mm (0.55 inch) . (Page 328)

**B.2.2.3 Mounting on linear actuator > 14 mm (0.55 inch)**


**Prerequisites**

1. An EMC filter module in the positioner.
2. An NCS for linear actuators > 14 mm (0.55 inch) 6DR4004-.N.30.
3. Linear actuator with interface to NAMUR  
Item no. based on the respective stroke range: 6DR4004-8V or 6DR4004-8V + 6DR4004-8L.  
or  
linear actuator without interface to NAMUR and individual mounting solution. Item No. 6DR4004-8VK or 6DR4004-8VL can be used as individual assembly solution, depending on the stroke range.

**Description**







- |   |                                       |   |                                  |
|---|---------------------------------------|---|----------------------------------|
| A | Mounting on a yoke with fin           | ⑨ | Spring washer A8                 |
| B | Mounting on a yoke with plane surface | ⑩ | Washer B 8.4                     |
| C | Mounting on a yoke with columns       | ⑪ | Washer B 6.4                     |
| ① | NAMUR mounting bracket IEC 60534      | ⑫ | Spring lock washer               |
| ② | Pick-up bracket                       | ⑬ | Spring washer A6                 |
| ③ | Clamping piece                        | ⑭ | Hexagonal screw size M6x25       |
| ④ | Dog pin                               | ⑮ | Hexagonal nut M6                 |
| ⑤ | Lever                                 | ⑯ | Square-head nut M6               |
| ⑥ | U bracket                             | ⑰ | Hexagonal nut M8                 |
| ⑦ | Hexagonal screw size M8x20            | ⑱ | Hex socket head screw size M6x25 |
| ⑧ | Hexagonal screw size M8x16            |   |                                  |

Figure B-6 Mounting instructions for linear actuators with a stroke > 14 mm (0.55 inch)

## Procedure

1. Mount the clamping pieces ③ to the actuator spindle using the hexagonal screw ⑭ and spring washers ⑬.
2. Slide the pick-up bracket ② into the milled recesses of the clamping pieces.
3. Set the necessary length.
4. Tighten the screws so that you can still shift the pick-up bracket ②.
5. Set the center of the pin ④ to the stroke range value specified on the actuator, or to the next higher scaling value of the lever ⑤. The actuating distance in mm will be displayed on successful initialization if you set the same value at parameter "3.YWAY" when commissioning the system.
6. Slide the lever ⑤ onto the shaft ⑱ up to the mechanical stop.
7. Secure the lever ⑤ using the hex socket head screw ⑱.

8. Mount the bracket ① to the NCS mounting kit using:

- Two hexagonal screws ⑧
- Spring washer ⑨
- Washer ⑩
- Hexagonal nut ⑰

The selection of the row of holes depends on the yoke width of the actuator. Make sure that the dog pin ④ engages in the pick-up bracket ② as close as possible to the spindle over the complete stroke range. The dog pin must not touch the clamping pieces.

9. Place the NCS assembly kit with the mounting bracket ① onto the actuator. Ensure that the dog pin ④ is guided inside the pick-up bracket ②.

10. Tighten the pick-up bracket ② .

11. Prepare the assembly parts for the relevant actuator type for installation:

- For mounting on yoke with fin: hexagonal screw ⑦, washer ⑩ and spring washer ⑨.
- For mounting on a yoke with plane surface: Four hexagonal screw ⑦ with washer ⑩ and spring washer ⑨.
- For actuator with columns: Two U brackets ⑥, four hexagonal screw ⑰ with washer ⑩ and spring washer ⑨.

12. Mount the NCS assembly kit to the yoke using the assembly parts that you prepared.

---

**Note**

**Observe the height**

Adjust the height of the NCS assembly kit so that the lever position is in line horizontally with the stroke center. Use the lever scale on the actuator for orientation. If a symmetrical assembly is not possible, you must always ensure that the lever is in horizontal position within the range of the stroke.

---

## Reference

For information on the scope of delivery, refer to section "NCS sensor scope of delivery (Page 327)"

### B.2.3 Connecting NCS to EMC filter module

#### Requirement

You need the EMC filter module, article number 6DR4004-6F or -8F for the electrical connection of the accessory part "NCS sensor for contactless position measurement" to the positioner. The positioner supplies auxiliary power to the NCS sensor via the EMC filter module.

#### Wiring diagram





Figure B-7 Example of connecting the NCS to the EMC filter module

## Procedure

The NCS sensor is equipped with a shielded four-pole cable. Wire this cable to the positioner as follows:

1. Feed the four-pole NCS cable ⑩ through the union nut and the cable gland. Note: The type of cable gland depends on the positioner version.
2. Tighten the cable gland ⑨.
3. Terminate the four-pole NCS cable ⑩ in the EMC module of the positioner in accordance with the wiring diagram.
4. Place the cable clamp ⑦ onto the outer insulation of the four-pole NCS cable ⑩.
5. Use the screw ⑧ to bond the cable shielding lug ⑫ and the cable clamp ⑦ to the ground terminal of the positioner.
6. Grounding:  
The rear steel panel of the NCS sensor is inevitably bonded to the ground potential of the system when mounting on the console. This ground connection is only functional if there is a low-impedance connection to ground potential of the system. Ensure this state by measuring the ground resistance. If necessary, ensure proper grounding by means of an additional cable from the NCS sensor to ground potential.

## B.2.4 Commissioning of NCS

### B.2.4.1 Prerequisites / default settings

1. Supply electrical and pneumatic auxiliary power to the positioner. The top row of the display shows the current sensor voltage (0 to 100%), while the "NOINI" info flashes in the bottom row. The pneumatic actuator does not move.
2. If the positioner has already been initialized, perform a reset. Carry out the reset of parameter group "Init" in the '48.PRST' Preset (Page 158) parameter.
3. Preset for part-turn actuators:  
While the valve or flaps are closed, align the North pole of the magnet with the cable; "N" in position ⑦ in "Figure B-4 Mounting on part-turn actuator with magnet holder made of glass fiber reinforced polyester (left figure) or anodized aluminum (right figure) (Page 316)".
4. Monitor the display of the positioner while adjusting the actuator to its mechanical stops by means of ▲ and ▼ at the positioner. Verify that the displayed values never exceed the range from P2.0 to P98.0.

---

#### Note

This condition cannot be met with slipping flaps or linear actuators that exceed the mechanical actuation limits.

---

### B.2.4.2 Initialization of part-turn actuators

#### Procedure

1. For part-turn actuators operating in standard control direction, set parameter "1.YFCT" to "ncSt", or to "-ncSt" in case of inverse control direction.
2. Launch initialization as usual with "INITA".

### B.2.4.3 Initializing linear actuators with a stroke range up to 14 mm (0.55 inch)

#### Requirements

1. Set the "1.YFCT" parameter of the positioner to "ncSL" or - with inverse control direction - to "-ncSL".
2. Launch initialization as usual with "INITA".

### B.2.4.4 Initializing linear actuators with a stroke range > 14 mm (0.55 inch)

#### Note

Parameter values "ncSLL" and "-ncLL" are only available for devices of the 6DR5... series and only with the firmware version > C4. Set the value to 90° on devices of the 6DR5... series with firmware version < C5 (YAGL). This setting is also necessary for devices of the 6DR4... series. Resultant non-linearity can be corrected by means of the programmable characteristic by setting the parameter value from "SFCT" to "FrEE" and adapting the interpolation points.

#### Requirements

1. Set the "1.YFCT" parameter of the positioner to "ncSLL" or - with inverse control direction - to "-ncLL".
2. Launch initialization as usual with "INITA".

## B.2.5 Technical specifications NCS

Additional modules	Without Ex protection	With Ex protection Ex "ia"	With explosion protec- tion Ex "ic", "ec"
Travel range			
• Linear actuator 6DR4004-6/8N.20		3 to 14 mm (0.12 to 0.55")	
• Linear actuator 6DR4004-6/8N.30	10 to 130 mm (0.39 to 5.12"); up to 200 mm (7.87") on request		
• Part-turn actuator		30 to 100°	

## External position detection

### B.2 Non-Contacting Sensor

Additional modules	Without Ex protection	With Ex protection Ex "ia"	With explosion protection Ex "ic", "ec"
Linearity (after corrections made by positioner)		± 1 %	
Hysteresis		± 0.2 %	
Temperature influence (range: rotation angle 120° or stroke 14 mm)		≤ 0.1 %/10 K (≤ 0.1 %/18 °F) for -20 to +90 °C (-4 to +194 °F) ≤ 0.2%/10 K (≤ 0.2%/18 °F) for -40 to -20 °C (-40 to -4 °F)	
Climate class		According to IEC/EN 60721-3	
• Storage		1K5, but -40 to +90 °C (-40 to +194 °F)	
• Transport		2K4, but -40 to +90 °C (-40 to +194 °F)	
Vibration resistance			
• Harmonic oscillations (sine) according to IEC 60068-2-6		3.5 mm (0.14"), 2 to 27 Hz, 3 cycles/axis 98.1 m/s <sup>2</sup> (321.84 ft/s <sup>2</sup> ), 27 to 300 Hz, 3 cycles/axis	
• Bumping according to IEC 60068-2-29		300 m/s <sup>2</sup> (984 ft/s <sup>2</sup> ), 6 ms, 4000 shocks/axis	
Torque for cable gland nut made of	Plastic	Metal	Stainless steel
	2.5 Nm (1.8 ft lb)	4.2 Nm (3.1 ft lb)	4.2 Nm (3.1 ft lb)
Torque of hexagon socket-head screw M6x12 (shaft end or mounting bracket)		4 Nm (3 ft lb)	
Torque of hexagon socket head screw M6x25 (mounting console or mounting plate)		4 Nm (3 ft lb)	
Torque of hexagon socket head screw M3x12 (clamping ring)		1 Nm (0.7 ft lb)	
Degree of protection		IP68 / type 4X	
For connecting to circuits with the following peak values		U <sub>i</sub> = 5 V I <sub>i</sub> = 160 mA P <sub>i</sub> = 120 mW	U <sub>i</sub> = 5 V
Effective internal capacitance	-	C <sub>i</sub> = <sup>1)</sup>	C <sub>i</sub> = <sup>1)</sup>
Effective internal inductance	-	L <sub>i</sub> = <sup>2)</sup>	L <sub>i</sub> = <sup>2)</sup>

<sup>1)</sup> C<sub>i</sub> = 110 nF + 110 nF per meter of connecting cable

<sup>2)</sup> L<sub>i</sub> = 270 μH + 6.53 μH per meter of connecting cable

## B.2.6 Dimensional drawing of non-contacting sensor




Figure B-8 Dimensional drawing of the NCS and magnet

## B.2.7 NCS sensor scope of delivery

### B.2.7.1 Scope of delivery of NCS for part-turn actuators

6DR4004-.N.10	6DR4004-.N.40		
Quantity	Quantity	Name	Note
1	1	Magnet clamp	
5	5	Washer	6
2	2	Hex socket head screw	M6x12
1	-	Plastic washer	
1	1	Magnet	

B.2 Non-Contacting Sensor

6DR4004-.N.10	6DR4004-.N.40		
1	2	Tensioning ring	
4	4	Hexagon nut	M6
2	2	Hex socket head screw	M6x25
-	2	Hex socket head screw	M3x12
1	1	Non-contacting sensor	Cable lengths as ordered
1	1	Self-tapping screw for polycarbonate enclosure	F3x8
1	1	Sealing	For cable bushings
1	1	Plugs	For closing the sealing insert
1	1	Cable clamp	
1	1	DVD	with documentation

**B.2.7.2 Scope of delivery of NCS for linear actuators up to 14 mm (0.55 inch) .**

Linear actuator with a stroke range up to 14 mm (0.55 inch) 6DR4004-.N.20		
Quantity	Designation	Notes
1	Magnet	
5	Washer	6
2	Hex socket head screw	M6x12
4	Hexagon nut	M6
2	Hex socket head screw	M6x25
1	Non-contacting sensor	Cable lengths as ordered
1	Screw	F3x8
1	Sealing	For cable bushings
1	Plugs	For closing the sealing insert
1	Cable clamp	
1	DVD	with documentation

**B.2.7.3 Scope of delivery of NCS for linear actuators > 14 mm (0.55 inch) .**

Linear actuator > 14 mm (0.55 inch) 6DR4004-.N.30		
Quantity	Designation	Notes
1	NCS assembly kit, completely assembled	Mounting by means of assembly kit for NAMUR linear actuators Mounting kit available on separate order; refer to the 'Accessories' section in Catalog FI 01
1	DVD	with documentation



## B.3 External position detection system


### B.3.1 Principle of operation of external position detection system

The external position detection systems essentially consist of an enclosure and an internal position detection system. The position is recorded by a potentiometer or an internal NCS module, section "Principle of operation of NCS (Page 314)". The controller unit is separated from the positioner.

Such a separate installation is useful whenever the ambient conditions at the valve exceed the specified positioner values.

The external position detection system is secured to a console on rotary actuators and to a mounting bracket on linear actuators, section "Mounting to linear actuator (Page 42)".

Auxiliary power is supplied to the external position detection system via the EMC filter module, and EMC is ensured at the same time.



- ① Pneumatic line
- ② Pneumatic line for double-action actuators
- ③ External position detection system
- ④ Electrical cable
- ⑤ EMC filter module (fitted in the positioner or retrofittable)
- ⑥ Positioner

Figure B-9 External position detection system and positioner


Mounting of an external position detection system corresponds to the mounting of the positioner in a non-flameproof enclosure. Proceed as described in Section "Installing and mounting (Page 39)". The connection of the module is described in section "EMC filter modules 6DR4004-6F and -8F (Page 89)".

### B.3.2 Connecting the external position detection system to the EMC filter module

#### Requirement

You have an external position detection system.

**Wiring diagram**



① Connection of terminal Vcc is only needed for 6DR4004-2ES, -3ES and -4ES.

**B.3.3 Technical specifications of the external position detection system**

Rated conditions	
Ambient temperature	In hazardous areas, observe the maximum permissible ambient temperature corresponding to the temperature class.
<ul style="list-style-type: none"> <li>Permissible ambient temperature for operation</li> </ul>	-40 ... +90 °C (-40 ... +194 °F)
Degree of protection <sup>1)</sup>	IP66 / type 4X
Climate class	According to IEC/EN 60721-3
<ul style="list-style-type: none"> <li>Storage</li> <li>Transport</li> <li>Operation</li> </ul>	1K5, but -40 ... +90 °C (1K5, but -40 ... +194 °F) 2K4, but -40 ... +90 °C (2K4, but -40 ... +194 °F) 4K3, but -40 ... +90 °C (4K3, but -40 ... +194 °F)

<sup>1)</sup> Impact energy max. 1 joule.

Construction	
Material body	
<ul style="list-style-type: none"> <li>C73451-A430-D78</li> <li>6DR4004-1ES</li> </ul>	Glass-fiber reinforced polycarbonate (PC) Aluminum
Weight	
<ul style="list-style-type: none"> <li>Enclosure C73451-A430-D78</li> <li>Enclosure 6DR4004-1ES</li> </ul>	Approx. 0.9 kg (1.98 lb) Approx. 1.6 kg (3.53 lb)
Torque for cable gland nut made of plastic	See Construction (Page 283)

**B.3.4 Scope of delivery of external position detection system**

Scope of delivery of external position detection system C73451-A430-D78	
Quantity	Designation
1	DVD with documentation
1	External position detection system


Scope of delivery of external position detection system C73451-A430-D78	
Quantity	Designation
1	Gray cable gland
1	Sealing set 2x5 mm for cable gland
1	Plug for sealing set
1	Nameplate for device version <b>without</b> explosion protection



## Pressure gauge block

### Pressure gauge block

Pressure gauge blocks that are available as accessories are illustrated below. The gauges display measured values for the actuating pressure and supply air. The image to the left shows the pressure gauge block for single-acting actuators. The image to the right shows the pressure gauge block for double-acting actuators.



- Y1     Actuating pressure
- PZ     Supply air
- Y2     Actuating pressure

### Fixing the pressure gauge block

The pressure gauge block is fixed onto the lateral pneumatic connection of the positioner using the screws provided. Use the provided O-rings as sealing elements.




## Sealing plug / thread adapter

### D.1 Intended use of accessory part

The sealing plug and the thread adapter (components) can be used for installation in electrical equipment of flameproof "Ex d" type of protection of groups IIA, IIB, IIC as well as dust protection by enclosure "Ex t" type of protection.

### D.2 Safety instructions for accessory part

<p> <b>WARNING</b></p> <p><b>Incorrect assembly</b></p> <ul style="list-style-type: none"> <li>The component can be damaged or destroyed or its functionality impaired through incorrect assembly.             <ul style="list-style-type: none"> <li>Mount the component using a suitable tool. Refer to the information in Chapter "Technical specifications of accessory part (Page 336)", for example, torques for installation.</li> </ul> </li> <li>For "Explosion-proof Ex d" type of protection: To ensure an engagement depth of 8 mm, the enclosure must have a wall thickness of at least 10 mm.</li> </ul> <p><b>Improper modifications</b></p> <p>Danger to personnel, system and environment can result from modifications and repairs of the component, particularly in hazardous areas.</p> <ul style="list-style-type: none"> <li>Any modification which deviates from the delivery state is not permitted.</li> </ul> <p><b>Loss of enclosure type of protection</b></p> <p>IP protection is not guaranteed without sealant.</p> <ul style="list-style-type: none"> <li>Use a suitable thread sealant.</li> <li>If you are using the component in type of protection dust protection by enclosure "Ex t", use the supplied sealing ring (①, figure in Chapter "Dimension drawing for accessory part (Page 337)").</li> </ul> <p><b>Unsuitable fluids in the environment</b></p> <p>Danger of injury or damage to device.</p> <p>Aggressive media in the environment can damage the sealing ring. Type of protection and device protection may no longer be guaranteed.</p> <ul style="list-style-type: none"> <li>Make sure that the sealing material is suitable for the area of use.</li> </ul>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

**Note****Loss of type of protection**

Changes in the ambient conditions can loosen the component.

- As part of the recommended maintenance intervals: Check the compression fitting for tight fit and tighten, if necessary.



## D.3 Technical specifications of accessory part

### Technical specifications sealing plug and thread adapter



Sealing plug suitable for types of protection	Explosion-proof enclosure "d" of groups IIA, IIB, IIC Dust protection by enclosure "t"
Standard compliance	The components meet Directive 94/9. They meet the requirements of standards IEC/EN 60079-0; IEC/EN 60079-1; IEC/EN 60079-31.
Explosion protection	
• Gas explosion protection	II2G Ex d IIC
• Dust explosion protection	II1D Ex t IIIC
Certificates	IECEX TUN 13.0022 U TÜV 13 ATEX 121710 U
Material for sealing plug / thread adapter	Stainless steel
Material for seal	Vulcanized fiber or Victor Reinz AFM 30
Ambient temperature range	-40 ... +100 °C (-40 ... +212 °F)
For "Ex d" type of protection: Required wall thickness for tappings	10 mm
Torque	
• For thread size M20 x 1.5	65 Nm
• For thread size M25 x 1.5	95 Nm
• For thread size ½-14 NPT	65 Nm
Width A/F for thread size M20 x 1.5	27
Width A/F for thread size M25 x 1.5	30
Key size for thread size ½-14 NPT	10



## D.4 Dimension drawing for accessory part





Sealing plug Ex d, M20 x 1.5, dimensions in mm




Sealing plug Ex d, M25 x 1.5, dimensions in mm



D.4 Dimension drawing for accessory part



① Sealing ring: Use for dust protection "Ex t" type of protection.



Thread adapter Ex d, M25 x 1.5 on M20 x 1.5 and M25 x 1.5 on 1/2-14 NPT, dimensions in mm



Sealing plug Ex d 1/2 -14 NPT

# Booster

# E

## E.1 Increased sound pressure level



### CAUTION

#### Increased sound pressure level

Changes to the sound absorber of the positioner or the mounting of pneumatic components or pneumatic options on the positioner can cause a sound pressure with a level of 80 dBA to be exceeded.

- Wear suitable hearing protection to protect yourself against hearing damage.

## E.2 Booster introduction

In order to shorten the travel times, use a booster between the positioner and actuator. The booster increases the air performance.

With single-acting positioners, use of the boosters 6DR4004-1RJ, -1RK, -1RP or -1RQ, you connect to the air output Y1.

With double-acting positioners, use one of the boosters 6DR4004-2RJ, 2RK, 2RP or 2RQ which you connect to the air outputs Y1 and Y2.

---

### Note


#### Double-acting positioners

The booster changes the double-acting operation of the positioner in the event of the loss of supply air. The Integral Volume Booster or external Volume Booster is used to depressurize the output pressure; the valve position cannot be determined in the event of loss of supply air. The Integral Volume Booster does not have any effect on the operation of the positioner in the event of the failure of the control signal or power supply.

---

### E.3 Operating principle of booster

The input pressure from the positioner which acts on the effective surface of the upper diaphragm, produces a force which counteracts the force of the outlet pressure acting on the lower diaphragm at a ratio of 1:1. A change of the inlet pressure results in a difference so that balance has to be restored by a pilot valve. This increase presses the diaphragm module down, opens the pilot valve and releases supply air to the outlet until balance is restored. A decrease, on the other hand, ensures that the diaphragm module is raised, which opens the outlet air seat and lowers the outlet pressure such that it corresponds to the inlet pressure. These devices have a stabilizing bypass needle valve, so that the inlet pressure can directly go to the output in the event of small or gradual changes at the input. As the booster has a bypass, there is no loss of accuracy and if the needle valve is set properly, the persistence stability can be retained. The suitable setting of the needle valve depends on the size of the actuator. The larger the actuator, the more the needle valve can be closed and its stability retained.



- |                      |                   |
|----------------------|-------------------|
| ① Input              | ⑤ Supply pressure |
| ② Exhaust air outlet | ⑥ Output          |
| ③ Outlet air seat    | ⑦ Diaphragm       |
| ④ Supply air seat    | ⑧ Bypass valve    |

## E.4 Mounting booster, without flameproof enclosure


### Requirements

1. You are familiar with the safety instructions in section "Installing and mounting".
2. You have one of the following boosters:
  - With single-acting positioners, booster with the article number 6DR4004-1RJ or -1RK
  - With double-acting positioners booster with the article number 6DR4004-2RJ or -2RK


### A. Mount extension shaft and booster

Using the example of a single-acting positioner

1. Remove the extension shaft ① from the booster mounting kit.




2. Lower the extension shaft ① completely into the positioner.
3. Tighten the locking screw ② at the flat end of the positioner shaft.




4. Check that the extension shaft ① sits properly.
5. Screw the 4 threaded bolts ③ with the short end of the thread into the positioner.

6. Tighten the threaded bolts (3) around the extension shaft (1).



7. Insert the booster (14) via the threaded bolts (3).



8. Fasten the booster (14) to the 4 threaded bolts (3) with the lock washers (4) and nuts (5). The extension shaft (1) can still be rotated manually.

**Note**


**If the extension shaft (1) is no longer rotatable**

1. Loosen the nuts (5).
2. Bring the booster (14) in position by turning the extension shaft (1).
3. Tighten the nuts (5) again.


## B. Mounting the manometer and connection block

Using the example of a single-acting positioner

1. Fasten the manometer block (6) to the positioner with two screws (7) and lock washers (8).



2. Check whether the O-rings are in the manometer block. There are two O-rings in the single-acting version. There are three O rings with the double-acting version.
3. Apply light pressure to the lock washers (8). **The screws are tightened later.**
4. Fasten the connection block (9) to the booster with 2 screws (12) and 2 lock washers (13).




5. Fasten the connection block (9) to the manometer block (6) with 2 screws (10) and 2 lock washers (11).

6. Check whether the O-rings are in the manometer block. There are two O-rings in the single-acting version. There are three O-rings with the double-acting version.
7. Apply light pressure to the lock washers ⑬. **The screws are tightened later.**


### C. Tighten screws

Tighten the screws in the following sequence:



1. Screws ⑦ which are used to fasten the manometer ⑥ to the positioner.
2. Screws ⑫ which are used to fasten the connection block ⑨ to the booster.
3. Screws ⑩ which are used to fasten the connection block ⑨ to the manometer ⑥.
4. Mount the positioner on the actuator as described in:
  - Mounting to linear actuator (Page 42)
  - Mounting to part-turn actuator (Page 47)
5. Use the existing interfaces on the booster.



**Result**

Left: Single-acting positioner with mounted booster

Right: Double-acting positioner with mounted booster


**E.5 Booster mounting, flameproof enclosure****Requirements**

1. You are familiar with the safety instructions in section "Installing and mounting (Page 39)".
2. You have one of the following boosters:
  - With single-acting positioners, booster with the article number 6DR4004-1RJ or -1RK
  - With double-acting positioners booster with the article number 6DR4004-2RJ or -2RK

**A. Mount extension shaft and booster**


Using the example of a single-acting positioner in a flameproof enclosure (Ex d)

1. Remove the extension shaft ① from the booster mounting kit.




2. Lower the extension shaft ① completely into the positioner.


3. Tighten the locking screw ② at the flat end of the positioner shaft.



4. Check that the extension shaft sits properly.
5. Screw the 4 threaded bolts (3) into the 4 holes (4).
6. Turn the threaded bolts (3) at least 5 to max. 9 full revolutions into the hole (4).



7. Insert the booster (14) via the threaded bolts (3).



8. Fasten the booster (14) to the 4 threaded bolts (3) with the lock washers (4) and nuts (5). The extension shaft (1) can still be rotated manually.

#### Note

**If the extension shaft (1) is no longer rotatable**


1. Loosen the nuts (5).
2. Bring the booster (14) in position by turning the extension shaft (1).
3. Tighten the nuts (5) again.

## B. Mounting the manometer and connection block

Using the example of a single-acting positioner in a flameproof enclosure (Ex d)

1. Fasten the manometer block (6) to the positioner with two screws (7) and lock washers (8).
2. Check whether the O-rings are in the manometer block. There are two O-rings in the single-acting version. There are three O rings with the double-acting version.

3. Apply light pressure to the lock washers (8). **The screws are tightened later.**



4. Fasten the connection block (9) to the booster with 2 screws (12) and 2 lock washers (13).
5. Fasten the connection block (9) to the manometer block (6) with 2 screws (10) and 2 lock washers (11).
6. Check whether the O-rings are in the manometer block. There are two O-rings in the single-acting version. There are three O-rings with the double-acting version.
7. Apply light pressure to the lock washers (13). **The screws are tightened later.**

### C. Tighten screws

Tighten the screws in the following sequence:

1. Screws (7) which are used to fasten the manometer (6) to the positioner.
2. Screws (12) which are used to fasten the connection block (9) to the booster.
3. Screws (10) which are used to fasten the connection block (9) to the manometer (6).
4. Mount the positioner on the actuator as described in:
  - Mounting to linear actuator (Page 42)
  - Mounting to part-turn actuator (Page 47)
5. Use the existing interfaces on the booster.

## Result





Figure E-1 Ex d: Booster mounted

## E.6 Booster commissioning

### Condition

1. You operate the positioner with a booster.
2. '49.PNEUM' Pneumatics type (Page 159) parameter is set to 'booSt'.

### Procedure for booster commissioning

1. Check whether the restrictor(s) on the positioner are completely open. With a new positioner, the restrictors are factory-set to open. The position of the restrictors is shown in the figure in section Device components (Page 28).
2. Set '31.DEBA' Deadband of controller (Page 148) to the largest value permissible for your process. The largest value is usually 0.5.
3. Start the automatic initialization process as described under Commissioning (Page 107).
4. With RUN 3, the initialization is stopped for five seconds. During these five seconds, start the function for setting the booster using the  button.  
A cycle is started which continuously determines the overshoots. The values 'oSUP' and 'oSDo' are shown alternately in the display. 'oSUP' and 'oSDo' represent the values of the overshoot in % of the total stroke.



5. During the automatic initialization, adjust the booster bypass using the adjustment screw on the booster. For single-acting actuators, there is one adjustment screw; there are two adjustment screws for double-acting actuators. Observe the description of your booster. If 'oCAY' is shown on the display, the overshoot is less than 3%.



Adjustment of the booster is sufficient. If you do not achieve the message 'oCAY' (<3% overshoot), try instead to achieve as small a value as possible. Observe the travel time in the process.

6. Press the ▲ or ▼ button. The positioner again runs through the initialization step RUN 3, starting with determination of the travel times. The following figure schematically shows the RUN 3 sequence for the booster.
7. 'FINISH' is shown on the display when the initialization has been completed.

If the process value on the display does not remain stable or if a constant manipulated variable cannot be achieved for a constant setpoint, further optimization of the controller data is necessary. This is described in section Optimization of controller data (Page 104).

### E.7 RUN 3 and 4 sequence (booster)





Figure E-2 RUN 3 and 4 (booster)

## E.8 Booster dimension drawings

### E.8.1 For positioners in non-flameproof enclosure



SA Single-acting  
 DA Double-acting

Figure E-3 Dimension drawings booster mounted on positioner, dimensions in mm (inch)



E.8.2 For positioners in flameproof enclosure




Figure E-4 Dimension drawings booster mounted on positioner in a flameproof enclosure, dimensions in mm (inch)

E.9 Technical specifications of booster

<b>Booster</b>	
Vibration resistance	
• Harmonic oscillations	According to ISA-S75.13
• Bumping (half-sine) according to EN 60068-2-27/02.2010	150 m/s <sup>2</sup> (492 ft/s <sup>2</sup> ), 6 ms, 1000 shocks/axis
Climate class	According to IEC/EN 60721-3

## Booster

### E.9 Technical specifications of booster


<b>Booster</b>	
• Storage	1K5, but -40 ... +80°C (1K5, but -40 ... +176°F)
• Transport	2K4, but -40 ... +80°C (2K4, but -40 ... +176°F)
<b>Weight booster, single-acting</b>	
• Booster, single-acting, polycarbonate, with positioner	4.0 kg (8.8 lb)
• Booster, single-acting, polycarbonate, installation kit only	2.9 kg (6.5 lb)
• Booster, single-acting with flameproof enclosure, with positioner	7.9 kg (17.4 lb)
• Booster, single-acting with flameproof enclosure, installation kit only	3.3 kg (7.3 lb)
<b>Weight booster, double-acting</b>	
• Polycarbonate enclosure, with positioner	5.3 kg (11.7 lb)
• Polycarbonate enclosure, installation kit only	4.3 kg (9.4 lb)
• Enclosure with flameproof enclosure, with positioner	9.3 kg (20.5 lb)
• Enclosure with flameproof enclosure, installation kit only	4.7 kg (10.4 lb)
<b>Connections</b>	
• Pneumatic	1/2-14 NPT or G½
• Manometer	1/4-18 NPT or G1/8
<b>Auxiliary power (air supply)</b>	
	Compressed air, carbon dioxide (CO <sub>2</sub> ), nitrogen (N), noble gases or cleaned natural gas
• Pressure	1.4 ... 7 bar (20.3 ... 101.5 psi)
• Supply air	According to ISO 8573-1
• Air consumption	1.2 x 10 <sup>-2</sup> Nm <sup>3</sup> /h (0.007SCFM)
<b>Manometer</b>	
	Thread 1/4-18 NPT or G½ with stainless steel enclosure
	MPa, bar, psi
	Degree of protection IP66
<b>Flow capacity</b>	
	Cv 2.0

# Positioner with remote control electronics

## F.1 Introduction

The control electronics is installed remotely with this version of the positioner. This remote control electronics allows the valves to be controlled in radiation contaminated environment, as all highly integrated electronic components are located in the area that is protected from radiation. Highly integrated electronic components are, for example, memory blocks and microprocessor blocks.

For the above described deployment you require:



① 19" slide-in module (Page 356)

Order the 19" slide-in module according to the number of required PA modules ③:

- Article No. A5E00250501 for a 19" slide-in module with 1 PA module
- Article No. A5E00250502 for a 19" slide-in module with 2 PA modules
- Article No. A5E00250503 for a 19" slide-in module with 3 PA modules

Each PA module comes with a QRL module ④ whose connectors are used for connecting one or more positioners ② with the 19" slide-in module ①.


② Positioner without basic electronics 6DR5910-... (Page 363)

## F.2 19" slide-in module

### F.2.1 Commissioning positioner 6DR5910-... and 19" slide-in module

#### Procedure

The figure shows a 19" slide-in module with three installed PA modules, article number A5E00250503.



- |   |                                                                  |   |                                                        |
|---|------------------------------------------------------------------|---|--------------------------------------------------------|
| ① | Rear with all connectors                                         | ⑧ | PA module 1                                            |
| ② | QRL module 3 with connection socket, connected to PA module 3 ⑩  | ⑨ | PA module 2                                            |
| ③ | QRL module 2 with connection sockets, connected to PA module 2 ⑨ | ⑩ | PA module 3                                            |
| ④ | QRL module 1 with connection sockets, connected to PA module 1 ⑧ | ⑪ | Front with handles                                     |
| ⑤ | PA bus with connectors PAI_IN, PAII_IN and PAI_OUT               | ⑫ | Channel (CH) of PA module 1 ⑤ with display and buttons |
| ⑥ | Mounting screws 3x                                               | ⑬ | Ground terminal                                        |
| ⑦ | Assignment of channels to PAI, PAII via coding bridges (7a)      | ⑭ | Connection socket on QRL module 1 ④                    |

Figure F-1 Example: Device view 19" slide-in module with 3 PA modules

1. Mount the positioner without basic electronics 6DR5910-... to the valve. Mounting corresponds to the mounting of the positioner in non-flameproof enclosure.  
Installing/mounting (Page 39)
2. Connect the positioner with the 19" slide-in module.  
Connecting the positioner to the 19" slide-in module (Page 358)
3. Note the grounding concept of the 19" slide-in module (Page 365).
4. Loosen the three mounting screws ⑥ and remove the cover.
5. Assign the channels via the coding bridges ⑦.  
PA cable connection for bus connection (Page 361)
6. Plug the male connector Burndy B50 into the corresponding socket on the QRL module.  
Connecting the positioner to the 19" slide-in module (Page 358)
7. Connect the PA cable that you want to use to connect the 19" slide-in module to the control room.  
PA cable connection for bus connection (Page 361)
8. Initialize the positioner using the three buttons of the associated channel of the PA module.  
Example: Channel CH1 of PA module 1 ⑧ for the first positioner. Repeat the initialization for all additional positioners until all channels are ready to use.

Note the technical specifications of the 19" slide-in module (Page 363) and the technical specifications of the positioner (Page 281).

Note the general safety instructions (Page 19) as well as the basic safety instructions in section:

- Installing/mounting (Page 39)
- Connect (Page 77)
- Commissioning (Page 107)

### F.2.2 Connecting the positioner to the 19" slide-in module

#### Requirement

You are familiar with:

- Safety instructions in section Connect (Page 77)
- Commissioning positioner 6DR5910-... and 19" slide-in module (Page 356)
- Grounding concept 19" slide-in module (Page 365)

#### Procedure





Figure F-2 Connecting positioner to 19" slide-in module

1. Strip off 85 mm of the cable jacket (with the shielding) and 5 mm of the insulated conductor insulation of the cable ②.



2. Remove the enclosure cover of the positioner 6DR5910-..., by loosening the four mounting screws.
3. Insert the prepared cable ② through the cable entry of the positioner.
4. Tighten the cable gland ③.
5. Connect the conductors of the cable ② to the terminals ④ of the positioner according to the connection diagram ⑤.
6. Fasten the enclosure cover with the four mounting screws.
7. Assign a maximum of five positioner (-channels) to the male connector Burndy B50 ⑥ in the field distributor ①.  
Connecting multiple positioners (Page 360)
8. Plug the male connector Burndy B50 ⑥ into the Burndy B50 ⑧ socket on the QRL module ⑦.
9. Specify the number of channels for each PROFIBUS line and set the coding bridges on the PA module accordingly.  
Connecting 19" slide-in modules (Page 362)  
PA cable connection for bus connection (Page 361)

## Result

The remote electronics in the 19" slide-in module is connected to the positioner 6DR5910-...

## F.2.3 Connecting multiple positioners

### Introduction

Each PA module installed in the 19" slide-in module has five channels (CH1 to CH5). A remote basic electronics with 8 terminals is behind each channel (CHx). Use a Burndy 50 connector to connect up to five positioners 6DR5910-.... The table shows the assignment of the individual connector pins and how the pins must be connected to the terminals on the positioner.

### Requirement

1. The ORL EC modules are already installed on the rear of the 19" slide-in module.
2. The cables with male connectors that are connected to the 19" slide-in module are available. To do that:
  - The positioners 6DR5910-... must be installed at the valves.
  - The positioners 6DR5910-... must be connected to the field distributors.

You can find an overview of the connection concept at Grounding concept 19" slide-in module (Page 365).

### Assignment table Burndy 50 connector

Note on "Connector contacts" column: Depending on the design of the Burndy 50 connector, the contacts are labeled either with numbers or letters.

QRL EC module																	
Connector contacts		Channel CH1	Contacts not assigned			Contacts B50		Channel CH2	Contacts B50		Channel CH3	Connector contacts		Channel CH4	Connector contacts		Channel CH5
1	C	Sup.+	9		x	17	U	Sup.+	25	FF	Sup.+	33	m	Sup.+	41	R	Sup.+
2	H	Sup.-	10	V	x	18	Y	Sup.-	26	D	Sup.-	34	s	Sup.-	42	V	Sup.-
3	M	Exh.+	11	Z	x	19	c	Exh.+	27	J	Exh.+	35	w	Exh.+	43	Z	Exh.+
4	S	Exh.-	12	DD	x	20	h	Exh.-	28	N	Exh.-	36	AO	Exh.-	44	d	Exh.-
5	W	GND	13	A	x	21	n	GND	29	T	GND	37	EI	GND	45	i	GND
6	a	VRef	14	E	x	22	t	VRef	30	X	VRef	38	B	VRef	46	p	VRef
7	e	GND	15	K	x	23	x	GND	31	b	GND	39	F	GND	47	u	GND
8	k	POS	16	P	x	24	BB	POS	32	f	POS	40	L	POS	48	y	POS
															49	CC	x
															50	HH	Shield



## F.2.4 PA cable connection for bus connection

1. There are three 3-pin connection sockets on the rear of the 19" slide-in module for connecting the bus cable.  
Commissioning positioner 6DR5910-... and 19" slide-in module (Page 356)
2. Connect up to two 2 PROFIBUS segments PAI\_IN or PAII\_IN.
3. Connect an additional 19" slide-in module to the same segment using PAI\_OUT.
4. Only the PAII\_IN I/O has an internal bus termination. If necessary, install an external bus termination to the segment at PAI. Plug the bus termination into the PAI\_OUT connection socket.
5. Use coding bridges to assign the individual channels to the segments. The coding bridges are located under the transparent cover of the PA modules.
6. Reconnect the coding bridges in pairs per channel. In the following example, channel CH1 is assigned to the segment PAII and channel CH5 to the channel PAI:




Figure F-3 Assignment of channels to PAI, PAII via coding bridges

### Note

#### Number of channels and slaves per PROFIBUS line

The maximum number of channels and slaves per PROFIBUS line depends on the data volume (input and output) and the capacity of the segment. Graphic in Connecting 19" slide-in modules (Page 362).

### F.2.5 Connecting 19" slide-in modules

Typical distribution with 12 slaves per PA segment and 15 channels per 19" slide-in module.





Figure F-4 Segment distribution

## F.3 Positioner with remote control electronics

### Device view of positioner 6DR5910



## F.4 Technical specifications, 19" slide-in module

This section contains the technical specifications of the 19" slide-in module. The technical specifications of the positioner 6DR5910-... correspond to the technical specifications (Page 281) of a polycarbonate enclosure.

Rated conditions	
Degree of protection <sup>1)</sup>	IP40 according to IEC/EN 60529
Mounting position	Any
Vibration resistance	
• Harmonic oscillations (sine wave) according to DIN EN 60082-2-6/05.96	3.5 mm (0.14"), 5 ... 8.4 Hz, 4 cycles/axle 10 m/s <sup>2</sup> (33 ft/s <sup>2</sup> ), 8.4 ... 500 Hz, 4 cycles/axle
• Oscillations (sinusoidal) according to DIN EN 60068-2-6/04.96	KWU DD 7080.9/93 KTA 3503 from 11.86
• Shock (half-sine) according to DIN EN 60068-2-27/02.2010	150 m/s <sup>2</sup> (492 ft/s <sup>2</sup> ), 11 ms, 6 shocks/axle
Climate class	According to IEC/EN 60721-3

F.5 Scope of delivery of remote control electronics

Rated conditions	
• Storage	-25 °C ... 80 °C (-13 °F ... 176 °F), 75% at 25 °C (77 °F), without condensation
• Temperature	-25 °C ... 80 °C (-13 °F ... 176 °F), 75% at 25 °C (77 °F), without condensation
• Operation	0 °C to 50 °C (32 °F ... 122 °F), 75% at 25 °C (77 °F), without condensation

Construction	
Weight	Approx. 8.5 kg
Enclosure material	19" slide-in module, 2HM, aluminum
Number of channels, basic electronics	5 / 10 / 15

Technical specifications for the controller unit is available at Controller (Page 284).

Electrical specifications	
Electrical connection	PA bus: LEMO Field: 50-pin male connector Burndy B50-f / 19-f /8-m, 50-pin socket connector Burndy B50
Auxiliary energy supply	Bus-powered
Bus voltage	9 ... 32 V
Current consumption	10.5 mA ± 10% per channel
Fault current	0 mA


Technical specifications for position feedback is available at Position feedback module (Page 294).

Technical specifications for communication is available at Communication (Page 291).

## F.5 Scope of delivery of remote control electronics

Description	Article number
19" slide-in module as 4 to 20 mA version, aluminum, 3 channels, non-Ex	A5E00151560
SIPART PS2 without basic electronics, single-acting, polycarbonate enclosure, non-Ex	6DR5910-...

## F.6 Grounding concept 19" slide-in module



- |   |                                                                                           |   |                                          |
|---|-------------------------------------------------------------------------------------------|---|------------------------------------------|
| ① | Link 1 / coupler (control room) via PA bus connection PAI/PAII at the 19" slide-in module | ⑤ | Field distributor; 48-wire, approx. 1 km |
| ② | Link 2 / coupler (control room) via PA bus connection PAI/PAII at the 19" slide-in module | ⑥ | Connection point                         |
| ③ | PA cable from QRL module to the control system, connection via Burndy B50 connector       | ⑦ | PA modules                               |
| ④ | Shield                                                                                    | ⑧ | 19" slide-in module                      |
- Ground = Ground

Figure F-5 Grounding concept, 19" slide-in module, PROFIBUS PA

See the notes marked with ❶ to ❹ in the graphic:

- ❶ Do **not** apply the cable shield at the positioner 6DR5910-....
- ❷ Mount the positioner 6DR5910-... to Ground 2 as described under Installing/mounting (Page 39).  
Ground the positioner enclosure as described under Interference immunity (Page 81).
- ❸ Ground each field distributor. Connect the cable shields only among each other.
- ❹ Connect the cable shields on the 19" slide-in module to the field distributor.
- ❺ Ground the 19" slide-in module.
- ❻ Connect the cable shields to the coupler. Ground the cable shields.

# Abbreviations

## G.1 Abbreviations for positioners

Abbreviation	Long form	Meaning
A/D	Analog-to-digital converter	-
AC	Alternating current	Alternating current
AI	Analog Input	-
AMS	Asset Management Solutions	Communication software from Emerson Process comparable with SIMATIC PDM
AO	Analog Output	-
AUT	Automatic	Operating mode
ATEX	Atmosphère explosible	Product and operation directive of European Commission for explosion protection.
CENELEC	Comité Européen de Normalisation Electrotechnique	Standards organization, responsible for European standardization in the field of electrical engineering.
CPU	Central Processing Unit	Master processor
CSA	Canadian Standard Association	Canadian standards organization
DC	Direct current	Direct current
DI	Digital Input	-
DIN	Deutsche Industrie Norm	-
DO	Digital Output	-
DTM	Device Type Manager	-
EDD	Electronic Device Description	-
Ex	Explosion protection	-
EMC	Electromagnetic compatibility	-
FDT	Field Device Tool	-
FF	FOUNDATION Fieldbus	Fieldbus of the Fieldbus Foundation
FM	Factory Mutual	American testing agency/insurance company
FW	Firmware	Device-specific software
GSD	Device master data	-
HART®	Highway Addressable Remote Transducer	Communication system for the development of industrial field busses.
IEC	International Electrotechnical Commission	International standards organization for standards in electrical engineering and electronics.
IP	International Protection Ingress Protection	International degrees of protection (long form as per DIN) Seepage protection (long form as used in US)
ISO	International Organization for Standardization	
LC	Liquid Crystal	Liquid crystal
MAN	Manual	Operating mode

G.3 Abbreviations for functional safety

Abbreviation	Long form	Meaning
NAMUR	Standards working group for measurement and control technology in the chemicals industry	Association of users in process conductor technology
µC	Microcontroller	One-Chip computer system
NCS	Non-Contacting Sensor	Sensor for contactless position detection
NEMA	National Electrical Manufacturers Association	US standards institution National Electrical Manufacturers Association
NPT	National Pipe Thread Taper	Pipe threading for self-sealing threads as per ANSI B.1.20.1
OPOS interface®	Open Positioner Interface	Standard interface for the connection between a positioner and a pneumatic linear or part-turn actuator
PA	Process Automation	Process automation
PDM	Process Device Manager	Siemens communication software / Engineering tool
PROFIBUS	Process Field Bus	Fieldbus
RSS feed	Rich Site Summary Feed	Shows changes in regular intervals to web sites you are subscribed to.
SIA	Slit initiator alarm module	Option module of the positioner
VDE	Verband der Elektrotechnik, Elektronik und Informationstechnik e. V.	Industrial and professional association
VDI	Verein Deutscher Ingenieure e. V.	Technical/scientific association

## G.2 Abbreviations positioner without basic electronics 6DR5910

<< 2018-01-25: Clarify what the meaning of abbreviations is and whether you can change these abbreviations >>

Abbreviation	Long form	Meaning
Exh.	Exhaust air	
CHx	Channel x	Channel
GND	Ground	Grounding
POS	Position	
QRL		
Shield		
URef		

## G.3 Abbreviations for functional safety

Abbreviation	Full term in English	Meaning
FIT	Failure in Time	Frequency of failure Number of faults within 10 <sup>9</sup> hours
HFT	Hardware Fault Tolerance	Hardware fault tolerance: Capability of a function unit to continue executing a required function in the presence of faults or deviations.



Abbreviation	Full term in English	Meaning
MooN	"M out of N" voting	<p>Classification and description of the safety-instrumented system in terms of redundancy and the selection procedures used.</p> <p>A safety-instrumented system or part that consists of "N" independent channels. The channels are connected to each other in such a way that "M" channels are in each case sufficient for the device to perform the safety instrumented function.</p> <p>Example: Pressure measurement: 1oo2 architecture. A safety-instrumented system decides that a specified pressure limit has been exceeded if one out of two pressure sensors reaches this limit. In a 1oo1 architecture, there is only one pressure sensor.</p>
MTBF	Mean Time Between Failures	Average period between two failures
MTTR	Mean Time To Restoration	Average period between the occurrence of a fault in a device or system and restoration of functionality
PFD	Probability of Dangerous Failure on Demand	Probability of dangerous failures of a safety function on demand
PFD <sub>AVG</sub>	Average Probability of Dangerous Failure on Demand	Average probability of dangerous failures of a safety function on demand
SFF	Safe Failure Fraction	<p>Proportion of safe failures:</p> <p>Proportion of failures without the potential to bring the safety-instrumented system into a dangerous or non-permissible functional status.</p>
SIL	Safety Integrity Level	The international standard IEC 61508 defines four discrete Safety Integrity Levels (SIL 1 to SIL 4). Each level corresponds to a range of probability for failure of a safety function. The higher the Safety Integrity Level of the safety-instrumented system, the lower the probability that it will not execute the required safety functions.
SIS	Safety Instrumented System	A safety-instrumented system (SIS) executes the safety functions that are required to achieve or maintain a safe status in a system. It consists of sensors, logic unit/control system and final controlling elements.



# Glossary

## Actuator

Converter that converts electric signals into mechanical or other non-electric variables.

## Actuator chamber

For pneumatic actuators which consist of two pressure chambers in double-acting versions and of a pressure chamber and a spring chamber in single-acting versions.

## Analog

A signal type which represents data using continuously varying, measurable and physical quantities, e.g. current or voltage. Opposite to digital. The range between 4 and 20 mA is often used to transfer analog signals.

## Analog-to-digital converter

An analog-to-digital converter is an interface between the analog environment and the digitally working computers. Only then can the computers be used for measurement and control tasks.

Analog-to-digital converters convert analog input signals to digital signals. Analog measurement data is thus converted into digital information. On the other hand, a digital-to-analog converter converts digital information into analog signals.

## Asset Management Solution (AMS)

Software package by Emerson Process. The AMS Device Manager, which is somewhat similar to the PDM, is the most significant part of the package.

## ATEX

ATEX is the abbreviation of the French term "Atmosphère explosible". ATEX stands for the two directives of the European Community in the field of explosion protection: the ATEX product directive 2014/34/EU and the ATEX operation directive 1999/92/EC.

## Auxiliary voltage

Auxiliary voltage is an electric supply or reference voltage that is required by some electric circuits in addition to the standard supply. The auxiliary voltage can, for example, be specially stabilized, have a particular level or polarity and/or other properties which are important for the correct functioning of switch components. Auxiliary voltage is used, for example, with four-wire systems.

## **Chamber**

A largely or completely enclosed cavity in a machine or apparatus.

## **Conduit piping system**

A piping system for the American market, wherein the electric and pneumatic lines are protected by a casing.

## **Configuring**

See parameter assignment.

## **Control fitting**

A valve consisting of an actuator + control valve + positioner.

## **Decrement**

From the Latin word decrementare, decrease. Decrement is the defined amount of change when decreasing a variable gradually. IT term that refers to a step-by-step decrease in a numeric value. →Increment.

## **Degree of protection**

The degree of protection of a device indicates the extent of protection. The extent of protection includes the safety of persons against coming in contact with live or rotating parts, and the protection of electric resources against the penetration of water, foreign bodies and dust. The degrees of protection of electric machines are indicated by an abbreviation comprising two letters and two numbers (e.g. IP55). The degree of protection is coded using the IP code. The degrees of protection are standardized in DIN EN 60529.

## **Device category 1**

Category 1 devices must be procured such that they ensure an extremely high degree of safety. Devices in this category must ensure an extremely high degree of safety even for faults that occur rarely. Even if two faults occur in the device, it should not lead to ignition. Devices in this category are suitable for use in zone 0 or 20.

## **Device category 2**

Category 2 devices must be procured such that they ensure a high degree of safety. Devices in this category must ensure the required degree of safety in case of frequent faults or ones that can be normally expected, e.g. defects in the device, and avoid ignition sources. Devices in this category are suitable for use in zone 1 or 21.

**Device category 3**

Category 3 devices must be procured such that they ensure a normal degree of safety. Devices in this category must ensure the required degree of safety in case of frequent faults or ones that can be normally expected, e.g. defects in the device, and avoid ignition sources. Devices in this category are suitable for use in zone 2 or 22.

**Digital**

Representation of a variable in the form of characters or numbers. The functional course of an originally changeable analog variable is simulated in predefined stages. Predefined values are assigned to these stages. Opposite to "analog".

**EEPROM**

EEPROM (Electrically Erasable Programmable Read-Only Memory; literally: elektrisch löschbarer, programmierbarer Nur-Lese-Speicher in German) is a non-volatile electronic memory. EEPROMs are often used when individual data bytes change over long time periods and need to be saved in a manner protected against power failure, e.g. configuration data or operating hours counters.

**Electromagnetic compatibility**

Definition as per the EMC law: EMC is the capability of a device to operate satisfactorily in an electromagnetic environment without itself emitting electromagnetic signals which interfere with other devices in that environment.

**Ex d**

"Flameproof enclosure" type of protection. When the potentially explosive mixtures enter the enclosure of a resource and an ignition source exists in the enclosure. The transfer of the explosion inside the enclosure to the surrounding space must be ruled out.

- d: flameproof enclosure

**Ex ia / Ex ib / Ex ic**

If potentially explosive mixtures enter the enclosure of a resource, it should not lead to ignition. Demarcation of energy and increased temperatures.

**Ex n**

Equipment containing energy-limiting, non-sparking contacts as well as circuits whose contacts are supplied with limited energy.

**Ex t**

Dust ignition protection with "t" enclosure. Dust ignition protection where the electric equipment has an enclosure providing protection against dust ingress and a measure for limiting the surface temperature.

## Factory Mutual

Industrial property insurer and certification agency in the USA. FM Global is one of the largest industrial insurers in the world who are specialized in the field of technically-supported property insurance. It offers services like product research, testing and certification.

## Failure that causes a dangerous situation

Failure with the potential to switch a safety-instrumented system to a hazardous or non-functioning safety status.

## Fieldbus

A fieldbus is an industrial communication system used to connect a number of field devices with a control device. Field devices include temperature transmitters, pressure transmitters, and positioners.

## Firmware

Firmware (FW) is software that is embedded on a chip in electronic devices – in contrast to software which is saved on hard disks, CD-ROMs or other media. These days, firmware is mostly stored in a flash memory or an EEPROM. Firmware is software in the hardware, and is thus an intermediate between software and hardware. Firmware is normally model-specific. This means that it does not function on other device models and is delivered by the manufacturing company. The corresponding devices cannot function without the firmware. The firmware mostly contains elementary functions to control the device, as well as input and output routines.

## Frequency shift keying

ENGLISH: Frequency shift keying (FSK)

Frequency shift keying is a simple modulation format in which digital values 0 and 1 are represented by two different frequencies.

## GSD file

The file that describes the properties of a PROFIBUS DP slave or a PROFINET IO device.

The GSD file is a database file for PROFIBUS devices. The device manufacturer provides the corresponding GSD file containing the description of device properties. The information in the file can be read using Engineering Tools.

## Increment

From the Latin word incrementare, increase. Increment is the defined amount of change when increasing a variable gradually. IT term that refers to a step-by-step increase in a numeric value. →Decrement.

**Initialization**

Setting the most important basic parameters. Requirement for commissioning the positioner.

**IP code**

The abbreviation IP stands for International Protection as per DIN. In English-speaking countries, IP stands for Ingress Protection.

**Microcontroller**

Microcontrollers (also  $\mu$ Controller,  $\mu$ C, MCU) are single-chip computer systems in which almost all components such as master processor, program memory, working memory and input/output interfaces are included in a single chip.

**NAMUR**

Standardization association for measurement and control in chemical industries. NAMUR is an association of users of process control technology. The members are mainly companies from German-speaking countries. The association was formed in Leverkusen in 1949.

**NEMA**

National Electrical Manufacturers Association. NEMA is a standardization institute in the USA. NEMA was formed in 1926 with the merge of Associated Manufacturers of Electrical Supplies and the Electric Power Club.

**Parameter assignment**

Individual parameter settings are specifically changed to adjust the positioner as per the actuator or other requirements. Parameter assignment is carried out after the complete commissioning of the positioner.

**Piezoelectric effect**

Name of a physical phenomenon. Due to mechanical compression loads on a crystal, an electric potential develops on specific crystal surfaces. In a reverse case, applying an electric field to specific crystal surfaces leads to crystal deformation.

**Potentially explosive atmosphere**

Mixture of air, combustible gases, fluff, fibers or dusts.

**Pressure chamber**

The pneumatic actuators are available in single and double-acting versions. In a single-acting version, only one pressure chamber is pressurized and depressurized. The pressure developed works against a spring. In a double-acting version, two pressure chambers work against each

other. Pressurizing the volume of one chamber simultaneously depressurizes the volume of the other.

### **Process Device Manager**

PDM is a Siemens software package for configuration, parameter assignment, commissioning and maintenance of network configurations and field devices. Part of SIMATIC STEP 7. Used for configuration and diagnostics.

### **PROFIBUS**

PROFIBUS stands for process fieldbus. PROFIBUS is a vendor-independent standard for networking field devices (e.g. PLCs, actuators, final control elements, and sensors). PROFIBUS is compatible with protocols such as DP (decentralized peripherals), FMS (fieldbus message specification) and PA (process automation).

### **Protection level**

- ia: Protection level. Electric equipment operating fault-free, and with existence of two countable errors.
- ib: Protection level. Electric equipment operating fault-free, and with existence of one countable error.
- ic: Protection level. Electrical equipment is not able to cause an ignition when operating fault-free.

### **Protocols**

Protocols contain information about data formats, time sequences and error handling when exchanging data between computers.

A protocol is a convention about establishing, monitoring and terminating a connection. Different protocols are required for a data connection. Protocols can be assigned to every layer of the reference model. Transport protocols are used for the lower four layers of the reference model and higher protocols are used for control, data provision and application.

### **Safety function**

Defined function executed by a safety-instrumented system with the objective of attaining or maintaining a safe status of the system by taking a defined hazardous incident into account.

Example: limit pressure monitoring

### **Safety-instrumented system**

A safety-instrumented system (SIS) executes safety functions that are required to attain or maintain the safe status in a system. It consists of sensors, logic unit/control system and final controlling elements.

Example: a safety-instrumented system consists of a pressure transmitter, a limit signal indicator and a servo valve.



**Sensor**

Converter that converts mechanical or other non-electric variables into electric signals.

**SIL**

The international standard IEC 61508 defines four discrete safety integrity levels (SIL) from SIL 1 to SIL 4. Every level indicates a probability range for the failure of the safety function. The higher the SIL of the safety-instrumented system, the higher the probability that the required safety function works. The achievable SIL is determined by the following safety-instrumented characteristics:

- Average probability of dangerous failures of a safety function on demand (PFD<sub>AVG</sub>)
- Hardware fault tolerance (HFT)
- Safe failure fraction (SFF)

**SIMATIC software**

Programs for process automation (e.g. PCS 7, WinCC, WinAC, PDM, STEP 7).

**Type 4X**

according to UL 50E. This standard contains additional requirements relating to the design and performance of enclosures which are to be used indoors and outdoors.

**Zone 0**

Area in which potentially explosive atmospheres build up often, regularly or over long durations during the normal operation of a device.

**Zone 1**

Area in which potentially explosive atmospheres build up occasionally during the normal operation of a device.

**Zone 2**

Area in which a potentially explosive atmosphere normally never builds up or builds up only for a short while during the normal operation of a device.

**Zone 20**

Zone 20 is an area in which a potentially explosive atmosphere in the form of a cloud of combustible dust in air is present continuously, over a long period, or frequently.

**Zone 21**

Zone 21 is an area in which a potentially explosive atmosphere in the form of a cloud of combustible dust in air can be occasionally produced during normal operation.

**Zone 22**

Zone 22 is an area in which a potentially explosive gaseous atmosphere in the form of a cloud of combustible dust in air never develops or develops only for a short while during normal operation.

# Index

## 1

- 19" slide-in module
  - Remote control electronics, 355

## 6

- 6DR5910-...
  - See Remote control electronics, 355

## A

- Accessories, 304
- Actuating pressure, 28
  - Figure, 93
  - Position, 94
- Adapter, 308
- Additional Support, 311
- Alarm module
  - Installation, 62
  - Position, 54, 55, 57
- Amplifier, (See booster)
- Analog Output Module (AOM), 86
- Article number
  - on the nameplate, 26
- Auxiliary power
  - Failure, 95

## B

- Basic electronics, (Motherboard)
  - Graphic, 30
  - Position, 54, 57
- Booster, 339
- Bus cable, 28
  - Connecting, 83

## C

- Cable gland, 308
  - Technical specifications, 284
- Carrier, 47, 135
- Carrier pin, 121, 123
- Certificates, 19, 311, (Certificates)
- characteristics
  - Safety, 239

- Cleaning, 241
- Coding bridge
  - PA module 19" slide-in module, 361
- Commissioning
  - Automatically, 120, 126
  - Cancel, 129
  - Interrupting, 120
  - Manual, 122, 128
- Compensation
  - Pneumatic leakage, 139
- Compressed air, 40
- Connecting
  - NCS sensor, 323
  - SIA module, 86
- Connection
  - Pneumatic, 93, 118
- Construction
  - Technical specifications, 283, 284
- Control system, 23, 237
- Coupler, 36
- Customer Support Hotline, 311

## D

- Dead angle function, 148
- Device operating mode
  - Parameter, 162
- Diagnostics, 256
  - During ongoing operation, 271
  - Extended, 138, 160
- Diagnostics guide, 277
- Disposal, 248

## E

- EMC filter module
  - Figure of ribbon cable, 54
  - Installation, 75
  - Retrofitting, 315
  - Scope of delivery, 308
- Enclosure, 303
- Exhaust air outlet, 28
- Extended diagnostics, 160
  - Parameter, 138

- F**
- Factory setting
    - Resetting to ~, 120, 126
  - Fast closing, 150
  - Fault identification, 277
  - Final controlling element, 237
  - FISCO, 36
  - Five-point controller, 23, 31
  - Freezing
    - Exhaust air outlet, 41, 236
  - Friction clutch, 23, 28
    - Position, 55
    - Set, 117
- G**
- Gear
    - switchable, 23
  - Gear latch, 52
- H**
- Hazardous area
    - Laws and directives, 19
    - Qualified personnel, 21
  - Hotline, 311
- I**
- I/Os
    - Technical specifications, 284
  - iNCS
    - Installation, 70
  - Initialization
    - Automatically, 111
    - Cancel, 129
    - Interrupting, 126
  - Installation
    - Alarm module, 62
    - Mechanical limit switch module, 67
    - Position feedback module, 60
  - Insulating cover, 54, 70
  - Internal NCS module
    - Commissioning, 119
    - Installation, 51, 70
    - Technical specifications, 297
  - Internet, 311
  - ly module, (See position feedback module)
- L**
- Laws and directives
    - Disassembly, 19
    - Personell, 19
  - Leakage
    - Pneumatic, 139
  - Leakage test
    - Offline, 261
  - Limit monitoring for total strokes, 158
  - Linear actuator
    - Automatic commissioning, 120
    - Automatic commissioning (flowchart), 111
    - Manual commissioning, 122
    - Pneumatic connection, integrated, 93
    - Single-acting, 24
  - Link, 36
- M**
- Manometer
    - Mounting, 333
    - Technical specifications, 284
  - Master
    - Class-1 master, 34
    - Class-2 master, 34
  - Material
    - Technical specifications, 283
  - Mechanic Limit Switches, 109
  - Mechanical limit switch module, 67
    - Installation, 67
    - Position, 54, 57
    - see Mechanic Limit Switches (MLS), 109
  - Mode of operation, 30
  - Modifications
    - correct usage, 20
    - improper, 20
  - Module cover
    - Position, 54, 57
  - Motherboard, (See basic electronics)
  - Mount
    - Dimensions, 50
  - Mounting kit
    - Linear actuator, 42
- N**
- Nameplate
    - Position, 55, 58

- Natural gas, 292
  - Operation, 109
- NCS, 74
  - Installation, 51
- NCS module
  - Internal, 51
- NCS sensor
  - Connecting to EMC filter module, 323
  
- O**
- Offline leakage test, 261
- Online diagnostics, 271
- Operation
  - Natural gas, 109
- Option module
  - Terminal, 28
- Option modules, 303
  - Installation, 55
- Order code, 26
- Ordering supplement, 26
  
- P**
- PA module 19" slide-in module
  - Coding bridge, 361
- Parameters 1 to 5
  - Overview, 134
- Parameters 6 to 53
  - Overview, 135
- Parameters A to P
  - Overview, 139
- Part-turn actuator
  - Automatic commissioning, 126
  - Automatic commissioning (flowchart), 111
  - Double-acting, 25
  - Manual commissioning, 128
  - Mounting, 47
- Pneumatic actuator, 31
- Pneumatic block, (See pneumatic block)
  - Position, 54, 57
  - Purging air selector, 118
- Pneumatic connections, 118
- Position feedback module
  - Installation, 60
  - Position, 55, 58
  - see Analog Output Module (AOM), 86
- Positioner
  - Replacing, 130
  - With linear actuator, 24
  
- Potentiometer, 74
  - Position, 54, 57
- Pressure gauge block, 24
  - Torque, 284
- Printed circuit board, (See basic electronics)
- Product name, 26
- PROFIBUS, 33
  - Automation system, 34
  - Connection, 35
  - DP, 33
  - Eigenschaft, 35
  - PA, 33
  - Profile, 35
  - Strand, 35
  - Topology, 34
- Purging air selector, 28, 118
- Pz, 239
  
- Q**
- QRL module
  - Remote control electronics, 355
- Qualified personnel, 21
  
- R**
- Reading initialization parameters, 130
- Remote control electronics
  - 19" slide-in module, 355
  - QRL module, 355
- Return procedure, 247
- Ribbon cable
  - Figure, 54
  - Graphic, 57
  
- S**
- Safety function, 235
- Safety position, 95
  - Parameter, 162
- Safety shutdown, 235
- Scope of delivery, 15
  - EMC filter module, 308
- Screen
  - Cleaning of~, 242
- Screw terminal, 83
- Sealing plug
  - Technical specifications, 336
- SELV, 36
- Service, 311

servo valve  
  Integrated, 23  
Shield connection, 28  
SIA module  
  Connecting, 86  
  Installation, 64, 65  
  Position, 54, 57  
SIL 2, 237  
Single-channel operation, 237  
Slot initiator, (See SIA module)  
Sound absorber, 28  
Special screw  
  Position, 54  
Station number  
  Parameter, 162  
Support, 311  
System pressure, (see Supply air)

## Y

Y1, 239

## T

Terminal strip, 118  
  Without flameproof enclosure, 83  
Terminating resistor, 36  
Terminating resistor T, 35  
Test certificates, 19  
Threaded adapter  
  Technical specifications, 336  
Tight closing, 150, 235  
Tightening torque  
  Technical specifications, (Torque)  
Torque, 283, 336  
Transmission ratio selector, 28, 52  
  Position, 54, 58  
Transmitter, 237  
Travel integral  
  Refer to limit monitoring for total strokes, 158

## V

Version  
  Technical specifications, 283

## W

Warning label  
  Position, 54, 57  
Warranty, 17  
Weight  
  Technical specifications, 283  
Wiring diagram on module cover, 55